


# TOSHIBA

FILE NO. 110-9407

## SERVICE MANUAL

# VIDEO CASSETTE RECORDER ***V-804B, V-854B***



(V-854B)

# CONTENTS

## SECTION 1 GENERAL DESCRIPTIONS

OPERATING INSTRUCTIONS .....	1-1 to 1-48
------------------------------	-------------

---

## SECTION 2 ADJUSTMENT PROCEDURES

1. MECHANICAL ADJUSTMENT .....	2-1	2. ELECTRICAL ADJUSTMENT .....	2-44
1-1. Mechanical Parts Location .....	2-1	2-1. Servo Circuit .....	2-46
1-2. Servicing Jig List .....	2-2	2-2. Self Diagnosis Function .....	2-48
1-3. Main Parts Servicing Time .....	2-3		
1-4. V3 Mechanism Check Method .....	2-4		
1-5. Mechanical Deck Removal and Mounting .....	2-7		
1-6. Main Parts Replacement .....	2-9		
1-7. Check and Adjustment .....	2-35		

---

## SECTION 3 SERVICING DIAGRAMS

1. INSPECTION PROCEDURE .....	3-1	8-3. KDB1, KDB2 Circuit Diagram .....	3-47
2. REMOVAL OF CABINET .....	3-2	8-4. Servo/Logic Circuit Diagram .....	3-50
3. ELECTRICAL UNITS LOCATION DIAGRAM .....	3-2	8-5-1. Video Circuit Diagram (Type A) .....	3-55
4. STANDING PC BOARDS FOR SERVICING .....	3-3	8-5-2. Video Circuit Diagram (Type B) .....	3-60
5. PART CONFIGURATION AND THEIR SYMBOLS .....	3-4	8-6. Audio Circuit Diagram .....	3-63
6-1. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM (Type A) .....	3-10	8-7. Terminal Circuit Diagram .....	3-65
6-2. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM (Type B) .....	3-12	9. PC BOARDS .....	3-68
7. BLOCK DIAGRAMS .....	3-14	9-1. KDB2 PC Board .....	3-68
7-1. Power Block Diagram .....	3-14	9-2. FCB PC Board .....	3-68
7-2. Sub Main Block Diagram .....	3-15	9-3. JSB PC Board .....	3-68
7-3. KDB1, KDB2 Block Diagram .....	3-17	9-4. KDB1 PC Board .....	3-69
7-4. Servo/Logic Block Diagram .....	3-21	9-5. MPX PC Board .....	3-69
7-5-1. Video Block Diagram (Type A) .....	3-29	9-6-1. Main PC Board (Type A) .....	3-71
7-5-2. Video Block Diagram (Type B) .....	3-32	9-6-2. Main PC Board (Type B) .....	3-75
7-6. Audio Block Diagram .....	3-35	9-7. Sub Main PC Board .....	3-77
8. CIRCUIT DIAGRAMS .....	3-38	9-8. Terminal PC Board .....	3-77
8-1. Power Circuit Diagram .....	3-38	9-9. Video 2 PC Board .....	3-79
8-2-1. Sub Main Circuit Diagram .....	3-41	9-10. Video 3 PC Board .....	3-79
8-2-2. MPX Circuit Diagram .....	3-44	9-11. AMP PC Board .....	3-79

---

## SECTION 4 PARTS LIST

1. SAFETY PRECAUTION .....	4-1	4. EXPLODED VIEWS .....	4-2
2. NOTICE .....	4-1	4-1. Packing Assembly .....	4-2
3. ABBREVIATIONS .....	4-1	4-2. Remote Control Unit (V-804B) .....	4-2
3-1. Integrated Circuit IC .....	4-1	4-3. Remote Control Unit (V-854B) .....	4-2
3-2. Capacitor (Cap) .....	4-1	4-4. Cabinet Assembly .....	4-2
3-3. Resistor (Res) .....	4-1	4-5. Chassis Assembly .....	4-3
		4-6. Mechanical Parts (1) .....	4-5
		4-7. Mechanical Parts (2) .....	4-5
		5. PARTS LIST .....	4-6

Video Plus+ and PlusCode are trademarks of Gemstar Development Corp.  
Video Plus+ system is manufactured under license from Gemstar Development Corporation.

# SECTION 1


## GENERAL DESCRIPTIONS

### OPERATING INSTRUCTIONS (V-804B)

**1**


## IDENTIFICATION OF CONTROLS

### Front Panel




\*This jack is for a special case of satellite receiver setting. Not in general use.

### Rear Panel





## VTR Display



# 1

## IDENTIFICATION OF CONTROLS

### Remote Controller



#### VTR/TV

To select the equipment to be operated by this remote control unit.

VTR: Set to "VTR" to operate this VTR.

TV: Set to "TV" to operate a TV.

# 1

## MULTI BRAND REMOTE CONTROLLER


The remote controller provided with this VTR is compatible with various brands of TVs.

### Information

Remote control codes for a variety of TV brands have been programmed in this remote controller. The TOSHIBA code has initially been set in the unit. If your TV is not a TOSHIBA, you must first select a brand code for your brand maker of TV.

### Important


Set the VTR/TV selector on the remote controller to "TV".



### Setting the Brand Code

- 1 While holding down the **OSP** button, press the two digits of your TV's brand code by using **number buttons**.  
(For your brand code, see the table on the next page.)

Hold down.



- 2 Release the **OSP** button.  
The brand code you set is memorized in the remote controller.


Release.



- 3 Point the remote controller at your TV and use each button listed in "Operating a TV" (see the next page) to make sure that the TV is operated properly.

### Note

If you replace the remote controller's batteries, set the brand code again.



## Table of Brand Code

Brand name of your TV	Brand code
TOSHIBA	01, 14, 15, 16, 17, 19
AKAI	08
BANG & OLUFSEN	20
BLAUPUNKT	04
BRANDT	11
BRIONVEGA	20
CGE	19
CONTINENTAL EDISON	22
FERGUSON	11, 25
FINLUX	02, 15, 20
FISHER	08
FORMENTI	20
GOLDSTAR	02
GRUNDIG	04, 15, 19
HITACHI	06, 10, 11, 22
IMPERIAL	19
JVC	07
LOEWE	02
LOEWE OPTA	02, 20
METZ	20
MITSUBISHI	02, 09, 14
MIVAR	19
NOKIA	21
NORDMENDE	10, 11, 22
PANASONIC (NATIONAL)	03, 21
PHILIPS	02, 18, 20
PHONOLA	02, 18, 20
PIONEER	11, 21
RADIOLA	02, 18
RADIOMARELLI	20
REX	21
SABA	10, 11, 20, 21, 22
SALORA	21
SAMSUNG	02
SANYO	08, 14
SCHNEIDER	02
SELECO	21
SHARP	05, 14
SIEMENS	04
SINGER	20
SINUDYNE	20
SONY	13, 14
TELEAVIA	11
TELEFUNKEN	11
THOMSON	10, 11, 22
WEGA	20
YOKO	02

- For some brands, several remote control codes (brand code) are allocated.

## Operating a TV

Once the brand code is set, you can operate your TV with this remote controller by using the following buttons.

### Preparation

Set the VTR/TV selector to "TV".

### ON/STANDBY button



To turn the TV on or off.

### CH/TRK buttons



To select TV channel in the upper or lower direction.

### VOL (Volume) buttons



To adjust the sound level.

### INPUT SELECT button



To select an external source, such as a VTR.

### Number buttons / ENTER button

To select TV channel directly.  
(Ways of use may differ. Check how they work on your TV.)

Ex. to select TV channel 3.

- Press **number button 0** and **3**.
- Press **number button 0, 3** and the **ENTER** button.
- Press the **ENTER** button and **number button 3**.

Ex. to select TV channel 16.

- Press **number button 1** and **6**.
- Press **number button 1, 6** and the **ENTER** button.
- Press the **ENTER** button twice and **number button 1, 6**.

### Important

Some TVs may not respond to all of the operations above, or may not be operated at all with this remote controller. In such a case, operate the TV with its own remote controller.

# 2

## HOW TO ALLOCATE A TV CHANNEL TO THE VIDEO CHANNEL


To watch or record video pictures when your TV and VTR are connected only by aerial, you need to tune your VTR into a TV channel (e.g. 5).

### Important

The following adjustment is necessary when the VTR is connected to the TV via the AERIAL OUTPUT socket only.

### Information

The VTR converts the received signals into the type of output signals used in TV broadcasts, and send them to your TV from the AERIAL OUTPUT socket. Your television must have a channel set aside exclusively for these VTR signals. This is called the video channel.




**1** Turn on the TV.

**2** Select a free station on the TV which you wish to use for your video picture, for example station 5. This station 5 will be only used for watching a video picture.


**3** Press the **ON/STANDBY** button to turn on the VTR.



**4** Hold down the **OSP** button for more than 5 seconds.



**5** Tune the TV (on station 5 for example in step 2) so that the following screen is shown clearly. (For tuning the TV, refer to the TV's manual.)



If after tuning (in step 5), you still have some interference because of neighbouring broadcast channels, press the **SHIFT** button to select another video channel e.g. between channels 53 and 67.





Re-tune the TV to around UHF channel 62 (for example), and confirm the screen is displayed clearly.

**6** Press the **OSP** button. Video channel setting is complete.



Set the VTR/TV selector on the remote controller to "VTR".




### ***Note on the Antenna Output***

On the screen in step 5, the antenna output can be set to "MIX" or "SW".

(Applied only when the VTR is connected to your TV only via the AERIAL OUTPUT socket.)

Press **number button 3** to select "MIX" or "SW".



**MIX:** You can watch a video picture on the video channel regardless of whether or not you have pressed the TV/VIDEO button.

The switch should only be set to "SW" if the video pictures or TV pictures cannot be obtained clearly.

**SW:** You can watch a video picture on the video channel only when the "VIDEO" indicator is lit in the VTR display by pressing the TV/VIDEO button.


# 2

## MENU/SETUP SCREEN

You can set desired functions on the TV screen.

### Preparation

- Confirm the TV is on and set it to the video input mode, or select the video channel if you made the aerial connection for the TV and the VTR.
- Set the VTR/TV selector on the remote controller to "VTR".




### MENU Screen


- 1 Press the **ON/STANDBY** button to turn the VTR on.




- 2 Press the **OSP** button.  
The MENU screen appears.



### SETUP Screen



- Press **number button 2**.  
The SETUP screen will appear on the TV.



If the TV programme or the tape is monochrome, press **number button 3** to set to "OFF".

Press the **OSP** button twice to return to the normal TV screen.


# 2

## ON SCREEN DISPLAY


The VTR tells you current operating modes on the TV screen.

### Information

- When you press the **DISPLAY** button, the VTR displays the current operating mode on the TV screen.
- In addition to the indication shown below, the VTR may display other indications such as index search. See respective pages for each explanation.



Pressing the **DISPLAY** button makes the operating mode appear. If you press this button again, the indication goes off, leaving the counter indication (counter, tape remaining, clock) on the screen. To turn it off, press the **DISPLAY** button once more.



The indicator varies with the operating mode.

Ejecting a tape	▲
Stop	■
Double speed playback	▶▶
Fast-forwarding	▶▶
Forward picture search	▶▶
Rewinding	◀◀
Reverse picture search	◀◀
Recording	●
Recording pause	●
Playback	▶
Reverse playback	◀
Still picture	
Frame advance	▶
Slow playback	▶▶
Reverse slow playback	◀◀

The indication varies with the receiving NICAM broadcasts.

NICAM broadcasts	
NICAM Stereo or Mono	N I C A M ∞
NICAM Bilingual sound (Not yet used in U.K.)	N I C A M I/II
Normal TV programme (standard mono)	not lit

## HOW TO ALLOCATE TV STATIONS ON THE VTR


To watch and record TV programmes via the VTR, it is first necessary to store each TV station in the memory of the VTR. This VTR can store up to 48 positions for TV broadcasting stations.

## Information

Each TV station operating in the U.K. (e.g. BBC1, ITV) broadcasts on a unique frequency, which in turn has been allocated a transmission channel number (21 – 69). However, this unique frequency and corresponding number changes for each TV station from area to area. For example, BBC1 in London uses channel number 26, while in Oxford BBC1 uses channel number 57 (i.e., CH57). This VTR will indicate these channel numbers (1 – 9, 21 – 69) during tuning.

### - Preparation

- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".
- Turn on the VTR.
- If you use a satellite receiver, make the connection correctly and turn it on.



### Example


to store BBC1 to position number 1 on your VTR.

Allocation of the TV stations into the memory of the VTR is expected to be as follows, for Video Plus+ recording.


BBC1: Position number 1  
BBC2: Position number 2  
ITV: Position number 3  
CHANNEL 4: Position number 4  
Satellite: Position number 10 (example)  
(if not connected via SCART)

### Important

If the "L1", "L2" or "SA" indicator appears in the VTR display, press the INPUT SELECT button so that the position number appears.




- 1** Press the **OSP** button.




- 2** Press number button 4.

④



- 3** Press **number button 1** to select "CH MEMORY".  
The VTR enters the tuning mode.

①



- 4** Press the **CH/TRK** button to select position number 1 for this example.

⌈


CH/TRI  
▼



- 5** Repeatedly press the **SHIFT** button until BBC1 is found.




SHIFT



- If the received TV station signal is not BBC1, press the **SHIFT** button again.

- 6** If a clear picture does not appear on the TV screen after searching is finished, make fine adjustment with the **INDEX** buttons.



- 7** Repeat steps 4 to 6 for other TV stations and your satellite receiver if not connected by a SCART.

BBC2 on position number 2  
 ITV on position number 3  
 CHANNEL 4 on position number 4  
 Satellite on position number 10

Record all position numbers you stored on the VTR in the chart (GUIDE channel table) below so that you will be ready to use the Video Plus+ recording.

- 8** Press the **OSP** button.  
 Channel tuning is now complete.




Once channel tuning is done, you will select the TV station by selecting the position number on which the desired TV station is stored.

## Skipping Channels


You can prevent the use of certain channel position numbers when you use the skip function.

- 1) Set the VTR to the tuning mode following steps 1 to 3 of the channel storing procedure.
- 2) Select the position number you want to skip with the **CH/TRK** button.

**Example:** to skip position number 4



- 3) Press **number button 3**.  
 The following indication will appear in the VTR display with the skip function on or off.



If you press **number button 3** again, the TV channel number will appear and the skip function will be cancelled.

- 4) Press the **OSP** button.  
 Channel skipping is now complete.

**To cancel channel skipping**  
 Follow steps 1) to 4) above.

## GUIDE Channel Table

Stations	GUIDE	Position number in which the TV station has been memorized on the VTR.	Stations	GUIDE	Position number in which the TV station has been memorized on the VTR.
BBC1	001	1	PRO 7	120	
BBC2	002	2	TELE 5	121	
ITV	003	3	TELECLUB	122	
CHANNEL 4	004	4	UK GOLD	123	
RTE (IRELAND)	005		DISCOVERY	124	
NETWORK 2 (IRELAND)	006		BRAVO / ADULT CHANNEL	125	
SKY ONE	101		CNN	126	
SKY NEWS	102		EURONEWS	127	
SKY MOVIES	103		THE LEARNING CHANNEL	128	
THE MOVIE CHANNEL	104		QVC	129	
SKY SPORT	105		UK LIVING	130	
NICKELODEON / NICK AT NIGHT	106		RAI 1	131	
EUROSPORT	107		RAI 2	132	
GALA VISION	108		TV5 EUROPE	133	
MTV EUROPE	109		TVE INTERNATIONAL	134	
CHILDREN'S / FAMILY & CHINESE CHANNEL	110		MBC/ARABIC	135	
SKY MOVIES GOLD	111		VTM	136	
BBC WORLD SERVICE	112		SPORTNET	137	
RTL 4	113		VIDEO HITS ONE	138	
FILMNET +	114		SUPERCHANNEL	144	
RTL PLUS INTERNATIONAL	115		JAPAN TV	145	
SAT 1	116		RTL-5	146	
PREMIERE	117		FILMNET MOVIES	147	
3 SAT	118		T.N.T./CARTOON NETWORK	149	

# 2

## SETTING THE CLOCK


When the VTR is first connected to the AC socket or after a power failure, "0:00" blinks in the VTR display and it is necessary to set the clock.

### Preparation

- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".

### Information


The item to be set will blink. Set the data with the number buttons, following the blinking position. You can change the blinking position by pressing the SHIFT (→/←) buttons.



### Example


to set the clock to 15:30 on October 5, 1994.

- 1 Press the **OSP** button.



- 2 Press **number button 1**.


①



- 3 To set the clock for summer time (daylight saving), press **number button 1**: if not set, press **number button 2**.


①

②



- 4 Set the hours and minutes. (24 hours clock format)

① → ⑤ → ③ → ①




### Correcting a mistake



Press the SHIFT (←) button repeatedly until the number you set incorrectly blinks. Press the correct number button and then press the SHIFT (→) button to return to the previous digit.

- 5 Set the day and month.

① → ⑤ → ① → ①



- 6** Set the year.  
Press the numbers of the last two figures.





### ***Resetting the VTR clock***

If a power failure of short duration has occurred, the colon between the hour and minutes digits in the VTR display blinks.

The time displayed may be incorrect.



- 7** Press the **OSP** button.  
Now the clock starts.



In this case, you must set the VTR clock again.  
Follow the clock setting procedure.

- 8** Press the **OSP** button to return to the normal TV screen.



#### **Notes**

- If you input irregular clock data such as February 29, 1994, it will not be accepted.
- The built-in calendar of this VTR is valid from 1990 to 2089.


# 3

## LOADING/EJECTING A VIDEO CASSETTE

This section explains how to handle video cassettes.



### ■ Loading a video cassette

Push the cassette into the cassette compartment with the window side facing up and the label side towards the front.

The power is automatically turned on. The  mark will appear in the VTR display.

### ■ Ejecting a cassette

Press the **EJECT** button. The cassette is ejected from the cassette compartment.




## Precautions When Using Video Cassettes

- Video cassettes have a safety tab to prevent accidental erasure. If the tab has already been removed, recording cannot be performed.


### To prevent accidental erasure

Remove this safety tab with a screwdriver.



### To record again

Cover the tab hole with adhesive tape.



- Avoid exposing cassettes to direct sunlight. Keep them away from heaters.
- Avoid extreme humidity, vibrations or shock, strong magnetic fields (near a motor, transformer or magnet) and dusty place.
- Place cassettes in their cassette cases and store them in a vertical position.
- Do not insert hand(s) or any foreign object(s) into the cassette compartment as injury may result or the VTR may be damaged.
- Children using the VTR should be supervised.





# 3

## TV VIEWING

Three types of normal TV viewing are possible when the VTR is connected to a TV.

### Preparation

Make sure that the VTR is connected to your TV using the connection method.



### Using the VTR Tuner

- 1 Press the **ON/STANDBY** button to turn the VTR on.
- 2 Turn on the TV and select the video channel or video input mode depending on the TV connection method.



Video channel or video input mode

- 3 Press the **TV/VIDEO** button so that the "VIDEO" indicator appears in the VTR display.



- 4 Press the **CHANNEL** (v / ^) button on the front panel of the VTR, or press the **CH/TRK** button on the remote controller to select a TV programme you want to watch.



### Using the TV Tuner

- 1 Turn on the TV.
- 2 Choose a TV programme you want to watch, using the station selector on the TV.




Station selector on the TV

It is not necessary to turn on the VTR in this case. The VTR needs to be plugged in an AC outlet.

### Using the TV Tuner While the VTR is Turned on

- 1 Turn on the TV and the VTR.
- 2 Turn off the "VIDEO" indicator by pressing the **TV/VIDEO** button.



- 3 Choose a TV programme you want to watch, using the station selector on the TV.



# 3

## PLAYBACK


This section explains a basic playback operation.

### Preparation


- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".



- 1 Load a recorded cassette.  
The power is turned on.  
If the cassette's safety tabs is removed, playback starts automatically.




- 2 Press the **PLAY** button to start playback.




- 3 Press the **STOP** button when playback is finished.



- **Rewinding a video cassette tape:**  
Press the **REW** button in the stop mode.



- **Fast-forwarding a video cassette tape:**  
Press the **FF** button in the stop mode.



### Notes

- Televisions connected via SCART leads normally select the video input mode automatically when the **PLAY** button is pressed.

### Playback and recording in LP mode

When playing back a tape that has been recorded on another VTR, it may happen that the picture colour disappears, the picture becomes unstable and that noise occurs. It is therefore recommended that tapes that have been recorded on this VTR also are played back on this VTR.

## Adjusting the Tracking

The VTR automatically adjusts the tracking for a clear picture and sound.

### ■ Digital auto tracking

When playback starts, the digital auto tracking is automatically activated. (the "DT" indicator blinking)



Tracking is set when the "DT" indicator stops blinking.

#### Notes

- While the "DT" indicator is blinking, the playback picture and sound may be distorted.
- The digital auto tracking is activated only in the playback mode.

### ■ Adjusting the tracking manually

If the VTR cannot find the best possible tracking point, adjust the tracking manually.

Hold down the **CH/TRK** button until you can obtain the best possible picture and sound.



#### Notes

- When you want to reset the tracking point to the center, press both the  $\vee$  and  $\wedge$  buttons at the same time.
- The noise on the screen may not be completely removed depending on the tape used, especially when the tape has been recorded on another VTR.

### To return to digital auto tracking mode

Hold down simultaneously both **CHANNEL** ( $\vee$  /  $\wedge$ ) buttons on the front panel of the VTR for more than 1 second.



The "DT" indicator lights up.

## Hi-Fi and Normal Audio System

This unit's Hi-Fi stereo audio track (2-channel) can be used to playback an excellent Hi-Fi sound. Sound that has been recorded on the normal audio track is compatible with conventional VTR's.

When playing back a Hi-Fi recorded tape, press the

**A. SELECT** button to select desired sound output.

The **L**, **R** indicators in the VTR display tell you what kind of sound output you are selecting. Accordingly, you can select the desired sound output while observing the lit and/or unlit indicators.



## Audio Mix Function

The VTR can output sounds, mixing one on the Hi-Fi stereo audio tracks and one on the normal audio track.

This function enables you, for example, to record your voice on a Hi-Fi recorded tape ("AUDIO DUBBING").

Press the **A. SELECT** button several times to make "MIX" appear in the VTR display.



### CAUTION

- The VTR has a dynamic range of more than 90dB for Hi-Fi audio capability. It is recommended that you check the maximum level if you are going to listen to the Hi-Fi audio signals through a stereo amplifier. A sudden surge in sound input may cause speaker damage.
- Some speakers and televisions are specially shielded to prevent television interference. If both are of the non-shielded type, do not place the speakers next to a TV set, as the video playback picture may not be normal because of mutual interference.


# 3

## NTSC-RECORDED TAPE PLAYBACK

This VTR can play back an NTSC-recorded tape. You can watch the playback picture on a PAL system TV or an NTSC 4.43 system TV.

### Information

NTSC tape: Tapes on which NTSC M system broadcasts mainly transmitted in the U.S. and Japan are recorded, and tapes recorded in the NTSC video system which are commercially available on the market. For the playback operation, see "PLAYBACK".



If you connect this VTR to a multi system TV (NTSC 4.43 compatible) and play back an NTSC tape




- 1 Press the **OSP** button.  
The MENU screen will appear on the TV.
- 2 Press **number button 2** to select "VTR SETUP".
- 3 Set "NTSC ON PAL TV" to "OFF" by pressing **number button 2**.

②

SETUP		
1	TAPE SELECT	(E180)
2	NTSC ON PAL TV	(OFF)
3	COLOUR	(ON)
4	16:9	(OFF)
5	VIDEO PLUS+ EXTEND	(OFF)
6	NICAM	(ON)
SET=1-6 END=OSP		

- 4 Press the **OSP** button twice to return to the normal TV screen.

If you connect this VTR to a PAL system TV and play back an NTSC tape




- 1 Press the **OSP** button.  
The MENU screen will appear on the TV.
- 2 Press **number button 2** to select "VTR SETUP".
- 3 Set "NTSC ON PAL TV" to "ON" by pressing **number button 2**.

②

SETUP		
1	TAPE SELECT	(E180)
2	NTSC ON PAL TV	(ON)
3	COLOUR	(ON)
4	16:9	(OFF)
5	VIDEO PLUS+ EXTEND	(OFF)
6	NICAM	(ON)
SET=1-6 END=OSP		

- 4 Press the **OSP** button twice to return to the normal TV screen.



#### Notes for Using a PAL TV for NTSC Playback

- Use a TV compatible with PAL video signals of PAL 60 (525 lines).

When the TV, that is not compatible with PAL video signals of PAL 60, is used (when the TV, that is compatible only with PAL video signals of PAL 50 (625 lines), is used) NTSC playback pictures may roll up and down. This is not malfunction of the VTR or the TV. If your TV is equipped with a V-HOLD control, it may be possible to stop the rolling of pictures by adjusting this control.

About PAL 50 and PAL 60 of PAL video signals:

PAL 50 : is a normal signal and its PAL video signal is 50 fields (625 lines).

PAL 60 : is a special signal and its PAL video signal is 60 fields (525 lines).

Some TVs operate properly only with PAL 50 signals, some TVs operate properly with both PAL 50 and 60 signals.

Therefore, if your TV is switchable between PAL 50 (625 lines)/PAL 60 (525 lines), you can view an NTSC recorded tape in the PAL colour system with your own TV.

- Depending on the TV used, the picture may shrink vertically and black bars may appear both at the top and bottom of the TV screen.  
This is not an indication of malfunction.

- Variable speed playback (picture search, still, slow playback, etc.) may produce a skewed image and quite a bit of noise on the picture.

- If the tape pre-recorded in the SP tape speed mode is played back in the picture search mode, the picture may be reproduced with no colour.

#### Note

For viewing an NTSC-recorded tape, we recommend using an NTSC 4.43 TV.



# 3

## VARIABLE SPEED PLAYBACK

You can play back a tape at various tape speeds.

### Preparation


- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".




### Picture Search

This function allows you to quickly locate a particular scene or segment on the tape while monitoring the playback picture in the fast-forward or rewind mode.

- 1 During playback, press the **REW** or **FF** button. The tape runs at 5 times the normal playback speed.



- 2 If you hold down the **REW** or **FF** button in the picture search mode, the searching speed increases.



- When you release the button, the searching speed returns to the 5 times searching speed.

- 3 To resume normal playback, press the **PLAY** button.

#### Notes

- The picture will have some interference. This is not a defect in the unit.
- If you play back a tape recorded in the LP mode or a tape recorded on another VTR in various mode, the picture may be noisy, or monochrome.
- If you press the **REW** or **FF** button while rewinding or fast-forwarding the tape, the VTR enters the picture search mode. If you press the **REW** or **FF** button while picture searching, the VTR enters the rewinding or fast-forwarding mode, respectively.

### Still Picture

This function enables you to freeze a picture so that you can watch important scenes closely.

- 1 During playback, press the **PAUSE/STILL** button. The picture freezes.



- 2 To resume normal playback, press the **PAUSE/STILL** button.



The still picture mode will be released automatically after approximately 5 minutes. The VTR will then shift to the normal playback mode.

#### Adjusting still picture stability

If the still picture is distorted or flickers, hold down the **CH/TRK** button until the picture becomes stable.



#### Notes

- The distortion of the still picture may not be eliminated completely if the tape has been recorded on another VTR.
- If you play back a tape recorded in the LP mode or a tape recorded on another VTR in various mode, the picture may be noisy, or monochrome.
- The still picture may shake if a picture of a fast-moving object or scene is frozen. This is not a defect in the unit.
- If noise appears in the still picture, adjust the tracking manually in the slow-motion picture mode.

---

## Slow-motion Picture

This function has two variations: 1/6th and 1/12th the normal speed.

- 1 During playback, press the **SLOW** button.  
The tape will run at about 1/6th the normal playback speed.

Playback   to 1/6 slow

- 2 If you press the **SLOW** button again, the tape speed changes to 1/12 slow.

1/6 slow   to 1/12 slow

Each time you press the **SLOW** button, the speed changes between 1/6 and 1/12 alternately.

- 3 To resume normal playback, press the **PLAY** button.

1/6 slow or 1/12 slow   to normal playback

The slow-motion picture mode will be cancelled automatically after approximately 5 minutes. The VTR will shift to the normal playback mode.

### Adjusting the tracking in the slow-motion mode

If the slow-motion picture is noisy, hold down the **CH/TRK** button until the best picture is obtained.



### Notes

- The slow-motion picture may flicker up and down. This is not a defect in the unit.
- The noise in the slow-motion picture may not be eliminated completely by the tracking adjustment.

---

## Frame Advance

This function allows you to advance the picture frame by frame.

- 1 During playback, press the **PAUSE/STILL** button to put the VTR in the still picture mode.

Playback   to still picture

- 2 Press the **PLAY** button.  
The picture advances one frame each time you press the **PLAY** button.

Still picture   to frame advance

When the **PLAY** button is held down, the tape runs at 1/25th the normal playback speed.

- 3 To resume normal playback, press the **PAUSE/STILL** button.

# 3


## SHUTTLE RING OPERATION

You can also activate variable speed playback such as the picture search or slow playback by turning the SHUTTLE ring on the VTR.


### Information

The picture search and slow playback speed differ depending on the video system and recording tape speed of the tape used.

	Slow playback		Picture search	Accel. picture search
PAL (SP)	1/12 slow	1/6 slow	x5	x13
PAL (LP)	1/12 slow	1/6 slow	x5	x13
NTSC (SP)	1/15 slow	1/7 slow	x5	x9
NTSC (SLP)	1/15 slow	1/7 slow	x5	x27



- The diagram below explains for the case of PAL tape recorded at SP/LP speed. For NTSC tapes (SP/SLP), refer the table above.



### Notes

- The still mode or reverse playback (-x1) mode will be released automatically after about 5 minutes and forward playback will start.
- The reverse slow playback mode will be released automatically after about 1 minute and forward playback will start.
- Fast-forwarding or rewinding started from the stop mode continues even if the SHUTTLE ring is released. To stop, press the STOP button.




# 3

## COUNTER FUNCTION


You can see the clock, linear tape counter or tape time remaining in the VTR display.

### Preparation

Set the VTR/TV selector to "VTR".



VTR display



### Changing the Counter Display

Each time you press the **COUNT/TR** button, the display changes in sequence as follows:

Linear time counter	VTR display 1 25 00s hour minutes seconds
Tape time remaining	1 30 TR
Clock	15:30
Linear time counter	Linear time counter

#### To reset the linear time counter to "0H00M00S"

The counter is automatically reset to "0H00M00S" when a cassette is ejected. If you want to reset the counter at some other point, for example, when you start a new recording, just press the **COUNTER RESET** button.

#### Notes

- The linear time counter does not work on non-recorded portions of the tape.
- When the tape is ejected or the VTR is turned off, the linear time counter changes to clock display.
- If the tape rewinds back over "0H00M00S", "—" appears in the VTR display.
- The displayed time of the linear time counter is approximation.

### Tape Time Remaining

- Turn on the VTR and load a cassette.
- Press the **OSP** button.  
The MENU screen will appear on the TV.



- Press **number button 2** to select "VTR SETUP".

②

SETUP	
1 TAPE SELECT	(E180)
2 NTSC ON PAL TV	( ON)
3 COLOUR	( ON)
4 16:9	( OFF)
5 VIDEO PLUS+ EXTEND	(OFF)
6 NICAM	( ON)
SET=	END=OSP

- Press **number button 1** and select a tape length, E180, 240, 260 or 300 depending on the tape to be used. Each time you press **number button 1**, the tape length changes.

①

E180: when using an E-195 tape or shorter.  
E240: when using an E-210 or E-240 tape.  
E260: when using an E-260 tape.  
E300: when using an E-300 tape.

- Press the **OSP** button twice to return to the normal TV screen.
- Press the **COUNT/TR** button.  
The tape time remaining is displayed. (See the chart on the left column.)

#### Notes

- The displayed time remaining is an approximation.
- The time remaining is calculated according to the tape speed (SP or LP) and the cassette type.
- It is necessary to set the tape length correctly beforehand in step 4 when you use the time remaining display.


# 3

## INDEX SEARCH FUNCTION



You can easily locate the desired programme using the index signal registered on the tape.

### Information

**Index Search:** Plays back each programme with an index signal for about 5 seconds.



**Skip Search:** Finds and plays back a programme with an index signal you specified.



### Registering Index Signals Automatically

An index signal is automatically registered when a recording starts.

An index signal is also registered when one-touch timer recording or timer programme recording starts.


#### Note

An index signal is not registered automatically when the VTR is in the recording pause mode and recording restarts.

### Registering Index Signals Manually

During recording, index signals can be manually registered at desired points on the tape.

Press the INDEX (+) button at a desired point.



#### Note


When registering two or more index signals, certain intervals are required: more than 1 minute in the SP mode and more than 2 minutes in the LP mode.

## Index Search

This function plays back the tape for about 5 seconds at each index signal.

- 1 Load a cassette with the index signals registered.
- 2 Press the **INDEX (-)** or **(+)** button while in the stop or playback mode.

 : to search in the reverse direction

 : to search in the forward direction



The VTR fast-forwards or rewinds the tape. When an index signal is found, the VTR plays back the tape for about 5 seconds, and then resumes fast-forwarding or rewinding. This operation is repeated at each index signal.

- 3 Press the **PLAY** button when the desired programme is found. Normal playback starts.





### Notes

- At the very beginning of the tape, the index search function may not work correctly.
- If you registered the index signals on a tape recorded on another VTR, the recording may be blurred at the index point and the index search may not work correctly.



## Skip Search

This function fast-forwards or rewinds the tape to the point at which the selected index signal is registered, and starts playback from there.

- 1 Load a cassette with the index signals registered.
- 2 Press the **INDEX (-)** or **(+)** button twice in the stop or playback mode.




- 3 Press the **INDEX (-)** or **(+)** button depending on the direction where your desired programme is located. Each time you press the **(-)** or **(+)** button, the number decreases or increases respectively.



The VTR starts to search for the point you specified with the **(-)** or **(+)** button. When the point is found, playback will start automatically.

### Notes

- You can set an index number up to  $\pm 20$ .
- The skip search is cancelled when the **PLAY** or **STOP** button is pressed.




# 3

## TIME SEARCH FUNCTION

The VTR fast-forwards or rewinds the tape by an amount of time you specified.

### Preparation


- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Set the TV/VTR selector to "VTR".




**Example** to move tape ahead 1 hour and 15 minutes

**3** Press the FF or REW button within 10 seconds.  
Time search starts.

**1** Press the T. SEARCH button in the stop mode or playback mode.



**2** Within 10 seconds, press number buttons to set the hours and minutes.



To set less than one hour, put 0 for the hours.

### Notes

- If you make a time search in the playback mode, playback will start after the search is completed.
- The displayed time is approximation.


# 3

## NICAM BROADCAST SYSTEM AND SOUND OUTPUT

This VTR incorporates a special decoder that can receive NICAM broadcast programmes.

### Information

NICAM programmes are divided into 3 types. NICAM Stereo, NICAM Mono and Bilingual (transmission in another language). NICAM Programmes are always accompanied by a standard mono sound broadcast and you can select the desired sound with "NICAM ON/OFF" on the SETUP screen (when recording) or with the A. SELECT button (when playing back).



### NICAM Broadcast Programme Setting

- 1 Press the **OSP** button.  
The MENU screen appears.
- 2 Press **number button 2** to select "VTR SETUP".
- 3 Press **number button 6** to switch "NICAM" on or off.

⑥

SETUP	
1 TAPE SELECT (E180)	
2 NTSC ON PAL TV (ON)	
3 COLOUR (ON)	
4 16:9 (OFF)	
5 VIDEO PLUS+ EXTEND (OFF)	
6 NICAM (ON)	
SET=1-6	END=OSP

ON: Normally set at this position.

OFF: Only set at this position to record the standard mono sound during a NICAM broadcast if the stereo sound is distorted due to inferior reception conditions.

- 4 Press the **OSP** button twice to return to the normal TV screen.

Indicators appearing on the TV screen when a NICAM broadcast is received (with "NICAM ON" set)

	TV screen
NICAM Stereo or Mono Programme received	NICAM
NICAM Bilingual sound programme received (Not yet used in the U.K.)	NICAM I/II
No NICAM programme received Standard mono	Not indicated

### Monitoring Sound Output

When monitoring a TV programme or playing back a Hi-Fi recorded video tape, press the **A. SELECT** button to select a desired sound output.

Sound type	Stereo sound	Bilingual sound	Standard sound broadcast
VTR display			
	Heard in stereo. (left channel and right channel)	Channel I (MAIN) heard from the left speaker, Channel II (SUB) from the right speaker.	Heard in monaural.
	Left channel heard from both the left and right speakers.	Channel I (MAIN) heard from both the left and right speakers.	Heard in monaural.
	Right channel heard from both the left and right speakers.	Channel II (SUB) heard from both the left and right speakers.	Heard in monaural.
	Both  and  go off.	Channel I (MAIN) heard from both the left and right speakers.	Heard in monaural.
	Sound mixed the left and right channel, and the normal audio track.		

### Sounds of a recorded TV programme

This VTR is capable of recording sound in Hi-Fi system. Stereo broadcasts and bilingual sound broadcasts are recorded in its original sound system regardless of the setting. (See the list above.)

### Notes

- When listening to a stereo broadcast or playing back a tape Hi-Fi recorded in stereo, you have to connect the VTR with the stereo audio system or the stereo TV.  
The sound which is output from the AERIAL OUTPUT socket is monaural.
- If a tape which is not Hi-Fi recorded is played back, and indicators go off automatically and the sound output is monaural.



# 4

## RECORDING A TV PROGRAMME


This section explains a basic recording operation.

### Preparation


- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".



- 1 Load a cassette with the safety tab attached.




- 2 Press the TV/VIDEO button so that the "VIDEO" indicator appears in the VTR display.



- 3 Select the TV programme (position number) to record with the CH/TRK buttons, or number buttons (1 - 0) on the remote controller.

**Example :** to record a programme of a station stored in position 1.



If you find "L1", "L2" or "SA" in the position number area, press the **INPUT SELECT** button so that the position number appears instead.



- 4 Press the SP/LP button to select the recording tape speed.



SP: suitable for a general recording with better picture and sound quality.

LP: suitable for doubling recording time, but with less picture quality and sound than using SP mode.

- 5 Press the REC button on the VTR, or simultaneously press the two REC buttons on the remote controller. Recording starts.



- 6 Press the STOP button when recording is finished.

## ■ Skipping unnecessary scenes while recording

- 1) Press the **PAUSE/STILL** button while recording.  
Recording stops briefly.



- 2) Press the **PAUSE/STILL** button again to restart recording.

## ■ Changing the recording programme while recording


- 1) Press the **PAUSE/STILL** button while recording.  
Recording stops briefly.
- 2) Select another TV programme (position number) with **CH/TRK** buttons or **number buttons (1 - 0)**.
- 3) Press the **PAUSE/STILL** button again to restart recording.

### Note

The VTR automatically shifts to the stop mode if the recording pause mode continues for 10 minutes.

## Watching Another TV Programme While Recording

- 1) Follow steps 1 to 5 and record a TV programme.



- 2) Press the **TV/VIDEO** button so that the "VIDEO" indicator disappears in the VTR display.



- 3) While recording, choose another TV programme using the station selector on the TV.


### Note

To monitor the programme which is being recorded, press the **TV/VIDEO** button again so that the "VIDEO" indicator will appear in the VTR display. Select the video channel or video input mode on the TV.

## One-touch Timer Recording

While recording, you can set its end time.


- 1) Follow steps 1 to 5 and record a TV programme.



- 2) Press the **REC** button on the VTR to set the recording end time.



Each time you press the **REC** button, the recording end time in the VTR display changes in 30-minute increments up to the maximum of 4 hours later.  
(If you press the button further, the one-touch timer recording mode will be cancelled and the indicator shows "-- : --".)



At the recording end time you set, the recording stops and the VTR is turned off automatically.

### Notes

- To cancel the one-touch timer recording in progress, press the **STOP** button.
- To delay the recording end time, further press the **REC** button on the VTR.
- If the VTR clock is not set, the one-touch timer recording is not activated.
- If the **COUNT/TR** button is pressed in the one-touch timer recording mode, the VTR display changes as below.

→ recording → clock → linear time counter → tape remaining → end time



# 4

## RECORDING FROM A SATELLITE RECEIVER

If you are using a satellite receiver, you can connect it to this VTR to record a satellite programme.


### Preparation

- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".
- Make sure your satellite receiver is connected to the VTR correctly.



1 Turn on the connected satellite receiver.

2 Load a cassette with the safety tab attached.



3 Press the **TV/VIDEO** button so that the "VIDEO" indicator will appear in the VTR display.



4 Press the **INPUT SELECT** button so that "SA" will appear in the position number area.



Each time you press the **INPUT SELECT** button, the display changes as shown below.


→ TV (Position number) → L 1 → L 2 → SA (satellite)

5 Choose the satellite programme you want to record using the station selector on the connected satellite receiver. Make sure that selected programme is on the TV screen.

6 Press the **SP/LP** button to select the recording tape speed.



7 Press the **REC** button on the VTR, or simultaneously press the two **REC** buttons on the remote controller. Recording starts.



8 Press the **STOP** button when recording is finished.



## Satellite Monitor Function

You can watch a satellite programme from your connected satellite receiver even while the VTR is recording a TV programme, or is in the playback or stop mode.

### Preparation


Make sure that the satellite receiver, the TV and the antenna are connected properly, using the diagram "CONNECTION TO A SATELLITE RECEIVER".

### Important

This function only applies when the TV and the satellite receiver are connected to the VTR using the SCART socket.

## ■ WATCHING A SATELLITE PROGRAMME WHILE RECORDING A TV PROGRAMME

- 1) Follow steps 1 to 5 of "RECORDING A TV PROGRAMME" and record a TV programme.



- 2) Press the **SAT. MONI.** button. The "MONI" indicator appears.



Each time you press the **SAT. MONI.** button, the "MONI" indicator goes on and off.

- 3) Choose the satellite programme you want to watch on the connected satellite receiver.

## ■ WATCHING A SATELLITE PROGRAMME WHILE THE VTR IS IN THE PLAYBACK OR STOP MODE


- 1) Press the **SAT. MONI.** button so that the "MONI" indicator will appear in the VTR display.
- 2) Press the **TV/VIDEO** button so that the "VIDEO" indicator will appear in the VTR display.
- 3) Choose the satellite programme you want to watch on the connected satellite receiver.

### Notes


- When OSP mode (ex. the MENU screen is displayed) is set, the satellite monitor function is cancelled.
- The satellite monitor function is also available in the timer programme recording mode, the timer standby mode, or the one-touch timer recording mode.

## ■ WATCHING A TV PROGRAMME WHILE RECORDING A SATELLITE PROGRAMME

- 1) Follow steps 1 to 7 of "RECORDING FROM A SATELLITE RECEIVER" and record a satellite programme.



- 2) Press the **TV/VIDEO** button so that the "VIDEO" indicator disappears in the VTR display.



- 3) Choose a TV programme you want to watch on your TV handset while recording a satellite programme.

## Video Plus+

This VTR is equipped with the Video Plus+ programming system. This system allows you to set up easily for unattended recording.

## Information

Before making a Video Plus+ recording, it is necessary to set GUIDE channels to the VTR, except for normal TV stations – no need to do anything.


## Preparation

- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".
- Turn on the VTR.

### Note

The recording systems below are also available on this VTR other than the Video Plus+ recording.

- One-touch timer recording
- Timer programme recording




## GUIDE Channel Setting


### Important

Make sure that the TV stations have been tuned to the position numbers (1 for BBC1, 2 for BBC2, 3 for ITV and 4 for CHANNEL 4) on the VTR.


- 1** Press the **OSP** button.



- 2** Press number button 4.



- 3** Press **number button 2**.  
The GUIDE CH P. screen appears.



**Fixed GUIDE channels  
for TV stations**  
1: BBC1 2: BBC2  
3: ITV 4: CHANNEL 4  
No need to change.

Position numbers factory  
set for the TV stations.  
No need to change.


It is not necessary to set the GUIDE channels for BBC1, BBC2, ITV and CHANNEL 4, since they have already set as shown in step 3.

If you want to use Video Plus+ recording for programmes of other stations, e.g. satellite, proceed to step 4 on next page.

If not, press the **OSP** button to complete the setting.

- 4 Press the **SHIFT** button to select the "GUIDE" channel for a desired satellite station.

**Example :** to set a GUIDE channel 101 for SKY ONE



- 5 Set the "CH P." column. Use the procedure **A)** or **B)** according to whether the "Satellite Receiver Control" function is available on your satellite receiver or not.

When **available** – your satellite receiver has its brand in the list and can use the satellite receiver control function, use **A)**.


When **not available** – your satellite receiver does not have its brand in the list use **B)**.

- A) Using this setting, the VTR can make a Video Plus+ recording of satellite programmes whilst you are absent, selecting automatically satellite channels as you have set.**


**Important**

To use this function, make the procedures for the "SATELLITE RECEIVER CONTROL".

- 1) Press the **SAT. CONT.** button.  
[SA] appears in the "CH P." column.




- 2) Enter a channel of the satellite station using **number buttons**.  
If SKY ONE is channel 15 . . .





Proceed to step 6.

- B) The VTR cannot select automatically satellite channels in the Video Plus+ recording mode. It is necessary to select a desired satellite channels using the station selector on your satellite receiver when you make a Video Plus+ recording.**

Set the "CH P." column using the **INPUT SELECT** button according to the connection of your satellite receiver and the VTR.



If your satellite receiver is connected via . . .



- 6 To set GUIDE channels for other satellite stations, follow steps 4 and 5.

- 7 Press the **OSP** button three times, to return to normal TV screen.  
GUIDE channel setting is all completed.

Your Video Plus+ programming is now ready to use.

# 4

## Video Plus+


After having setting GUIDE channels, you can perform Video Plus+ recording using the PlusCodes.

### Information

You can perform timer recording very easily using the Video Plus+ programming system of this VTR. You simply enter the PlusCodes carried in the daily newspapers or TV magazines.

### Preparation

- Make sure that the clock is set correctly.
- If you record from a satellite receiver, make sure that the connection is made correctly.
- Set the VTR/TV selector to "VTR".



### Setting Time Extension

Before making a Video Plus+ recording, set possible time extension for the recording to allow for a programme overrunning. You can extend the recording time in 10 minute increments up to 60 minutes.


- 1) Press the **OSP** button.  
The MENU screen appears on the TV.



- 2) Press **number button 2** to select "VTR SETUP".



- 3) Press **number button 5** repeatedly to set desired time extension.



OFF ← 60 ← 50 ← 40 ← 30 ← 20 ← 10 ←


### Notes

- Extend time should be set before starting Video Plus+ recording procedure. The time extending doesn't work on recording programmes already memorized.
- When you do not use time extension for Video Plus+ recording, set to "OFF" on the SETUP screen.

### Video Plus+ Recording Procedure

- 1 Load a cassette with the safety tab attached.
- 2 Press the **VIDEO PLUS+** button.  
The VTR enters the Video Plus+ mode.

VIDEO PLUS+




- 3 Enter the PlusCode.

**Example** : to record a TV programme beginning at 20:30 on 8, October, 1994 with PlusCode 74427 (fiction).

Press **number button 7, 4, 4, 2 and 7**.


Confirm that the entered number is correct.



### Correcting a mistake


- Press the **CANCEL** button. The current PlusCode is cleared.
- Re-enter a correct PlusCode.

- 4** Press the **VIDEO PLUS+** button.  
The TV screen changes as follows:  
(Some TV programmes may not require the selection on the screen below, and skip automatically to step 6 when its PlusCode is entered.)



**ONCE:** one-time recording.  
**DAILY(MO-FR):** records TV programmes on the same TV station at the same time Monday through Friday.  
**WEEKLY:** records TV programmes on the same TV station at the same time on the same day every week.

- 5** To select "ONCE" for example, press **number button 1**.  
The "ONCE" programming has been made automatically.  
Programme details are shown.



**Note:** When you set 10 minutes time extension on the SETUP screen, the "OFF" displays 21:40.


- 6** To change the tape speed, press the **SP/LP** button.




- 7** Press the **VIDEO PLUS+** button.  
Programme setting is now memorized.




- 8** To enter other PlusCodes, follow steps 2 to 7.


- 9** Finally press the two **TIMER** buttons simultaneously.  
The VTR enters the timer standby mode and  indicator lights up.



### **Recording or Playback in the Timer Standby Mode**

When you want to use the VTR while it is set to the timer standby mode, proceed as follows:

- 1) Press the **TIMER** buttons simultaneously.  
 indicator goes off.




- 2) Press the **ON/STANDBY** button to turn on the VTR and operate the VTR as usual.  
3) After operating the VTR, press the **TIMER** buttons.  
The VTR returns to the timer standby mode.

Finish normal use of the VTR before the preset recording start time, since the timer only works when the VTR is in the timer standby mode.


**Confirming the Video Plus+ Timer Programmes**

- To confirm the Video Plus+ recording programme before the VTR enters the timer standby mode (⊕ indicator not lit)

- 1) Press the **OSP** button.




- 2) Press **number button 3**.



Check your programme data.

- 3) Press the **OSP** button twice.  
The TV screen returns to the normal screen.


- To confirm during the timer programme recording (⊕ indicator lit)  
Press the **OSP** button so that the screen for confirming appears. After about 30 seconds, the screen disappears.

**Cancelling the Video Plus+ Timer Programmes****Preparation**

If the VTR is set to the timer standby mode, (⊕ indicator lit), press the **TIMER** buttons to release it and press the **ON/STANDBY** button.

- 1) Press the **OSP** button to display the MENU screen.  
2) Press **number button 3**.

3



- 3) Select a programme number which you want to cancel by using number buttons.

1 . . . 6

- 4) Press the **CANCEL** button.  
The selected programme data is cancelled.



- 5) Press the **OSP** button.  
6) If necessary, i.e. you still have a programme to record, press the **TIMER** buttons to return to the timer standby mode.

**Changing the Video Plus+ Timer Programmes****Preparation**

First cancel the timer programme. (See "Cancelling the Video Plus+ Timer Programmes".)

- 1) Press the **VIDEO PLUS+** button so that the **PLUSCODE** screen appears.  
Enter a new code.  
2) Press the two **TIMER** buttons simultaneously to enter the timer standby mode.

## ■ AUTO SPEED ADJUST


If you are not sure if the tape is long enough for timer programme recording in the SP mode, set the recording tape speed to "AUTO".

Recording starts in the SP mode and the VTR automatically selects the tape speed to record the programme to the end. If the tape length is not long enough, the tape speed automatically changes from the SP mode to the LP mode.

### Notes

- Make sure that the tape length is selected correctly according to the tape used on the SETUP screen.

- 1) Press the **OSP** button.  
The MENU screen will appear on the TV.
- 2) Press **number button 2**.  
The SETUP screen will appear on the TV.
- 3) Press **number button 1** to select a tape length.



E180: when using an E-195 tape or shorter.

E240: when using an E-210 or E-240 tape.

E260: when using an E-260 tape.


E300: when using an E-300 tape.

- When the LP mode is selected and the tape length is not sufficient to record the programme to the end, the programme cannot be completely recorded.
- The picture will be distorted when playing the part where the recording mode was switched from the SP mode to the LP mode with the AUTO SPEED ADJUST method.

## Overlaps the programme

If two programmes overlap, the recording start time of programme 2 has a priority over the recording end time of programme 1.

**Example:** when programme 2 overlaps programme 1



## Error indicators

When the "FULL (CLEAR PROG?)" message appears on the TV during programming, no more programmes can be entered. If you want to add another programme, delete one existing programme on the screen by using number button.

If impossible PlusCode is entered, "INVALID CODE ENTERED" blinks on the screen to tell you that the recording cannot be performed. Press the CANCEL button to clear the PlusCode number and enter correct one.

If "CLASH" message appears on the screen during programming, it tells you that two programmes with the same recording start time have been entered. You have to make a correction. On this screen, blinking item number means that the item has been entered later.

- 1) Enter the number of the programme you want to correct using **number buttons**.
- 2) Correct the timer programme data, or clear the data by pressing the **CANCEL** button and then press the **VIDEO PLUS+** button to enter the PlusCode.

# 4

## TIMER PROGRAMME RECORDING


The programmable timer allows you to record up to 6 different programmes over one month. This function is convenient when you are away from home or when you are busy.

### Information

The item to be set blinks. Set the data with the number buttons, following the blinking position. You can change the blinking position by pressing the SHIFT (→/←) buttons.

### Preparation

- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Make sure that the clock is set correctly.
- Set the TV/VTR selector to "VTR".




**Example** to record a programme of a station stored on position number 1 (e.g. BBC1) in the SP mode from 20:30 until 21:30 on October 8. Today is October 5.


- 1 Load a cassette with the safety tab attached.




- 2 Press the **OSP** button.





- 3 Press **number button 3**.



- 4 Select programme number 1.




- 5 Select position number 1.  
Press **number button 0 and 1**.



You can make a timer programme recording of a source programme from other equipment connected to this VTR using the **INPUT SELECT** button.

- L1 : to record from other equipment connected to the AUDIO/VIDEO (SCART) socket on the rear panel of this VTR.
- L2 : to record from other equipment connected to the LINE IN 2 jacks on the front panel of this VTR.
- SA : to record from the satellite receiver connected to the SATELLITE (SCART) socket on the rear panel of this VTR.

If you press the **SAT. CONT.** button, the VTR enters the satellite receiver control mode and **[SA]** is displayed. Enter a desired satellite station.





### Correcting a mistake

Press the SHIFT (←) button to reverse the blinking position until the number you set incorrectly blinks. Correct the number with the number buttons and press the SHIFT (→) button to return the blinking digit.

- 6** Select a one-time recording.  
You can also set daily and weekly timer recordings.

①

15:30	5.10.94	WE
CH DATE	ON	OFF SPD
1 OK 05	---	---

END=OSP

- 7** Set the recording date.

① → ⑧

15:30	5.10.94	WE
CH DATE	ON	OFF SPD
1 OK 8	---	---

END=OSP

- 8** Set the hours and minutes of the recording start time.

② → ③ → ① → ③

15:30	5.10.94	WE
CH DATE	ON	OFF SPD
1 OK 8 20:30	---	---

END=OSP

- 9** Set the hours and minutes of recording end time.

② → ① → ③ → ①

15:30	5.10.94	WE
CH DATE	ON	OFF SPD
1 OK 8 20:30-21:30	---	---

SP=1 LP=2 AUTO=3  
END=OSP

- 10** Select the tape speed (SP).

①

15:30	5.10.94	WE
CH DATE	ON	OFF SPD
1 OK 8 20:30-21:30	---	---

SELECT=1-8  
END=OSP

- 1=SP: Select for a recording with better picture and sound.  
2=LP: Select for doubling recording time, but with less quality of picture and sound than using the SP mode.  
3=AUTO: Select when you use the AUTO SPEED ADJUST function.


To set another programme, follow steps 4 to 11. (For this example, since programme number 1 is already used, set another programme using programme numbers 2, 3 . . 6 in step 4.)

- 11** Press the **OSP** button.  
Programme setting is complete.

OSP

MENU	
1	CLOCK SET
2	VTR SETUP
3	PROGRAM
4	CH PRESET
SELECT=1-4	
END=OSP	

- 12** Press the two **TIMER** buttons simultaneously.



The power will be turned off and the VTR enters the timer standby mode.

15:30
-------

# 4

## TIMER PROGRAMME RECORDING

### Daily and Weekly Recording

#### ■ Daily timer programme recording

You can record TV programmes on the same TV station at the same hour Monday through Friday.

- 1) In step 6 press **number button 2** to select "DAILY".

2

15:30	5.10.94	WE
CH	DATE	ON OFF SPD
1	MO-FR	-----SP
1	2	3
4	5	6
7	8	9
0		

END=OSP

- 2) Skip step 7.

- 3) Perform steps 8 to 12.

#### ■ Weekly timer programme recording

You can record TV programmes on the same TV station on the same day every week.

- 1) In step 6 press **number button 3** to select "WEEKLY".

3

15:30	5.10.94	WE
CH	DATE	ON OFF SPD
1	WE	-----SP
SU=1	MO=2	TU=3
WE=4	TH=5	FR=6
SA=7		

END=OSP

- 2) Press **number button 1 to 7** to select the day of the week.

For example, if you press **number button 2** to select "MO", you can record the programme on the same TV station on the same time every Monday.

2

15:30	5.10.94	WE
CH	DATE	ON OFF SPD
1	WE	-----SP
1	2	3
4	5	6
7	8	9
0		

END=OSP

- 3) Skip step 7.

- 4) Perform steps 8 to 12.

### Confirming the Timer Programmes

#### To confirm during the timer programme recording (⊕ indicator lit)

Press the **OSP** button so that the screen for confirming appears. After about 30 seconds, the screen disappears.

OSP

15:30	5.10.94	WE
CH	DATE	ON OFF SPD
1	WE	20:30-21:30 SP
1	2	3
4	5	6
7	8	9
0		

END=OSP

### Changing the Timer Programme

#### Preparation

If the VTR is set to the timer standby mode (⊕ indicator lit), press the **TIMER** buttons to release it and press the **ON/STANDBY** button.

- 1) Perform step 2 to 12 of the timer programme setting procedure to correct timer programme data.

- In step 4, select a programme number which you want to correct.


- 2) Press the **TIMER** buttons simultaneously to return the VTR to the timer standby mode.

## Cancelling the Timer Programmes


### Preparation

If the VTR is set to the timer standby mode (⏻ indicator lit), press the **TIMER** buttons to release it and press the **ON/STANDBY** button.

- 1) Press the **OSP** button to display the MENU screen.
- 2) Press number button 3.



- 3) Select a programme number which you want to cancel by using number buttons.



- 4) Press the **CANCEL** button.  
The selected programme data is cancelled.




- 5) Press the **OSP** button.
- 6) If necessary, press the **TIMER** buttons to return to the timer standby mode.

## Recording or Playback in the Timer Standby Mode

When you want to use the VTR while it is set to the timer standby mode, proceed as follows:

- 1) Press the **TIMER** buttons simultaneously.  
⏻ indicator goes off.



- 2) Press the **ON/STANDBY** button to turn on the VTR and operate the VTR as usual.
- 3) After operating the VTR, press the **TIMER** buttons.  
The VTR returns to the timer standby mode.

Finish normal use of the VTR before the preset recording start time, since the timer only works when the VTR is in the timer standby mode.

## Additional Information

### Error indicator

The "E" (error) indicator appears in the VTR display if you press the **TIMER** buttons when:

- a cassette is not loaded.
- a cassette without a safety tab is loaded.
- a cassette with a safety tab is loaded and no timer programmes are set on the VTR.

In these cases, a recording will not be made.


### If a power failure occurs during timer programme recording

- After a power failure of short duration, the colon between the hour and minute digits blinks in the VTR display. This indicates that the timer programmes are still in the memory of the VTR.
- After a power failure of long duration, "0:00" blinks in the VTR display. This indicates that the timer programmes have been cleared. Reset the clock and timer programmes on the VTR.

### Overlap of the programmes

If two timer programmes overlap, the recording start time of programme 2 has priority over the recording end time of programme 1.

**Example :** when programme 2 overlaps programme 1



# 4

## SATELLITE RECEIVER CONTROL

The VTR can directly control station selecting of the connected satellite receiver.


### Information

The following settings are required to control your satellite receiver by this VTR.

- 1) Placing the Satellite Receiver
- 2) Setting the Satellite Receiver Brand Code
- 3) Setting the Satellite Receiver Control


### Important

- First perform "Placing the Satellite Receiver".
- Keep the connected satellite receiver turned on.
- Set the VTR/TV selector to "VTR".




### Setting the Satellite Receiver Brand Code


- 1 Press the **OSP** button.



- 2 Press **number button 4**.




- 3 Press **number button 5**.



- 4 Press **number buttons** to enter three figures of the brand code for your satellite receiver.

**Example:** to enter brand code 2.



When you enter the brand code, the VTR sends a test signal to the satellite receiver to make sure that the brand code has been entered correctly. The signal will set the satellite channel to 12. Accordingly, if channel 12 is displayed on your satellite receiver, it means the brand code is set correctly.

Several codes may be allocated to one brand. Enter one after the other so that the channel shows 12.

- 5 After having confirmed that the channel of the satellite receiver is 12, press the **OSP** button three times to return the normal TV screen.

**Table of Satellite Brand Code**

Brand name	Brand code
TOSHIBA	33
ALBA	1, 2, 9, 16, 65, 66
ALDES	88
ALLSAT	9, 16, 23
AMSTRAD	3, 4, 5, 55, 56, 76, 77, 89, 90, 91
ARMSTRONG	43
BEST/DISKEXPRESS	26
BIG BROTHER	7, 8
BUSH	2, 9, 16, 65, 66
CABLE STAR	101, 102, 103, 104
CABLETIME	101, 102, 103, 104
CHANNEL MASTER	2, 3, 10
D2MAC DECODER	72
DECSAT/C+ SAT.	72
DRAKE	45
ECHOSTAR	13, 14, 92, 93, 94
FERGUSON	9, 15, 16, 17, 23, 38, 39, 59, 108
FUBA	49, 69, 70, 78, 96
GI	105, 106, 107, 108, 110
GRUNDIG	17, 19, 28, 71
HIRSCHMANN	11, 19, 47, 48
HUTH	74
IMPULSE	105, 106, 107, 108, 110
ITT/NOKIA	17, 26, 27, 50, 51, 52
JERROLD	105, 106, 107, 108, 110
KATHREIN	12, 16, 20, 24, 29, 31, 46, 73, 97
LENCO	49
MACOM	111
MASPRO	17, 20, 64, 67
MIMTEC	21
MORGAN	43

Brand name	Brand code
NAGAI PALSAT	95, 96
NEC	22, 57
NETWORK	9, 16
NORDMENDE	17
OAK	112, 113, 114, 115
PACE	9, 16, 17, 23, 38
PANASONIC	17, 61
PHILIPS	16, 24, 46, 73
REDIFFUSION	25
REVOX	21
SAKURA	62, 63, 68
SALORA	17, 26, 27, 50, 51, 52
SAMSUNG	36
SCHWAIGER	23, 43
SCIENTIFIC ATLANTA	116, 117, 118
SEEMANNS	23
SENTRA	10
SONY	30
STRONG	31
TATUNG/NIKKO	32, 54, 58, 80, 81
TECHNISAT	40, 41, 92, 93
TELEDIREKT	23
TEXSCAN	119, 120
THOMSON	7, 17, 39
TRISTAR	31
UNIDEN	67
VIDEOTRON	105, 106, 107, 108, 109, 110, 121
VIDEOWAY	105, 106, 107, 108, 109, 110, 121
VISIOPASS	16, 24, 46, 73
VORTEC	36
WISI	35, 37, 44, 93

- For some brands, several brand codes are allocated.
- Some satellite receivers may not be operated at all with this VTR.

# 4



## SATELLITE RECEIVER CONTROL

### Information

You can select satellite stations by operating this VTR. It is also possible to change automatically satellite stations according to your programme setting in the timer programme recording mode. See "TIMER PROGRAMME RECORDING".


### Important

- Perform "Setting the Satellite Receiver Brand Code" beforehand.
- Keep the connected satellite receiver turned on.



### Placing the Satellite Receiver

Put the satellite receiver on the top of the VTR as shown below.  
Do not block the sensor window.




The infrared signals come out of the sensor window and the front of the VTR, and they bounce off walls and objects in the room and are received by the satellite receiver. The VTR sends out infrared control signals to your satellite receiver even during timer programme recording.

### Note


If the satellite receiver cannot be controlled properly because the infrared signals fail to reach it, change the position on the VTR so that it can receive the signals enough.

### Setting the Satellite Receiver Control


- 1 Press the **OSP** button.



- 2 Press number button **4**.




- 3 Press number button **4**.




- 4** Set the position number or line input mode depending on your satellite receiver connection.  
If your satellite receiver is connected via . . .

**the SATELLITE (SCART) socket on the VTR,**  
press the **INPUT SELECT** button to select "SAT".



**the AERIAL INPUT socket,**  
press the **INPUT SELECT** button, and then set the position number on which you stored the satellite output (e.g. 10) by using the **CH/TRK** or **number buttons**.



- 5** Press the **OSP** button three times to return to the normal TV screen.  
The satellite receiver control function is ready to use.

## Using the Satellite Receiver Control

### ■ SELECTING SATELLITE CHANNELS WITH THE REMOTE CONTROLLER OF THE VTR

- 1) Press the **SAT. CONT.** button to make "SAT", "SA" appear in the VTR display.



- 2) Select a desired satellite channel using **number buttons**.

Ways of use may differ. Check how they work on your satellite receiver.

Ex. to select satellite channel 3.

- Press **number button 0** and **3**.
- Press **number button 0, 3** and the **ENTER** button.
- Press the **ENTER** button and **number button 3**.

Ex. to select satellite channel 16.

- Press **number button 1** and **6**.
- Press **number button 1, 6** and the **ENTER** button.
- Press the **ENTER** button twice and **number button 1, 6**.

### Important

Some satellite receivers may not respond to all of the operations above, or may not be operated at all with this remote controller. In such a case, operate the satellite receiver with its own remote controller.

### Notes

- Each time the **SAT. CONT.** button is pressed, this function goes on or off.
- To make a position number appear in the VTR display after you have cancelled this function, press the **INPUT SELECT** button.

### ■ CHANGING SATELLITE CHANNELS AUTOMATICALLY IN THE TIMER PROGRAMME RECORDING MODE

See "TIMER PROGRAMME RECORDING".

### Note

Keep the satellite receiver turned on even while the VTR is in the timer programme recording mode.

# 4

## 16:9 (WIDE SCREEN) COMPATIBILITY


The VTR automatically adjusts the image to fill the wide TV screen when recording or playing back a wide TV programme via the connected satellite receiver, etc.

### Information


When you play back a tape commercially available which is recorded in the wide screen format, or when you record or play back a wide TV programme via the connected satellite receiver, etc., the VTR automatically adjusts the image to fill the wide TV screen.

### Important

Connect equipment compatible with wide screen, to the VTR using the SCART cable.



### Wide TV and normal TV on this function



### Setting of 16:9 Wide Screen

Make the setting when you record or play back a wide TV programme.

- 1 Press the **OSP** button.  
The MENU screen will appear on the TV.
- 2 Press number button **2** to select "VTR SETUP".
- 3 Press number button **4** to set "16:9".

4

SETUP	
1 TAPE SELECT	(E180)
2 NTSC ON PAL TV	(ON)
3 COLOUR	(ON)
4 16:9	(OFF)
5 VIDEO PLUS+ EXTEND	(OFF)
6 NICAM	(ON)
SET=1-5      END=OSP	

OFF: Set if you do not use a wide TV.  
 AUTO: Set when you use a wide TV. The VTR automatically detects wide TV programmes and normal TV programmes.  
 ON: The VTR is set usually in the mode compatible with 16:9 wide screen. Set if the VTR cannot detect wide TV programmes with "AUTO" set.

- 4 Press the **OSP** button twice to return to the normal TV screen.




# 4

## AUDIO DUBBING

This function allows you to record sounds onto the normal audio track of a pre-recorded tape, without erasing the pictures or sounds on the Hi-Fi stereo track.


### Information

Audio dubbing can be made by importing sounds from a microphone or an external equipment connected to the LINE IN 2 jacks.



### Example

Your narration can be recorded on a tape which has been recorded on a camcorder.




### Preparation for Audio Dubbing Using a Microphone

Insert the microphone plug into the MIC jack on this VTR.

- Pull out the microphone after using.

### Preparation for Audio Dubbing Using an External Equipment

- 1) Connect an external equipment to the **LINE IN 2 (AUDIO)** jacks on the VTR.
- 2) Press the **INPUT SELECT** button several times to make "L2" appear in the VTR display.



- Be sure to pull out the microphone plug from the jack.

### Audio Dubbing Procedure

- 1 Load a cassette you want to make audio dubbing on.


- 2 Press the **PLAY** button to start playback.



- 3 Press the **PAUSE/STILL** button where you want to start audio dubbing.



- 4 Press the **A. DUB** button.



Some flickers may be produced on the screen. This is not a malfunction.

- 5 Press the **PAUSE/STILL** button to start audio dubbing. Speak into the microphone or play a sound of the external equipment.

# Instructions for Installing the Optical Infrared Transmitter

The satellite receiver can be controlled through the use of the Optical Infrared Transmitter (Part number: 70148859).


## ■ Installation and Position Setting

When setting up the brand of the satellite receiver, place the transmitter in such a position that the channel display of the satellite receiver will be changed to 12.


- Select a position where the transmitter is near the remote control sensor of the piece of that needs to be controlled.
- Be careful that the transmitter and its cord do not touch any doors when they are opened and closed.

## AD Fixing Method

1. Stick one face of the double-sided adhesive tape on the bottom of the transmitter.
2. After checking the proper operation of the satellite receiver, peel the cover off the adhesive tape attached to the transmitter and place the transmitter in position.





## Example of Installation



If a rack or TV table are not available or if there is not enough space for installation, use the supplied spacer for installing the transmitter.

## Example of Installation




## Notes:


- Set the transmitter installation position so that the distance from the remote control sensor falls within 50 cm. (21 inches)
- Make sure that the remote control sensor of the satellite receiver operates properly if the transmitter is moved slightly.

# SECTION 2 ADJUSTMENT PROCEDURES

## 1. MECHANICAL ADJUSTMENT








### 1-1. Mechanical Parts Location





Bottom View

## 1-2. Servicing Jig List

<p>Alignment tape</p>  <p>70909409 (ST-C6) 70909410 (ST-C7)</p>	<p>Back tension cassette gauge</p>  <p>70909103</p>	<p>Torque cassette gauge (KT-300NR)</p>  <p>70909199</p>
<p>Taper nut driver</p>  <p>70909228</p>	<p>VTR cleaning kit</p> 	<p>VTR lubrication kit</p> 
<p>Grease</p> 		

**Note:** Conventional alignment tapes ST-C1 (70909227) and ST-C3 (70909264) can be used partially.

### 1-3. Main Parts Servicing Time

- Part replacement time differs from servicing life time of each part.
- Following table is prepared based on a standard condition (room temperature, room humidity). The replacement time will be varied depending upon operation environment, using methods, operation duty, etc.
- Particularly, life of the upper cylinder depends upon operation conditions.

	Part Name	Service time (Operating Hours)										Note
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
Tape Transport System	Tension post											• When cleaning, use a swab or piece of gauze soaked in alcohol.
	S/T slant guide post											
	Impedance roller *											
	No. 8 guide post	△	△	△	△	△	△	△	△	△	△	• After cleaning, cleaned parts are dried completely, and then load a video cassette.
	Capstan											
	No. 9 guide post											
	No. 3 guide post											• When lubricating, always use the specified oil.
	S/T guide roller	△	△	△	○	○	○	○	○	○	○	
	Upper cylinder	△	○	○	○	○	○	○	○	○	○	
	Slip ring assembly		○	○	○	○	○	○	○	○	○	• When the lubricating, apply one or two drops of oil after the cleaning with alcohol.
	FE head	△	△	△	○	○	○	○	○	○	○	
	ACE head	△	○	○	○	○	○	○	○	○	○	
Tape Drive System	Pinch roller	△	○	○	○	○	○	○	○	○	○	• Check the back tension.
	Capstan motor	△	△	△	△	△	○	○	○	○	○	
	Loading motor				○	○	○	○	○	○	○	
	Loading belt/ Reel belt	△	○	○	○	○	○	○	○	○	○	
	S reel table assembly		○	○	○	○	○	○	○	○	○	
	T reel table assembly		○	○	○	○	○	○	○	○	○	
Other	Idle gear assembly	△	○	○	○	○	○	○	○	○	○	
	Band brake assembly		○		○		○		○		○	

△ : Cleaning    ○ : Check and replace if necessary

\* There are two types. One type has an impedance roller and another type has no impedance roller.

## 1-4. V3 Mechanism Check Method

If the abnormal condition is caused by the mechanism itself, analyze the cause according to the following procedures.

### 1-4-1. External Appearance Check

- (1) Check whether there are foreign matters or not inside the VTR.
- (2) Check whether the cylinder and the guides for tape transport system are contaminated.

### 1-4-2. Motor Sensor System Check

Check whether some abnormalities are found in the motor or the sensor system (including control circuits) according to the flow chart.





Fig. 4-1-1



### 1-4-3. Abnormality Analysis by Self-check

#### Function

The unit used V3 mechanism has a self-check function. The self-check function works as a system which stored some abnormal condition. So, use this function to try to analyze the cause(s).

For the data display method and the content of the data, refer to the self-check function (described on page 2-48) in item 2-2.

#### Note:

- Abnormal data is displayed only when the first abnormal condition occurs, and is not displayed in the second time. Accordingly, the claim from customers and the actual data displayed may be different.
- The data is stored only when the power turns off after occurring the abnormality condition(s). The data is not stored when the unit operation is recovered by the microcomputer.
- After repairing, initialize the data by pressing the [COUNTER RESET] button while displaying the abnormal mode.

The typical examples in abnormal condition are shown below.

Table 4-3-1

A	B	C	Abnormal Condition	Check Item
06	01	09	Cylinder is stopped at playback position during playback the tape.	} Check the cylinder motor. Check if the cylinder and tape transport guide are clogged.
02	01	0d	Cylinder is stopped at FF/REW position during rewind the tape.	
06	02	09	T reel sensor is abnormal at playback position during playback the tape.	} Check the capstan motor. Refer to the cases 2 and 3 describe on the table "Defective analyzing list".
03	03	07	S reel sensor is abnormal at playback position during REVIEW the tape.	
01	04	02	Cassette-in and out operation cannot be performed.	} Refer to the case 1 described on the table "Defective analyzing list".
03	05	08	Mode shift cannot be performed during shifting to REVIEW.	

A: System control mode, B: Abnormality No., C: Mechanical position when an abnormality occurs.

### 1-4-4. Check by Defective Analyzing List

If the abnormality causes the mechanism abnormal condition, presume, confirm and treat the defective according to the "Defective analyzing list" in table 4-4-1.

#### (1) Manual mechanism operation (mode shift) method

Push in the lock lever R and L manually and turn the worm wheel counterclockwise as shown in Fig. 4-1-1. The cam gear is turned clockwise and the mode shifts to the direction where the loading operation can be performed. So, check the mechanism condition in the defective mechanism position when the abnormality occurs.

#### (2) Defective parts replacement

When a defective occurs due to the defective part(s) and the part(s) is replaced, take care the following items.

- Especially as for the mechanical parts requiring the phase alignment, take care of the part replacement E.g., Assembling mode, phase alignment mark and etc.

- As for the part(s) requiring lubricant such as a specified amount of oil or grease, apply grease or oil according to the instructions and do not stick grease or oil to the portions without allowing to stick it (especially in removal and assembly).

#### (3) Check after treating the defective

After replacing a defective part and/or aligning a part, first check the mechanism operation manually and confirm that no problem occurs, and then mount the mechanical deck, turn the power ON and check the mechanism operation.

#### Note:

- After replacing the defective parts according to the procedure of the treatment method for the "damage and phase shift of mechanical part", check the operation of the mechanism again, since the same (or similar) defective problem may occur due to other serious cause (in mechanism or electrical circuit) when performing the actual total check with turning the power on.

**Table 4-4-1 Defective Analyzing List**

Case	Defective Phenomenon (Main Items)	Presumed Cause (Main Cause)	Check Method
1	Power does not turn on. Loading operation is defective. Mode shift operation is defective.	<General> Mechanical stops due to mechanical phase unmatching.	Check mode shift "Cassette out FF/REW position" can be performed when turning worm wheel.
	Loading operation is not performed.	Loading motor does not rotate. (Loading motor is defective or circuit is defective.)	Check loading motor whether it turns by the outer power supply (12.5V).
	Unloading operation is not performed.	S reel does not wind the tape.	Refer to case 3 in this table.
2	Playback operation is not performed. Playback operation is defective.	<General> Main brake is not released. (ON) T soft brake is not released. (ON) Idler does not swing. Pinch does not press.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
	Playback picture does not appear. Video recording can not be performed.	<In case of no mechanical problem> Cylinder is defective. (Circuit is defective.)	Check cylinder assembly.
3	Playback interruption. Defective phenomenon during playback. Recording interruption.	Reel rotation detection is defective. (Sensor is defective. Circuit is defective.)	Check sensor output.
		Idler does not swing.	Check mechanical position.
		Reel belt is removed.	Check the reel belt is removed or not.
4	FF operation is not performed. FF operation is defective. REW operation is not performed. REW operation is defective. Others: REV/FF is not performed. Others: REV/FF is defective.	Main brake is not released. (ON) T soft brake is not released. (ON) Idler does not swing. Pinch is not released.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
5	REVIEW is not performed.	Main brake is not released. (ON) T soft brake is not actuated. Idler does not turn. Pinch does not press.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
6	Slot-in is not performed. Cassette can not be inserted.	<General> When the F/L is mounted on the mechanical deck, the position is not correct.	Check mechanical position.
7	Capstan servo does not work. Capstan servo is uneven. Tape speed is fast. Tape speed is slow. Tape speed is uneven. FG pulse is not output.	Capstan motor is defective.	Check capstan motor.
		ACE head control output is defective. (Circuit is defective.)	Check ACE head. Check CTL output.
8	Audio output does not come out. Audio output is small. Audio output variation is large. Audio output is uneven. Audio distortion. Audio noise. Others: Audio is defective.	ACE head is defective.	Check ACE head. Check CTL output.
		Tape transport adjustment is not defective.	Perform tape transport adjustment again after confirming tape transport condition.
		Hi-Fi head (cylinder) is defective. (Circuit is defective.)	Check cylinder. Check whether B+14V is supplied.

Treatment: If the mechanical is found out to be defective according to the procedures described above, perform the following treatment.

- Misassembling, mechanical phase mismatch .....Repair correctly.
- Parts defect, parts damage.....Replace parts.

If the mechanical is found out not to be defective according to the procedures above, check the circuit(s).



## 1-5. Mechanical Deck Removal and Mounting

### 1-5-1. Mechanical Deck Removal

1. Remove three screws (2) mounting the top cover (1) and remove the top cover sliding backward and lifting upward.
2. Remove two screws (3) and remove the front panel (4).
3. Remove the FFC (8) connecting the main unit (5) and the KDB1 unit (6) & the Sub Main unit (7).

#### Note:

Be sure to remove the FFC (8) on the KDB1 unit (6) and the Sub Main unit (7) sides.

4. Remove three screws (10) securing the mechanical deck (9) and one screw (12) securing the terminal board (11).

5. Remove the claw securing the main unit (5).
6. Remove the mechanical deck (9) with the main unit (5) from the chassis lifting the terminal board (11) slightly and pulling the top bracket (13) upward.

#### Note:

When pulling the top bracket upward, take care not to deform the reinforcement plate located below the F/L assembly.

7. Remove the lead wire connecting between the mechanical deck (9) and the main unit (5).
8. Turn over the mechanical deck (9).
9. Remove the reel belt (14) and one screw (15).
10. Remove four claws securing the mechanical deck (9) and the main unit (5), and then remove the main unit (5) pulling upward.




Fig. 5-1-1

### 1-5-2. Mechanical Deck Mounting

1. Turn over the mechanical deck and lower the main unit vertically adjusting the tape end sensor and etc. to the holes.

**Note:**

- Adjust the rotor of the cylinder motor and the stator of the main unit, and then lower the main unit further more till four claws catch the mechanical deck completely.
  - Take care not to damage the rotor and the stator.
  - When locking the claw of the front right side to the main unit, turn the REC inhibit lever so as not to damage the switch.
2. Mount the mechanical deck on the chassis in reverse order of removal.

**Note:**

When mounting the front panel, mount it with its door fully open.

### 1-5-3. Confirmation of Each Operation Mode without Cassette

1. Shut out the light to the start/end sensor.
2. Release the both sides of the lock lever and make a slot-in condition.
3. Turn the reel table manually located on the opposite side of the rotating reel table.
4. In this condition, confirmation of each operation mode can be performed.

**Note:**

When turning the opposite side reel table of the rotating reel table manually in playback, FF/REW mode, and sending no reel pulse, the auto eject or power off function is performed.

## 1-6. Main Parts Replacement

### 1-6-1. Top Bracket Replacement

1. Remove two securing screws (2) on the top bracket (1).
2. Remove the top bracket (1) lifting in the direction shown by the arrow.




Fig. 6-1-1

3. When mounting the top bracket (1), move the tip of the grip lever (3) on the cassette holder assembly to the inclined portion of a trapezoidal cam, and then mount the top bracket (1).




Fig. 6-1-2

#### Note:

- After remounting the top bracket (1), move the cassette holder forward and backward, and then confirm the claws of the lock lever (5) catch completely the both left and right sides of the stopper section (4) at the top bracket (1).




Fig. 6-1-3

### 1-6-2. Cassette Holder Assembly Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. The cassette holder assembly (1) is guided along the guide grooves (2) with both left and right bosses of the cassette holder assembly (1). So first remove each side boss (3) on both left and right sides of cassette holder assembly (1) from the guide groove (2).
3. When the cassette holder assembly (1) is set at the EJECT position, the boss is located at (a), so move the boss from (a) to (b) and remove the bosses on both left and right sides simultaneously.







Fig. 6-2-1

**Note:**

The grip lever (4) on the cassette holder assembly (1) may catch the trapezoidal cam on the mechanical deck (2), so perform the work lifting the grip lever in the direction shown by the arrow.

**Fig. 6-2-2**


4. After removing the front side bosses (5) on both left and right sides, remove the cassette holder assembly (1) pulling to the front side.
5. When mounting the cassette holder assembly (1), insert the front side bosses (5) to the U shaped groove of the drive arm (6) and the guide groove (2) on the mechanical deck lifting the rear side of the cassette holder assembly (1).

**Fig. 6-2-3**


6. When mounting the rear side bosses (3), perform the reverse order of removal.

**1-6-3. Door Open Lever Replacement**

1. Release the lock lever (2) on the cassette holder assembly (1) pressing in the direction shown by the arrow.

**Fig. 6-3-1**

2. Move the cassette holder assembly (1) slightly to the rear side.
3. Remove the claws (A) and (B) on the door open lever (3) from the mechanical deck (4).
4. Match the boss on a new door open lever (3) and the hole (C) on the mechanical deck, and then insert the claws (B) first and then (A) to the mechanical deck (4).

**Fig. 6-3-2**

5. Remount the cassette holder assembly to the position as it was.

#### 1-6-4. Drive Lever Gear Replacement

1. Make the cassette holder assembly to the slot-out (EJECT) position.

##### Note:

- In this condition, both mark holes on the F/L drive slider (1) and the mechanical deck fit with each other, also the hole of the boss on the drive lever gear (2), the center of the gear tooth and the marking line are in line.
2. Move the claw of the drive arm (3) to the direction of the arrow (A) and remove the drive lever gear (2) upward.




Fig. 6-4-1

3. When remounting the drive lever gear (2), take care of the phase position (refer to the note described above.) and mount in the reverse order of removal.

#### 1-6-5. Drive Arm Assembly Replacement

1. Remove the top bracket assembly. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the door open lever. (Refer to item "1-6-3. Door Open Lever Replacement".)
4. Remove the drive lever gear. (Refer to item "1-6-4. Drive Lever Gear Replacement".)
5. Pull the REC-inhibiting lever slightly to the front side, turn the drive arm assembly (1) to the front side and push it in the direction shown by the arrow. Remove the left side boss (2) on the drive arm assembly (1) from the cutout of the guide groove on the mechanical deck (3).
6. Remount the drive arm assembly (1) in the reverse order of removal.




Fig. 6-5-1

### 1-6-6. Cam Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
4. Remove the loading drive assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
5. Remove the drive lever. (Refer to item "1-6-40. Drive Lever Replacement".)
6. Remove the pinch roller assembly. (Refer to item "1-6-21. Pinch Roller Assembly Replacement".)
7. Remove the cam gear. (Refer to item "1-6-31. Cam Gear Replacement".)
8. Move the cam lever (1) until it stops in the direction shown by the arrow (A). Pull out the cam lever (1) lifting up straightly at the position where the cam lever (1) stops.
9. Apply grease to the portions of bosses (A) to (C) on a new cam lever.

#### Note:

- Confirm that the boss (A) on the cam lever (1) is inserted into the hole on the F/L drive slider (2).
  - After inserting the cam lever (1), confirm that the cam lever (1) moves smoothly.
10. Replace the cam lever in the reverse order of removal.




Fig. 6-6-1

### 1-6-7. F/L Drive Slider Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
4. Remove the loading drive assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
5. Remove the drive lever. (Refer to item "1-6-40. Drive Lever Replacement".)
6. Remove the pinch roller assembly. (Refer to item "1-6-21. Pinch Roller Assembly Replacement".)
7. Remove the cam gear. (Refer to item "1-6-31. Cam Gear Replacement".)
8. Remove the cam lever. (Refer to item "1-6-6. Cam Lever Replacement".)
9. Remove the drive lever gear. (Refer to item "1-6-4. Drive Lever Gear Replacement".)
10. Push the F/L drive slider (1) in the direction shown by the arrow (A) and slide it. Furthermore, pull out it to the front side lifting it in the direction shown by the arrow (B).
11. Apply grease to the shaded parts (a) to (d) on a new F/L drive slider (1).

#### Note:

For the phase alignment of the drive lever gear, refer to item "1-6-4. Drive Lever Gear Replacement".

12. Replace the F/L drive slider (1) in the reverse order of removal.

#### Note:

After completion of the replacement, confirm that the F/L drive slider (1) moves smoothly.




Fig. 6-7-1

### 1-6-8. Arm Brake Lever Assembly and Arm Brake Torsion Spring Replacement

1. Make the cassette holder assembly to the slot-out (EJECT) position.
2. Turn the arm brake lever assembly (1) in the direction shown by the arrow (A) until it stops. Pull out the arm brake lever assembly (1) to the front at the position it stops.

#### Note:

Take care that the arm brake torsion spring (2) is removed forcefully.




Fig. 6-8-1

3. Hook the arm brake torsion spring (2) temporarily to a new arm brake lever assembly (1).

#### Note:

Take care of the direction of the arm brake torsion spring (2) so that the longer end of the arm brake torsion spring (2) is hooked on the temporary hook.




Fig. 6-8-2

4. Insert the hook portion on the arm brake lever assembly (1) to the cutout on the mechanical deck.
5. Turn the arm brake lever assembly (1) counterclockwise and fix it at the position which the arm brake lever assembly (1) faces to the straight below.
6. When pushing the tip of the arm brake torsion spring (2) located at (B) position, the tip is removed from the temporary hook and moves to the hook on the mechanical deck.
7. The arm brake lever assembly turns to the specified position by force of the arm brake torsion spring.




Fig. 6-8-3

## 1-6-9. Cylinder Assembly Inspection and Replacement

### <Inspection>

1. Check if the tape transport surface on the lower cylinder assembly are not damaged.
2. Check if the rotation of the upper cylinder assembly is not abnormal.

When any abnormality is found according to the inspection procedures described above 1 and 2, replace the cylinder assembly.

### <Replacement>

1. Remove the slip ring assembly. (Refer to item "1-6-13. Slip Ring Assembly Replacement".)
2. Remove the head cleaner. (Refer to item "1-6-14. Head Cleaner Replacement".)
3. Remove the FPC (1) on the rotary transformer.
4. Remove three screws (2) and the cylinder holding plate (3) and (4). (Refer to item "1-6-12. Cylinder Holding Plate Replacement".)
5. Remove the cylinder assembly (5).
6. Remount the cylinder assembly (5) in the reverse order of removal. Fix the cylinder pressing slightly in the direction shown by the arrow A and the cylinder holding plate (3) pressing slightly in the direction shown by the arrow (B). (Tightening torque: 294 – 392 mN•m (3 – 4 kg•cm))




Fig. 6-9-1

### Note:

- When remounting the cylinder holding plate (3), after confirming that the FPC (1) is hooked at the groove on the lower cylinder assembly properly, and then insert the FPC under the tip of the cylinder holding plate (3).
  - When replacing, take much care not to touch the video head directly and damage the cylinder.
7. Perform the tape transport adjustment.




Fig. 6-9-2

## 1-6-10. Upper Cylinder Assembly & Pre Amplifier Inspection and Replacement

### <Inspection>

1. Check if the video heads are damaged or worn out.
2. Check the video heads for clogging. (In case that the clogging is not remedied after cleaning.)

### <Replacement>

1. Remove the slip ring assembly. (Refer to item "1-6-13. Slip Ring Assembly Replacement".)
2. Remove two securing screws (1) and remove the upper cylinder assembly (2).
3. Remove four securing screws (3) and remove the pre amplifier assembly (4) and the ring (5).



4. 1)

If any abnormality is found on the video head, replace the upper cylinder sub assembly (6) and fix the pre amplifier (4) with two screws. (Tightening torque: 392 – 441 mN•m (4 – 4.5 kg•cm))




Fig. 6-10-1

2)

If any abnormality is found on the pre-amplifier (4), replace the pre-amplifier (4). After desoldering, remove the ring (5) and mount the pre-amplifier (4) to the upper cylinder sub assembly (6). Solder the pre-amplifier (4) after fixing with four screws (3).

(Tightening torque: 392 – 441 mN•m (4 – 4.5 kg•cm))

**Note:**

Adjust each phase of the head (8), rib and marking ▲ on the upper cylinder sub assembly (6), ring (5) and the pre amplifier (4).




Fig. 6-10-2

5. Clean the upper cylinder sub assembly (6) and the mounting surface of the flange (7) with a cleaning kit.
6. Mount the upper cylinder assembly (2) so that the rib of the upper cylinder (2) (ring (5)) matches with groove (A) on the flange (7), then fix them with two screws (1). (Tightening torque: 294 – 392 mN•m (3 – 4 kg•cm))

**Note:**

- Mount the FPC so that the FPC is inserted into the cutout of the lower cylinder assembly.
- During the work in steps 2 to 6, take care not to touch the joint spring on the pre amplifier and deform it.
- 7. Perform the tape transport adjustment according to its procedures.

### 1-6-11. Lower Cylinder Assembly Inspection and Replacement

#### <Inspection>

1. Check if the tape transport surface on the lower cylinder assembly is not damaged.
  2. Check if the rotation of the upper cylinder assembly is not abnormal.
  3. Check if the FPC on the rotary trans is not damaged.
- When any abnormality is found under the inspection described in the steps (1) to (3), replace the cylinder assembly.

#### <Replacement>

1. Remove the cylinder assembly. (Refer to item "1-6-9. Cylinder Assembly Inspection and Replacement".)
2. Remove two securing screws (1) and remove the upper cylinder assembly (2).
3. Replace the lower cylinder assembly (3).
4. Mount the lower cylinder assembly in the reverse order of removal taking care not to touch the video head directly and damage the cylinder.

#### Note:

- Take care not to deform the joint spring on the upper cylinder assembly (2).
- Refer to item "1-6-9. Cylinder Inspection and Replacement" for the treatment of the FPC.
- 5. Perform the tape transport adjustment according to its procedures.




Fig. 6-11-1

### 1-6-12. Cylinder Holding Plate Replacement

1. Remove screws (1) and (2) securing the cylinder holding plate (3) and a screw (5) securing the cylinder holding plate (4).
2. Remove the cylinder holding plate (3) and (4) sliding in the direction shown by the arrow (B) and (A).
3. Eliminate the cylinder lock key (wedge shaped parts).
4. After replacing the cylinder holding plates (3) and (4), mount new parts in the reverse order of removal.

#### Note:

- When remounting, fix the cylinder while pushing in the direction shown by the arrow (A) and the cylinder holding plate (3) in the direction shown by the arrow (B). Then tighten three screws while pushing the cylinder holding plate (4) toward the stopper on the outsert of the mechanical deck.
- Take care of the position inserting the FPC. (Refer to item "1-6-9. Cylinder Assembly Inspection and Replacement".)
- Tightening order of the screws is (1) → (2) → (5).
- Tightening torque of the screws (1), (2), (5) is 294 – 392 mN•m (3 – 4 kg•cm).
- Take care of the position inserting the FPC when mounting the cylinder holding plate (3). (Refer to item "1-6-9. Cylinder Assembly Inspection and Replacement".)




Fig. 6-12-1

### 1-6-13. Slip Ring Assembly Replacement

1. Remove two connectors (2) (cylinder side and PC board side) of the slip ring assembly (1).
2. Remove a screw (3).
3. Remove the slip ring assembly (1) upward.
4. After replacing the slip ring assembly (1), mount it in the reverse order of removal.

#### Note:

- Take care of the connector (2) direction. (The wire holder portion of the cylinder side connector (2) faces to the center pole of the cylinder.)
- Take care not to add force to the upper cylinder assembly.
- Take care not to deform the spring plate on the slip ring assembly, because it is easily deformed.
- After replacing, confirm no slack is found on the connector lead wire on the PC board side. (If any slack is found, remove the slack.)
- When securing the screw (3), be sure to secure the rag terminal together.
- When mounting the slip ring assembly (1), first insert the shaft into the center hole of the coupling.
- When mounting and removing the cylinder side connector, use tweezers.




Fig. 6-13-1

### 1-6-14. Head Cleaner Replacement

#### <Roller sub assembly replacement>

1. Remove the roller sub cleaner assembly (2) pulling upward from the hook (A) on the cleaner lever (1).
2. After replacing the roller sub assembly, mount in the reverse order of removal.

#### <Cleaner lever replacement>

1. Undo the hook (B) of the cleaner lever (1) from the mechanical deck, and pull out the cleaner lever (1) upward.
2. Replace the cleaner lever (1) on the roller sub assembly (2), and mount the cleaner lever (1) in the reverse order of removal.

#### Note:

- Take care the roller sub assembly (2) is not stained with grease or oil.




Fig. 6-14-1

#### Note:

- When remounting the head cleaner, position the stopper rib (C) in front of the stopper (D).





Fig. 6-14-2

**Note:**

- Confirm that the joint portion (E) of the elastic spring positions in front of the assist pin (F) on the cleaner assist lever (4).

**Fig. 6-14-3****1-6-15. No. 8, No. 3 Guide Sleeves Replacement**


1. When replacing the No. 8 guide sleeve (1), first remove the guide cap (2) on the loading bracket assembly.
2. Pull out the guide sleeve (1) from the guide post (3).

**Note:**

- Take care not to break the No. 8, No. 3 guide posts on the mechanical deck if twisting the guide sleeve forcefully.
3. Insert a new guide sleeve (1) to the guide post.

**Note:**

- When inserting the guide sleeve (1), take care so that its hole faces the opposite side to the tape transport surface.
4. For No. 8 guide sleeve, insert the No. 8 guide cap (2) onto it.

**Fig. 6-15-1****1-6-16. ACE Head Assembly Replacement**


1. Remove the FFC (1) from the connector.
2. Remove two screws (2) and remove the ACE main base (3) and ACE head assembly (4).
3. Remove three adjusting screws (5), (6), and (7) and then remove the ACE head assembly (4).

**Note:**

- When replacing ACE head (9) only without replacing its PC board, unsolder the ACE head (9) on the ACE head PC board (8) and then remove the ACE head (9) and the ACE head PC board (8).
4. Mount the ACE head assembly (4) in the reverse order of removal.

**Note:**

- When reassembling the ACE head assembly (4), First set the ACE springs (10) between the ACE head assembly (4) and the ACE main base (3), and secure the adjusting screws (5), (6), and (7).

**Fig. 6-16-1**

- When securing three adjusting screws, mount the ACE main base (3) and ACE head assembly (4) so that the clearance between them becomes parallel with the specified preset value ( $4.3 \pm 0.1$  mm).

5. After replacing, perform the tape transport adjustment.

**Note:**


- When replacing the ACE head assembly (4), always use an ACE head (9) having the same part number. Do not use any other ACE head assembly.

### 1-6-17. FE Head Replacement

1. Open the FE head holding hook (1) on the mechanical deck slightly in both left and right directions and remove the FE head (2) by moving in the direction shown by the arrows.
2. Replace the FE head (2) and mount the parts in the reverse order of removal.
3. Perform adjustment from the linearity adjustment item in the tape transport system adjustment.

**Note:**

- When mounting the FE head, Push the head backward completely.
- Though FE head (2) can be removed upward by opening the FE head holding hook (1) to both left and right directions, perform the standard replacement procedure described above since this may cause deformation of the hook.




**Fig. 6-17-1**

### 1-6-18. S, T Slider Replacement

1. Remove the tension lever assembly. (Refer to item “1-6-23. Tension Lever Assembly Replacement”.)
2. Remove the loading slider. (Refer to item “1-6-25. Loading Slider Replacement”.)
3. Remove the S loading assembly. (Refer to item “1-6-24. S Loading Assembly Replacement”.)
4. Remove the T loading assembly. (Refer to item “1-6-24. T Loading Assembly Replacement”.)
5. Remove the S slider (1) and T slider (2) lifting up to the cutout of the groove on the mechanical deck (3).
6. Remove the S and T guide rollers and mount a new slider.
7. Mount the parts in the reverse order of removal.

**Note:**

Perform the phase alignment between the loading slider (4) and S, T loading assemblies (5), (6) referring each replacement procedure.



**Fig. 6-18-1**

8. After completion of the replacement, perform the adjustment from item 1 in the tape transport system adjustment.

### 1-6-19. S, T Guide Rollers Replacement

The same replacement procedures will be applied for the S, T guide rollers.

1. Turn the guide roller (1) counterclockwise and remove the guide roller (1) from the slider assembly (2).
2. Mount a new guide roller on the slider assembly (2) turning clockwise.
3. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment..

#### Note:

- O ring is not applied to the T guide roller.
- For the T guide roller, marking is located on the upper flange. So take care not to mis-mount with the S guide roller.




Fig. 6-19-1

### 1-6-20. S, T Impedance Roller Replacement

1. Remove two screws (1) and (2), and then remove two brackets (3), (4).
2. Replace two impedance rollers (5), (6).
3. Mount the parts in the reverse order of removal.
4. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment.

#### Note:

- S, T impedance rollers (5), (6) is not always applied to all models.




Fig. 6-20-1

### 1-6-21. Pinch Roller Assembly Replacement

1. Remove the loading drive assembly (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
2. Remove the pinch assembly (1) lifting vertically from the pinch post (2).
3. Remove the pinch spring (5) from the hooks on the pinch drive assembly (3) and the pinch lever assembly (4).
4. Turn the projection (A) on the pinch drive assembly (3) counterclockwise till it goes to the cutout on the pinch lever assembly (4).
5. After replacing, mount the parts in the reverse order of removal.
6. After completion of the replacement, perform the tape transport adjustment.




Fig. 6-21-1

**Note:**

- For the removal and assembling of the loading drive assembly, refer to item 1-6-29.
- When inserting the pinch assembly (1) into the pinch post (2), insert it so that the pinch drive post (D) enters the groove (E) inside the cam gear.
- Take care not to touch the surface of the pinch roller and the grease is not stained on it.
- Be sure to apply grease to the surface of the bar-ring on the pinch lever assembly (4) and the pinch post (2) on the mechanical deck.

**1-6-22. No. 9 Guide Lever Assembly Replacement**

1. Remove the loading drive assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
2. Remove the drive lever. (Refer to item "1-6-40. Drive Lever Replacement".)

3. Remove the pinch assembly. (Refer to item "1-6-21. Pinch Roller Assembly Replacement".)
4. Remove the ACE head assembly. (Refer to item "1-6-16. ACE Head Assembly Replacement".)
5. Remove the cam gear (2) from the cam gear post (1).
6. Remove the T soft brake spring (3).
7. Remove the No. 9 guide lever assembly (4) lifting the No. 9 guide lever assembly upward from the No. 9 guide post (5).
8. After replacing, mount the parts in the reverse order of removal.
9. After completion of the replacement, perform the tape transport adjustment.

**Note:**

- When mounting the No. 9 guide lever assembly (4), confirm that (A) side of the No. 9 guide lever assembly (4) touches the capstan motor housing portion.
- After inserting the No. 9 guide lever assembly (4) into the No. 9 guide post (5), confirm that the lower projection of the No. 9 guide lever assembly (4) touches to the upper surface of the mechanical deck.
- Take care that the grease is not stained on the No. 9 guide post of the No. 9 guide lever assembly (4).
- Be sure to apply grease to the No. 9 guide post (5).




Fig. 6-22-1

### 1-6-23. Tension Lever Assembly, Band Holder and Band Brake Replacement

1. Remove the tension spring (1).

#### Note:

- Take care not to extend or deform the tension spring.
2. After setting the band brake adjuster to the band holder assembling position, undo the claw of the snap-fit type and remove the band holder from the band brake adjuster by lifting it upward.




Fig. 6-23-1 Detail of band holder assembling

3. Undo the claw of the outsert on the mechanical deck catching the shaft of the tension lever assembly (3) and remove the tension lever assembly lifting it upward.
4. Remove the band brake (5) from the reel table while pulling the S soft brake lever (4) in the direction shown by the arrow.
5. Remove the band brake (5) from the hook on the tension lever assembly (3).

#### Note:

- Take care not to contaminate, bend or damage the felt surface on the band brake (5).
6. After replacing the tension lever assembly (3), clean the shaft on the tension lever and apply a few amount of oil.
  7. Mount the parts in the reverse order of the removal.
  8. After mounting, check the tension post position and perform the adjustment and back tension check.
  9. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment.

#### Note:

- The band holder (2) can be replaced in the procedures described above steps 1 to 3.
- The band brake (5) can be replaced in the procedures described above steps 1 to 5.
- When replacing the band holder (2) and band brake (5), the linearity adjustment is not necessary.




Fig. 6-23-2



### 1-6-24. S,T Loading Assembly Replacement

1. Remove the mechanical deck assembly from the main PC board.
2. Set the mechanical position to the F/L out position (front side). Turn over the mechanical deck.
3. Remove the loading slider assembly. (Refer to item "1-6-25. Loading Slider Assembly Replacement".)




Fig. 6-24-1

4. Remove the S, T loading assemblies (1), (2).
5. Insert the S, T slider assemblies (3), (4) along the cutout of the S, T loading holes (A) and (B) on the mechanical deck and set the S, T slider assemblies (3), (4) to the loading position (rear side).
6. Insert the T loading assembly (2) to the post (C) on the T slider assembly (4) and the post (D) on the mechanical deck. And insert the S loading assembly (1) to the post (E) on the S slider assembly (3) and the post (F) on the mechanical deck.




Fig. 6-24-2

#### Note:

- Align the phases of the ▲ marks on the S, T loading gear (1), (2).
7. Set the S, T slider assemblies (3), (4) to the F/L out position.




Fig. 6-24-3

### 1-6-25. Loading Slider Assembly Replacement

1. Remove the mechanical deck from the main PC board.
2. Set the mechanical position to the F/L out position.
3. Turn over the mechanical deck.
4. Remove the stop ring (1).
5. Remove the loading slider assembly (2) while lifting its tip upward using the mold portion on the loading slider assembly (2) as a fulcrum.
6. Mount the parts in the reverse order of removal.

#### Note:

- When mounting the loading slider assembly (2), insert the tip of the loading slider assembly (2) slightly to the mold portion, then mount it so that the claw on the outsert is in the position of the cutout portion of the loading slider assembly.
- Confirm that the position mark on the loading slider assembly (2) and the mark on the T loading gear match each other in position.




Fig. 6-25-1 View from Mechanical deck bottom side




Fig. 6-25-2

### 1-6-26. Hook Lever Assembly Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. Remove the tension spring (1).
5. Turn the hook lever assembly (2) counterclockwise slightly, and remove the claw on the hook lever assembly (2) then replace.
6. After replacing the hook lever assembly (2), insert the (A) portion of the hook lever under the S reel table assembly. When the portions (B), (C), (D) are in line, push the claw into the mechanical deck.




Fig. 6-26-1

7. Turn the hook lever assembly (2) clockwise till it stops, and mount the tension spring (1). After replacing the hook lever assembly (2), slide the cam slider in the direction shown by the arrow, and then position the boss (E) under the cam slider.




Fig. 6-26-2

### 1-6-27. Hook Replacement

1. Remove the hook lever assembly. (Refer to item "1-6-26. Hook Lever Assembly Replacement".)
2. Turn over the hook lever assembly (1) and remove the hook lever assembly (1) opening the portion (A) of the hook (2) slightly and lifting the hook (2) upward.
3. When mounting a new hook, push the hook (2) in the portion (B) from above.

#### Note:

- Take care not to confuse the mounting direction of the hook (2).




Fig. 6-27-1

### 1-6-28. Tension Drive Lever Replacement

1. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
2. Turn over the mechanical deck and remove the tension drive lever (1) from the projection (A) moving counterclockwise slightly.
3. After replacing the tension drive lever (1), mount in the reverse order of removal.

#### Note:

- For the cam slider mounting, refer to the notes in item 1-6-41.




Fig. 6-28-1

### 1-6-29. Loading Drive Assembly Replacement

1. Remove the F/L ground plate and the head cleaner assembly. (Refer to item "1-6-14. Head Cleaner Assembly Replacement".)
2. Remove two flat cables (1) from the connectors.
3. Pull out the portion (A) (No. 8 guide cap) from the motor bracket (2).
4. Remove four claws (a), (b), (c), (d) securing the motor bracket in the order of (a) → (b) → (c) → (d).




Fig. 6-29-1

#### Note:

- Remove the claw (a) inserting a driver.
- Remove the claws (b) and (c) pushing inside previously and opening the claws slightly.






Fig. 6-29-2

**<Preparation for Loading drive assembly mounting >**

- a) Confirm that the head cleaner assembly is removed.
  - b) Confirm that the small hole b) on the cam gear aligns with the hole on the mechanical deck.
  - c) Confirm that the clearance between the pinch lever assembly and the cam gear is approx. 0.3 mm. (Confirm that the pinch lever assembly is correctly mounted on the groove of the cam gear.)
  - d) Confirm that the clearance between the drive lever and the cam gear is approx. 2 mm. (Confirm that the drive lever is correctly mounted on the groove of the cam gear.)
  - e) Confirm that the  $\Delta$  mark on the rotor of the cam switch aligns with the  $\Delta$  mark on the motor bracket.
5. After completion above steps a) to e), mount the loading drive assembly. Push four claws to the motor bracket in the order of (d)  $\rightarrow$  (c)  $\rightarrow$  (b)  $\rightarrow$  (a) and push the portion (A) (No. 8 guide cap) into the motor bracket.
  6. Confirm that the  $\Delta$  mark on the rotor of the cam switch aligns with that on the bracket when the hole b) on the cam gear aligns with the hole on the mechanical deck. If the alignment of the  $\Delta$  marks cannot be confirmed, remove loading drive assembly once again and reinstall after confirming the above steps a) to e).
  7. Mount two flat cables.
  8. Mount the F/L ground plate and the head cleaner assembly.




**Loading drive assembly bottom side**


**Fig. 6-29-3**

### 1-6-30. Loading Motor Sub Assembly, Cam Switch and Loading Drive Unit Replacement

1. Remove the loading drive assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
2. Remove the cleaner assist lever (1) from the claw (A).
3. After removing the cleaner assist lever (1), the worm wheel can be also removed upward.
4. Insert a slot-type screwdriver into the portion (C) of the loading drive bracket (3) and push the loading motor 2 – 3 mm lower. And push the tip of worm gear from the portion (D) of the loading bracket (3), then remove the worm gear (4) from the claw (E).
5. Remove the cam switch (5) from the claw (F) on the loading drive bracket (3) and pull out the loading drive unit (7) and the worm gear (4) simultaneously.
6. Replace the loading drive unit (7). When mounting the PC boards of the cam switch (5) and the loading drive unit (7), take care that no clearance is allowed.
7. Insert the loading drive unit (7) and the worm gear (4) into the loading drive bracket (3).
8. Push the tip (G) of the worm gear (4) into the claw (E) on the loading motor bracket.
9. Push the cam switch (5) into the claw (F) on the loading motor bracket.
10. Mount the parts in the reverse order of removal.



**Loading drive assembly (Top Side)**



**Loading drive assembly (Bottom side)**

**Fig. 6-30-1**

### 1-6-31. Cam Gear Replacement

1. Remove the loading drive assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
2. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
3. Remove the drive lever. (Refer to item "1-6-40. Drive Lever Replacement".)
4. Remove the pinch roller assembly. (Refer to item "1-6-21. Pinch Assembly Replacement".)
5. Remove the cam gear.
6. Apply grease on a new cam gear on the shaded portion as shown in Fig. 6-31-1 and the shaft of the main base.




Fig. 6-31-1

7. Make the S, T slider to the slot out condition.
8. Push the cam lever (1) and the pin (2) (loading slider) in the direction shown by the arrows (A) and (B).
9. Mount the cam gear at the angle which the small hole (a) on the cam gear aligns with the hole on the mechanical deck. (Refer to Fig. 6-31-1.)




Fig. 6-31-2

10. Mount the parts in the reverse order of removal.

### 1-6-32. S Reel Table Assembly and Washer 2 Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
4. Remove the S soft brake and S main brake assembly. (Refer to item "1-6-38. S Soft Brake Replacement and 1-6-37. S Main Brake Assembly Replacement".)
5. Remove the tension lever assembly. (Refer to item "1-6-23. Tension Lever Assembly Replacement".)
6. Remove the S reel table assembly (1) pulling it out upward.
7. Remove the washer 2 (2).
8. After cleaning the reel shaft (3) with a cleaning kit, insert a new washer 2 (2) to the reel shaft (3) and apply a drop of oil to the shaded portions (two locations) on the reel shaft (3).
9. After replacing, mount the parts in the reverse order of removal.
10. Confirm the reel torque using a torque cassette.

#### Note:

- The washer 2 (2) can use repeatedly.




Fig. 6-32-1

### 1-6-33. T Reel Table Assembly and Washer 2 Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the T soft brake and T main brake assembly (Refer to item "1-6-41. Cam Slider Replacement".)
4. Remove the T reel table assembly (1) pulling it out upward.
5. Remove the washer 2 (2).
6. After cleaning the reel shaft (3) with a cleaning kit, insert a new washer 2 (2) to the reel shaft (3) and apply a drop of oil to the shaded portions (two locations) on the reel shaft (3).
7. After replacing, mount the parts in the reverse order of removal.
8. Confirm the reel torque using a torque cassette.




Fig. 6-33-1

#### Note:

- Washer 2 (2) can use repeatedly.

### 1-6-34. Idle Arm Assembly Replacement (Center Gear Pulley, Idle Kick Lever, Idle up/down Lever)

1. Remove the mechanical deck from the main PC board.
2. Remove the stop ring (1) turning over the mechanical deck.
3. Remove the center gear pulley (2) lifting it upward.
4. Remove the claw (A) on the idle kick lever (3) moving and pulling it upward.
5. Remove the slit washer (4).
6. Remove the idle up/down lever (5) and the idle arm (6) simultaneously from two claws (B) on the mechanical deck.
7. After cleaning the center gear post (7) using a cleaning kit, apply a few drops of oil to the shaded portion on the center gear post.
8. Mount the parts in the reverse order of removal.

#### Note:

- Stop ring (1) is impossible to use again.
- When mounting the parts, take care of the notice shown in Fig. 6-34-2.




Fig. 6-34-1




Fig. 6-34-2

### 1-6-35. Holder Center Post Assembly Replacement

1. Turn over the mechanical deck and remove the center gear pulley and the idle arm. (Refer to item "1-6-34. Idle Arm Assembly Replacement".)
2. Turn over the mechanical deck and remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Assembly Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. After removing two screws (1), replace the holder center post assembly (2).
5. After replacing, mount the parts in the reverse order of removal.




Fig. 6-35-1

### Note:

- When mounting, push the cutout (A) on the holder center post assembly (2) aligning with the projection on the mechanical deck.
- Screw tightening torque is 294 – 392 mN•m (3 – 4 kg•cm).
- Before mounting the center gear pulley, apply a few drops of oil. (Refer to Fig. 6-34-1.)

### 1-6-36. REC Inhibiting Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
4. Remove the tension spring (2).
5. Undo the claw (A) on the S soft brake (1) sliding and lifting it upward.
6. Remove the projection (B) on the REC inhibiting lever (3) sliding in the direction shown by the arrow and lifting it upward.
7. After replacing the REC inhibiting lever (3), mount the parts in the reverse order of removal.




Fig. 6-36-1



### 1-6-37. S, T Main Brake Assembly Replacement

1. Remove the mechanical deck from the main PC board and turn the mechanical deck upside down.
2. When replacing the T main brake assembly (2), first remove the idle kick lever (3). (Refer to item "1-6-34. Idle Arm Assembly Replacement".)
3. Remove the tension spring (4).
4. Remove the claws on the S, T main brakes (1), (2) from the mechanical deck lifting the S, T main brakes (1), (2) upward.
5. After replacing the S, T Main brake assemblies (1), (2), mount the parts in the reverse order of removal.

#### Note:

- When mounting the S, T main brake assemblies (1), (2) take care that both ends of the S, T main brakes (1), (2), do not touch the gear of the reel table.




Fig. 6-37-1

### 1-6-38. S Soft Brake Replacement

1. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the S soft brake spring (1).
4. Remove the S soft brake (2) after removing the claw (A) on the S soft brake from the mechanical deck.

#### Note:

- When mounting the S soft brake spring (1), take care not to deform the hook (B).
- When mounting the S soft brake (2), take care of the band brake (3).




Fig. 6-38-1

### 1-6-39. T Soft Brake Replacement

1. Remove the T soft brake spring (1).
2. Remove the claw (A) on the T soft brake (2) from the mechanical deck and remove the T soft brake (2).
3. After replacing the T soft brake (2), mount the parts in the reverse order of removal.

#### Note:

- When mounting the T soft brake spring (1), take care not to deform the hook (B).
- Take care not to touch the surface (C) on the brake pad.




Fig. 6-39-1

### 1-6-40. Drive Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
5. Remove the Loading Drive Assembly. (Refer to item "1-6-29. Loading Drive Assembly Replacement".)
6. Remove the drive lever (1).

7. After replacing the drive lever (1), mount the parts in the reverse order of removal.

#### Note:

- Be sure to align the phase of the cam gear (2). (Refer to item 1-6-41. Cam Slider Replacement".)
- Mount the drive lever (1) so that it is positioned between the mark (A) on the mechanical deck and the outsert (B).
- Apply grease to the surface between the mark (C) on the mechanical deck and the drive lever shaft (D).




Fig. 6-40-1

### 1-6-41. Cam Slider Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the tension spring (1).
3. Turn the hook lever assembly (2) counterclockwise and turn the S soft brake (3) counterclockwise.
4. Move the cam slider (4) to the right and align the projection (A) on the mechanical deck and the cutout portion (B) on the cam slider (4).
5. Remove the claw (C) on the cam slider (4) and remove the cam slider (4) lifting the cam slider (4) upward.




Fig. 6-41-1

6. Apply grease on the shaded portion of a new slider for the replacement.
7. Mount the parts in the reverse order of removal. After inserting the cam slider, slide it to the left direction till it stops. (Fig. 6-26-2 shows this condition.)

#### Note:

- When mounting the cam slider (4), slide the tension drive lever in the direction shown by the arrow (counterclockwise).
- After completion of the replacement, confirm that the cam slider (4) can slide to left and right directions smoothly.




Fig. 6-41-2

### 1-6-42. Idle Centering Lever Replacement

1. Remove the cam slider. (Refer to item "1-6-41. Cam Slider Replacement".)
2. Remove the claw on the idle centering lever (1) and remove the idle centering lever (1) lifting it upward.
3. After replacing the idle centering lever (1), mount the part in the reverse order of removal.




Fig. 6-42-1

### 1-6-43. Capstan Motor Replacement

1. Remove the reel belt (1).
2. Remove one screw (2) from the bottom of the mechanical deck, and remove the PC board (3).

**Note:**

- Take care not to misuse the screw with others.




Fig. 6-43-1

3. Remove the capstan motor (4) after removing three screws (5).

**Note:**

- Take care not to drop the capstan motor.




Fig. 6-43-2

4. Take care not to damage and scratch the motor itself, and mount the capstan motor (4) fitting the hole (A) on the mechanical deck and the hole (B) on the capstan motor (4).




Fig. 6-43-3

5. Mount the capstan motor (4) with three screws (5) viewing from the top side of the mechanical deck.




Fig. 6-43-4

**Note:**

- Do not use once-removed screws again.
- Take care that no clearance is allowed when securing three screws.

6. After replacement, mount the parts in the reverse order of removal.

**Note:**

- In this case, take care not to twist the reel belt and stick the grease or etc. on it.
7. After replacing, perform the adjustment according to the tape transport adjustment procedures.

#### 1-6-44. S-VHS Switch Assembly Replacement (S-VHS model only)

1. Slide the cassette holder assembly (1) until the screw (2) can be seen from the hole on the top bracket (3).
2. Insert a screwdriver from the hole provided on the top bracket (3) and secure the screw (2).
3. Remove the S-VHS switch assembly (4) upward.
4. After completion of the replacement, mount the parts in the reverse order of removal.




Fig. 6-44-1

#### 1-7. Check and Adjustment

##### 1-7-1. Check of Tension Pole Position

1. Turn the worm wheel counterclockwise after removing the cassette holder assembly on the front loading mechanism, and set the cam gear at playback position.
2. Turn the S reel table assembly (1) clockwise slowly.
3. Adjust the adjuster (3) counterclockwise from the position shown in Fig. 6-23-1 so that the clearance between the left end of the tension lever assembly (2) and the left side of the mechanical deck becomes  $7.5 \pm 1$  mm.

##### Note:

- There is a long mark at the position of 7.5 mm from the round surface of the mechanical deck. Make sure the position of the mark when adjusting.




Fig. 7-1-1

## 1-7-2. Reel Torque Check

### (1) Reel torque

#### 1. REVIEW mode (supply side)

Poor torque may not wind the tape. On the other hand, excessive torque will cause damage to the tape during REVIEW mode.

#### 2. Record/Playback mode (take-up side)

Too little torque does not rewind the tape to the end. If too large torque, the tape may be stretched by excessive tension.

#### 3. Inspection

Rewind the torque cassette to the end, then check the torque values shown below:

Review	$15.95 \pm 3.65 \text{ mN}\cdot\text{m}$ ( $162.5 \pm 37.5 \text{ g}\cdot\text{cm}$ )
--------	--

Record/Playback	$6.85 \pm 2.45 \text{ mN}\cdot\text{m}$ ( $70 \pm 25 \text{ g}\cdot\text{cm}$ )
-----------------	--

For checking method, refer to the following item (2).

### (2) Reel torque and back tension check

1. First, record a TV broadcast program on the entire torque cassette tape (KT-300NR) in the SP mode.
2. Load the torque cassette tape (KT-300NR) in the VTR and feed it forward until the end of the tape, before proceeding with measurement.
3. Set the VTR to the REVIEW mode and feed the tape for about 15s, and then make sure the take-up torque described above is obtained while observing the left torque meter.
4. After completion of step 3), feed forward to tape start position and set the VTR to the PLAY mode and feed the tape for about 30s. Read the right torque meter and check the torque described above is obtained.
5. If the review torque and playback torque are out of limit, replace the clutch assembly.
6. When the S reel table assembly, the T reel table assembly and the idle arm assembly are replaced, perform the reel torque check.

### <Precautions for Use of Torque Cassette (KT-300NR)>

1. Before loading a torque cassette in a VTR, always remove tape slack. The tape slack can be removed by rotating the reel to its take-up direction. (The tape tends to slack when there is no reel brake actions.)
2. When the torque cassette is loaded, confirm followings:
  - Make sure the tape does not ride up or over the No. 8 cap. If it does, do not eject the tape but return the tape to its correct position, taking care not to damage the tape.
  - Make sure the tape is not slackened. If slackened, operate the VTR in FF or REW mode and then stop the tape. Then make sure the tape is not slackened again.
  - After above confirmation, proceed to the reel torque adjustment and confirmation.
3. Caution for removal of torque cassette
  - When removing the torque cassette from the VTR, set the VTR to the STOP mode and wait for several seconds. Then, make sure the tape is not slackened. Push the EJECT button to remove the cassette.
4. If the previous precautions 1), 2) and 3) are not performed properly, the tape may be damaged and correct measurements can not be performed.
5. Do not use worn out or damaged tape, if used they may damage video heads on the cylinder. In such a case always replace the tape with a new one. The replacement tape is of E-180, 10 m in length.

### 1-7-3. Tape Transport System

The tape transport system has been precisely adjusted in the factory, so no check and alignment are necessary except the followings:

- Noises observed on the screen
- Tape damage
- Parts, shown in the adjustment procedures for the tape transport system were replaced.

Electrical signal output terminal required for adjustment differs depending upon the models. Refer to the test point location in the Electrical Adjustment Section.

#### (1) Location of tape transport adjustment

##### <Adjustment reference>

Lower flange height of No. 8 guide is used as the basic reference for the transport adjustment. To keep height of the No. 8 guide, do not apply excessive force onto the main base to prevent the main base from deformation.

Rectangles shown in Figs. 7-3-1, 7-3-2 show the adjusting locations.




Fig. 7-3-1 Tape travel diagram





Fig. 7-3-2 Location of tape transport adjustment

**(2) Tape transport system adjustment flow chart**





### (3) Tape transport system adjustment

#### <Pre-adjustment>

When the part(s) listed in Table 7-3-1 is replaced, perform required adjustments by referring to procedures for the tape transport system. When the part(s) listed in Table 7-3-1 is replaced, the tape path may be changed and may damage alignment tape. To prevent this, first run a E-240 tape and make sure excessive tape wrinkle does not occur at each tape guide.

1. If tape wrinkle is observed at the S, T guide rollers, turn the S, T guide rollers until wrinkle disappears.
2. If tape wrinkle is observed at the No. 8 guide, perform the tilt adjustment of the ACE head.

Table 7-3-1

Parts replacement	Adjustment procedure
<ul style="list-style-type: none"> <li>• Cylinder assembly</li> <li>• S, T sliders</li> <li>• ACE head</li> <li>• Pinch lever assembly</li> <li>• Capstan motor</li> <li>• No. 9 guide lever assembly</li> </ul>	From item 1)
<ul style="list-style-type: none"> <li>• Upper cylinder</li> </ul>	From item 2)
<ul style="list-style-type: none"> <li>• S, T guide rollers</li> <li>• Tension lever assembly</li> <li>• FE head</li> </ul>	From item 3)
<ul style="list-style-type: none"> <li>• Reel clutch assembly</li> <li>• S, T reel tables</li> </ul>	From item 4)

#### <Adjustment procedures>

##### 1) ACE head assembly coarse adjustment

###### a. Audio head height adjustment

1. Play back the tape recorded in the SP mode. Observe the surface of the ACE head.
2. Turn the ACE height adjusting screw so that upper tape edge matches to the upper edge of the audio head core.

###### b. ACE head tilt adjustment

1. Play back the tape recorded in the SP mode and observe running condition of the tape at the lower flange of No.8 guide.

2. Turn the ACE tilt adjusting screw until tape wrinkle is caused at the lower flange of No. 8 guide as shown in Fig. 7-3-4 (A).
3. Turn the ACE tilt adjusting screw counterclockwise until the tape travels along the lower flange as shown in Fig. 7-3-4 (B).

##### c. Audio head azimuth adjustment

1. Play back the 7 kHz audio signal on the alignment tape in the SP mode.
2. Connect a millivoltmeter or oscilloscope to the audio line output terminal.
3. Turn the ACE azimuth adjusting screw to obtain maximum audio output.




Fig. 7-3-3




Fig. 7-3-4 No. 8 guide rough adjustment

##### d. ACE head position adjustment

1. Play back the 2 MHz video envelope signal in the alignment tape in the SP mode. Loosen the ACE head position securing screw.
2. Insert a slot-type screwdriver into the ACE head position adjusting slit on the ACE main base and adjust the ACE main base so that the video envelope reaches a peak level at the tracking center position when the channel (tracking) up/down buttons of VTR are pressed simultaneously.

## 2) Playback phase adjustment

1. Perform the adjustment according to the methods stated in the electrical adjustment (servo circuit).

## 3) Linearity adjustment


1. Play back the LP mode white video signal on the alignment tape.

### Note:

- For models SP mode only, use the 2 MHz (A ch) video signal in the SP mode.
- 2. Trigger the scope with the switching pulse to issue the envelope signal output.
- 3. Make sure the video envelope waveform (in its maximum output) meets the specification shown in Fig. 7-3-5. Again make sure the same by playing back the SP mode 2 MHz video signal on the alignment tape. If not satisfied, adjust as follows:

### Note:

- a = maximum output of the video RF envelope
- b = minimum output of the video RF envelope at the entrance side
- c = minimum output of the video RF envelope at the center point of cylinder
- d = minimum output of the video RF envelope at the exit side of cylinder



$$\left. \begin{array}{l} c, b, d/a \geq 0.75 \quad (\text{S-VHS model}) \\ b, d/a \geq 0.63 \\ c/a \geq 0.75 \end{array} \right\} (\text{Non S-VHS model})$$

Fig. 7-3-5

4. If the (A) section in Fig. 7-3-6 does not meet the specifications, adjust the S guide roller in up or down direction.
5. If the (B) section in Fig. 7-3-6 does not meet the specifications, adjust T guide roller in up or down direction.




Fig. 7-3-6

6. After completion of the adjustment(s), push the channel (tracking) up/down button and make sure video envelope variations are almost flat. Next, play back the 2 MHz SP mode video signal on the alignment tape and make the video RF envelope variations are also flat when channel (tracking) UP/DOWN buttons is pushed.
7. If the envelope varies like NG figures as shown in Fig. 7-3-7, perform the adjustment again. Smooth secondary curves are allowable level.




Fig. 7-3-7 Abnormal waveform variation

## 4) ACE head assembly fine adjustment

### a. ACE head height fine adjustment

1. Play back the stereophonic alternative recording 300 – 500 Hz audio signal on the alignment tape.
2. Adjust the ACE height adjusting screw so that the signal envelope is obtained almost flat.




Fig. 7-3-8

### Note:

- If there is no alignment tape (ST-C6, ST-C7), do not perform this item "a. ACE head height fine adjustment", and perform the process of the note in item "e. Audio head height check" described later.

#### **b. ACE tilt adjustment**

1. Observe the lower flange of No. 8 guide. If any wrinkle is observed, turn the ACE tilt adjusting screw counterclockwise until the wrinkle disappears.
2. If a gap is observed between the lower flange of No. 8 guide and the lower edge of tape, turn the ACE tilt adjusting screw clockwise until the tape travels along the lower flange.

#### **Note:**

- This adjustment is performed easily in SP mode playback, double speed playback mode or CUE mode.

#### **c. Audio head height check**

1. Play back the stereophonic alternative recorded 300 – 500 Hz audio signal as described in the step 4)-a, and check if the audio envelope is flat. If not, repeat the adjustment described in step 4)-a again.

#### **d. Audio azimuth adjustment**

1. Play back the 400 Hz, 7 kHz audio signal on the alignment tape.
2. Turn the ACE azimuth adjusting screw until the maximum audio output is obtained.

#### **e. Audio head height check**

1. Play back the alignment tape described in step 4)-a and check if the audio envelope is flat. If not, repeat the adjustment described in step 4)-a.

#### **Note:**

- If there is no alignment tape (ST-C6, ST-C7), perform the audio height alignment using the current alignment tape at this adjustment step.
1. Playback the 400 Hz audio signal (SP mode) on the alignment tape.
  2. Turn each three alignment screw of the ACE head to the same direction in 45 degrees steps evenly so that the audio output level becomes maximum.
  3. Perform the confirmation and adjustment for the tilt and the azimuth again.

#### **f. ACE head position adjustment**

1. Play back the white envelope (LP mode) on the alignment tape.
2. Push the channel (tracking) up/down buttons simultaneously and reset the tracking at its center position.

3. Trigger the oscilloscope with the video switching pulse and observe the video envelope waveform.
4. Slide the ACE main base until the maximum envelope output is obtained as described in ACE head position coarse adjustment.
5. Play back the 2 MHz video signal (SP mode) on the alignment tape.
6. Make sure the envelope output is maximum when the tracking control is placed at its center position.  
If no envelope output is obtained with the tracking control set to the center position, again adjust it for maximum envelope output in SP and LP modes. When envelope output is maximum in the LP mode at the tracking center, difference with the case in the SP mode is within 3 ms.
7. Tighten the ACE head position fixing screw and secure the ACE main base.

- g. After completion of ACE head fine adjustment, apply screw lock to two screws (tilt, azimuth adjusting screws) in front of the ACE head.

#### **5) No. 9 guide lever adjustment**

1. Set the VTR to Cue mode with E-240 tape (at beginning portion) loaded. Switch the Cue mode to the review mode when the tape has been rewound into the T-reel table to some extent.
2. Check tape wrinkle at the upper and lower flange of No. 8 guide. Check the tape does not come off from the flange while running. If the tape comes off from the flange, replace the pinch lever, capstan motor or No. 9 guide lever since the part(s) is (are) defective.

#### **Note:**


- Modify the lid of the cassette for the alignment tape E-240 previously so that the alignment is performed easily.

#### **6) Check for transitional operation from Review to Play, slot-in to play**

1. Play back the LP mode white video signal on the alignment tape in Review mode and observe the video envelope with the oscilloscope.
2. Switch the Review mode to the Play mode. When switched to the Play mode, make sure the entrance side envelope comes to an approximate steady state within 3s as shown in Fig. 7-3-9.

If it does not rise within 3s, take the following steps starting 4).

3. Switch the cassette slot-in mode to the Play mode. As in item 2), if it does not rise within 3s, adjust as follows.



**Fig. 7-3-9 Video envelope rising when operation mode is switched from review to play mode**

4. Adjust the S guide roller and perform the linearity adjustment again.
5. Check above items 2) and 3) to see that the video envelope rises within 3s. If not, S slider assembly or the tension lever is damaged. Replace either (or both) of them.

**Note:**


- If the rising characteristic is poor in Review mode, screen noise may occur in synchronous editing recording. Perform the adjustment carefully.

**7) Envelope check**

1. Make recordings and play back the tapes (E-180 and E-240) in SP and LP modes and make sure the playback output envelope meets the specifications shown in Fig. 7-3-5.
2. In playback the tape (with a E-180), the video envelope should meet the specification as shown in Fig. 7-3-10.

**Note:**

- Check for both modes, SP and LP. Also check for AFM envelope when using a Hi-Fi model.



- $B/A \geq 0.55$
- $B \geq 120\text{mV}$

**Fig. 7-3-10 Envelope output and output difference**

3. If the performance does not meet both specifications above 1 and 2 above, replace the upper cylinder assembly.

4. Set the VTR to Rec mode (LP) with the E-180 tape loaded (at the beginning part) and check operation of the synchronous editing recording.
5. If picture noises are observed at the starting position of the editing, perform "6) Check for transitional operation from Review to Play, slot-in to play".

**8) Tape wrinkle check**

1. Playback the E-240 tape in the normal Play mode, CUE mode, Review mode and the frame advance mode, and check each guide for wrinkle.
2. If excessive tape wrinkle is observed at the mode shown below, perform the associated adjustments also shown below. (The parts described in ( ) may need to replace.)

**a. Playback mode**

Tape wrinkle at the S, T-guide rollers section

Item 3) Linearity adjustment  
(Slider assembly)

Tape wrinkle at No. 8 guide flange

Item 1) ACE head assembly coarse adjustment  
(Pinch roller)

Tape wrinkle at lower flange of No. 1 guide

Item 6) Check for transitional operations from  
Review to Play, and Slot-In to Play  
(Tension lever)

**b. Review mode**

Tape wrinkle at No. 8 guide

Item 1) ACE head assembly coarse adjustment  
(Pinch lever, No. 9 guide lever,  
capstan motor)

Tape wrinkle at the guide rollers

Guide roller adjustment (Slider assembly)

**c. Frame advance mode**

Tape wrinkle at No. 8 guide

Item 3) Linearity adjustment  
(Pinch lever, capstan motor)

### 9) Maximum AFM envelope output point check (Hi-Fi model)

1. Playback the SP mode 3 MHz video signal and the 400 Hz AFM signal on the alignment tape.
2. Trigger the oscilloscope with the video switching pulse, adjust the tracking control and check the control pulse phase at the maximum video envelope (A ch) output point.
3. Make sure the control pulse phase difference among each maximum point of AFM envelope, Ach and Bch is within  $\pm 3$  ms with the above point used as the basic reference.

#### Note:

- If the phase difference exceeds 3 ms, replace the upper cylinder.

## 2. ELECTRICAL ADJUSTMENT

### <Test equipment required>

Adjustment will be performed with the following test equipment.

1. Color TV (Monitor)
2. Oscilloscope, 2 CHs, 15 MHz or higher with delay system
3. Frequency counter (7 digits or higher)
4. Millivoltmeter
5. Digital voltmeter
6. Tester (20 k $\Omega$ /V)
7. Audio generator
8. Audio attenuator
9. Alignment tapes  
Part code: ST-C6: 70909409, ST-C7: 70909410
10. Alignment screw driver (jig)
11. Color pattern generator
12. Video sweep generator

### <Color bar signal>

Color bar signals of 75% recorded on the alignment tapes are shown in Fig. 2-1-1.




Fig. 2-1-1

### <Specified input and output levels, and impedance>

Video input: Negative sync, standard composite video signal 1 V(p-p), 75 $\Omega$

Video output: Same as the video input 1 V(p-p), 75 $\Omega$

Audio input: 308 mV(rms), more than 47 k $\Omega$  (phono type), more than 10 k $\Omega$  (21 pin type)

Audio output: 308 mV(rms), less than 4.7 k $\Omega$  (phono type), less than 1.0 k $\Omega$  (21 pin type)

### <Alignment sequence>

Recorded the alignments in the sequence as shown in Fig. 2-1-2.





Fig. 2-1-2

## Alignment tape specifications


### [1] ST-C6

Segment	System	Playback Time (min)	Video Signal	Audio Signal	Applications
1	PAL & SECAM	10	Mono Scope	1 kHz	Playback phase check, audio level check
2	PAL & SECAM	5	3 MHz A ch	400 Hz and 7 kHz	ACE head position adjustment, ACE head azimuth adjustment, Linearity adjustment
3	PAL & SECAM	5	3 MHz A ch	1 kHz (stereo)	ACE head position adjustment, ACE head height adjustment, Linearity adjustment
4	PAL	5	Color bar	3 kHz	Video and Sound checks
5	SECAM	5	Color bar	3 kHz	Video and Sound checks
6	MESECAM	5	Color bar	3 kHz	Video and Sound checks
7	NTSC	5	Color bar	1 kHz	Video and Sound checks

### [2] ST-C7

Segment	System	Playback		Video Signal	Audio Signal	Applications
		Time (min)	Mode			
1	PAL	5	LP	3 MHz A ch	500 Hz (stereo)	ACE head position adjustment, ACE head height adjustment, Linearity adjustment
2	PAL	3	LP	Color bar	3.2 kHz	LP mode operation check, ACE head azimuth check and adjustment
3	PAL	3	SP	Color bar	AFM 400 Hz	SP mode operation check, AFM check
4	PAL & SECAM	5	SP	3 MHz A ch	AFM 400 Hz	AFM tracking checks
5	SECAM	5	LP	3 MHz A ch	No signal	Linearity adjustment
6	SECAM	3	LP	Color bar	No signal	LP mode operation check
7	SECAM	3	SP	Color bar	AFM 400 Hz	SP mode operation check, AFM check

## 2-1. Servo Circuit




Main PC Board

### 2-1-1. Playback Phase (PG) Adjustment

**Test point:** Pins 2 and 3 of P506, Pin 5 of P201 (Video out)

**Test equipment:** Oscilloscope

1. During playback press the channel up and down buttons simultaneously to reset the tracking to its center.
2. Confirm that phase difference between the fall of the SW pulse (pin 3 of P506) and the rise of CTL pulse (pin 2 of P506) is  $11.5 \pm 0.5$  ms.
3. Further, observe the envelope (pin 5 of P506) waveform, and confirm that the ACE head position adjustment and linearity adjustment have been made, and C-SYNC (pin 70 of IC501) is being input during playback.
4. Set the VTR to the STOP mode.
5. Press the unit's channel up/down buttons simultaneously for more than 5s.



6. Afterwards, within 2s, press the PLAY button on the remote controller.
7. The automatic adjustment will be made for about 10s, all the displays will blink. If the automatic adjustment is not carried out, confirm that the alignment tape has a safety tab or not, and redo from the step 3.
  - 1) When adjustment has been completed:  
The display will blink for 10s, stop blinking and return to the normal display in the STILL mode, then it shifts to the playback display in the playback mode.
  - 2) When adjustment fails:  
It goes into the STOP mode.
8. Confirm that the play indicator is displayed, and confirm that the rising and falling edge of the SW pulse is  $6.5 \pm 0.5H$  from the V-sync front edge of the video signal.

### 2-1-2. Pseudo V Adjustment

**Test point:** TV monitor

**Test equipment:** Channel up/down buttons

1. Make recordings and playback, and set to the STILL mode.
2. Adjust the main unit's channel up/down buttons so that center of the still screen will stop.


### 2-1-3. 16 MHz Crystal Oscillation Circuit (Clock) Adjustment

**Test point:** TP501

**Test equipment:** Frequency counter

**Adjusting point:** C552

1. Set the unit to power off mode.
2. After pressing the unit's channel up/down buttons simultaneously for more than 5s without loading a cassette, press the FF button on the remote controller within 2s.
3. Connect the frequency counter to TP501 and measure the frequency.
4. Adjust C552 (trimmer capacitor) with adjusting screwdriver so that the adjusting value  $8.00002 \pm 0.00002$  MHz is obtained.
5. The test mode is released when the power turns on and then return to the normal operation mode.




### 2-1-4. In Case of IC504 is Replaced

When IC504 is replaced, the data in the VTR is required to memorize in the new one. So perform the following procedures.


1. Press the channel up/down buttons on the VTR simultaneously for more than 5s while the display blinks and the unit is in the power off mode.
2. And then within 2s, press the CANCEL button on the remote controller.
3. After displaying the address at the channel display area and the data at the minute display area, set the address to 12 using the channel up/down buttons on the remote controller.

Next, set the data to 78 for V-804B and 69 for V-854B using the FF/REW buttons on the remote controller. The data goes up using FF button and down using REW button.

V-804B



V-854B



4. Set each address and data in the table below following the description above.

Address	Data
24	0A
25	03
26	15
27	0A

5. Perform the adjustment described in the item "2-1-1. Playback Phase (PG) Adjustment".
6. Pull out the power cord plug from the AC outlet once and insert the power cord plug into the AC outlet again.



## 2-2. Self Diagnosis Function

### 2-2-1. Outline


When a tape running stops or the VTR enters the power OFF mode, etc. due to some abnormality, the abnormality is stored in the EEPROM and displayed on the display tube.

### 2-2-2. Storing abnormal modes

- The abnormality is classed into 5 groups, and the abnormality number, system control mode, and the mechanism position at which the abnormality occurred are stored in the EEPROM.
- The writing timing is just after the abnormality occurred.

### 2-2-3. Abnormality mode display

- Press the CH UP and CH DOWN buttons on the VTR simultaneously for more than 5s.
- And then within 2s, press the STILL button on the remote control.
- The system control mode at which the abnormality occurred is displayed at the channel display area, "E" is displayed at the hour digit, abnormality generation number is displayed at the minute digit, and the mechanism position is displayed in the second digit position.
- The abnormality mode is displayed regardless of the power on off.



- When the Counter Reset button is pressed in the display period, the abnormality display data is initialized and "-" is displayed.

The data displayed are as follows:

#### Abnormality generation number

01	Cylinder stop
02	Reel abnormality (take up)
03	Reel abnormality (supply)
04	Abnormal slot in/ slot out
05	Abnormal loading

#### Abnormal system control modes

00	Standby
01	Stop
02	Rewind
03	Review
04	FF
05	Cue
06	Playback
07	Still, slow playback
08	2X speed
09	Stop (moisture condensation)
0A	Reverse playback
0b	Still in reverse playback, Reverse slow playback
0C	Recording
0D	Record pause
0E	Power off eject
0F	Eject
10	Short FF
11	Short REW
13	Audio dubbing
14	Audio dubbing pause

#### Abnormal mechanism positions

01	F/L out
03	F/L down
05	Loading/unloading
07	Reverse rotation with pinch roller ON
09	Playback with pinch roller ON
0b	Stop with main brake ON
0d	FF/REW
0F	Position detection impossible

Positions 0, 2, 4 exist as mechanism positions.  
For example, 8 shows a position between 7 and 9  
(between playback position and review position).

# SECTION 3

## SERVICING DIAGRAMS

### 1. INSPECTION PROCEDURE


Operation steps		Items to be confirmed	Inspection block	Page	
				Block Diagram	Circuit Diagram
1. AC Plug-in	Time setting Program timer setting	Clock display Time setting operation	Power (AC system) KDB	3-14 3-17	3-38 3-47
2. Power SW ON	Timer/counter, Memory  Channel selection, AFC operation, EE picture & tone quality	Mode display lamp TV receive condition, Channel select operation, AFC operation level, EE picture quality, Tone signal level	Power Logic RF reception Video (EE, REC mode) Audio (EE, REC mode)	3-14 3-26 3-15 3-29, 32 3-35	3-38 3-50 3-41, 44 3-57 3-63
3. Cassette-in and Cassette-out	Cassette-in Cassette loading Eject Cassette-out	F/L mechanism operation Cassette loading operation Eject operation Indicator lamp Abnormal sound	Logic	3-26	3-50
4. Key Entry Operation  Remote Control	REC, PLAY Cue/Review Still, Frame advance/slow FF/REW	Indicator lamp Each mode operation (Tape drive operation) Abnormal sound	Logic	3-26	3-50
5. Special Functions Counter Functions  Tracking	Linear time counter, Remaining time display, Index/skip search, Time search Digital auto tracking	Each mode operation  Mode operation	Servo/Logic  Servo/Logic	3-26  3-26	3-50  3-50
6. Playback Function Picture Sharpness Tone Quality Others	PLAY (Test tape: ST-C6, ST-C7) Cue/Review Still/Slow	Resolution, S/N Hue, Saturation, Color unevenness, Color dropout, Sound distortion, Level variation, Picture noise, Jitter Picture swing, Skew distortion, Flicker, Beat	Video PLAY system Audio PLAY system Servo system	3-29, 32 3-35 3-26	3-57, 60 3-63 3-50
7. REC/PLAY Functions Picture Sharpness Tone Quality Others	REC/PLAY	Resolution, S/N Hue, Saturation, Color unevenness, Color dropout, Sound distortion, Level variation, Picture noise, Jitter Picture swing, Skew distortion, Flicker, Beat	Video PLAY system Audio PLAY system Servo system	3-29, 32 3-35 3-26	3-57, 60 3-63 3-50

#### How to use the table


1. When inspecting a defective VTR, proceed according to the steps shown in the table.
2. Check the items to be confirmed for each operation step.
3. If a problem is found on the item, check waveforms (level) referring to the block diagram relating to the items.
4. Use PC board pattern diagram and schematic diagram to examine the circuit precisely.

## 2. REMOVAL OF CABINET

1. Disconnect power cord plug from AC outlet.
2. Remove 3 screws ② securing top cover ①.
3. Remove the top cover ① by sliding it backward.
4. Remove 2 screws ③.
5. Remove the front panel ④.



## 3. ELECTRICAL UNITS LOCATION DIAGRAM



### Note:

In models V-804B, V-854B, two types of Main PC board assemblies are used.

20256360.SA or 20320670.S\* (\*: Optional character) is printed on each PC board. The PC board 20256360.SA is called Type A and the PC board 20320670.S\* is called Type B in this service manual.

When using the Type A PC board, AMP PC board assembly is used and when using the Type B PC board, Video 2 and Video 3 PC boards are used.


## 4. STANDING PC BOARDS FOR SERVICING

After removing the mechanical deck with the main PC board, place the mechanical deck to upright. Then perform servicing in the condition that all the units are connected each other.

### Note:

Applying an excessive force to the connector connecting KDB1 and KDB2 PC board will damage the connector.

So, take much care when removing them.




## 5. PART CONFIGURATION AND THEIR SYMBOLS

### 1.ICs

NAME	SHAPE	NAME	SHAPE
TA8863AF		M5218AP LA6462M	
MSP3410		ST24C04	
TA8892N		TA7267BP	
BA7730S		BA7755	
TL8844P		PQ12RF1	
TA8894AF		STR-D6802	
STV6400		PQ05SZ11	
TB6515AP TL8843P		PST7032MT PST7045MT	
LA5611		PC120FY2	

NAME	SHAPE
------	-------


AN7805




TA78L008AP




TA78L09S




SDA5648



TMP90CR74DF-7328



TMP87CK70AF-6203



## 2. TRANSISTORS

2SC1959-Y  
2SC1959-Y



PT493F




NAME	SHAPE
------	-------

2SA1020-Y  
2SC2236-Y(C)



IMX1




KTA1273




KTD2092




RN1404,2SA1162GR,RN2404  
RN1401,2SC2712Y-R,2SC2712-Y  
DTC114EK,2SA1162Y-R,2SA1162-Y  
2SC2411KQ,RN1401  
RN2402,RN1402  
RN2406,RN1404



IMZ1




IMH6



## 3. DIODEs

1N4148  
ZPD5V1  
1SS136  
ZPD15





## 5-1. Replacing Subminiature "CHIP" Parts

### 5-1-1. Required Tools:

1. Fine tipped, well insulated soldering "pencil", about 30 Watts.
2. Tweezers.
3. Blower type hair dryer.

### 5-1-2. Soldering Cautions:

1. Do not apply heat for more than 3s.
2. Avoid using a rubbing stroke when soldering.
3. Discard removed chips; do no reuse them.
4. Supplementary cementing is not required.
5. Use care not to scratch or otherwise damage the chips.

### 5-1-3. Removal (Resistors, Capacitors, etc.):

1. Melt the solder at one side.




Fig. 1

2. Grasp the part with tweezers and melt the solder at the other side.




Fig. 2

3. Remove the part with a twisting motion.




Fig. 3

### 5-1-4. Removal (Transistors, Diodes, etc.):

1. Melt the solder of one lead.




Fig. 4

2. Lift the side of that lead upward.




Fig. 5

3. Simultaneously heat solder the two remaining leads and lift part to remove.




Fig. 6

### 5-1-5. Preheating (Except for semiconductors):

Immediately before installing new resistors or capacitors, use a blower type hair dryer and preheat the part for about two min. at approximately 150°C.

### 5-1-6. Replacement:

1. Presolder the contact points of the circuit pattern.




Fig. 7

2. Press the part downward with tweezers and apply the soldering pencil as indicated in the figure.




Fig. 8




## 5-2. Precautions for Part Replacement

- In the schematic diagram, parts marked  $\Delta$  (ex.  $\Delta$  F801) are critical part to meet the safety regulations, so always use the parts bearing specified part codes (SN) when replacing them.
- Using the parts other than those specified shall violate the regulations, and may cause troubles such as operation failures, fire etc.


## 5-3. Solid Resistor Indication

Unit	None ..... $\Omega$ k ..... $k\Omega$ M ..... $M\Omega$
Tolerance	None ..... $\pm 5\%$ B ..... $\pm 0.1\%$ C ..... $\pm 0.25\%$ D ..... $\pm 0.5\%$ E ..... $\pm 1\%$ G ..... $\pm 2\%$ K ..... $\pm 10\%$ M ..... $\pm 20\%$
Rated Wattage	(1) Chip Parts None ..... 1/16W (2) Other Parts None ..... 1/6W Other than above, described in the Circuit Diagram.
Type	None ..... Carbon film S ..... Solid R ..... Oxide metal film W ..... Metal film W ..... Cement FR ..... Fusible




## 5-4. Capacitance Indication

Symbol	$\text{---} \text{  } \text{---}$ ..... Electrolytic, Special electrolytic $\text{---} \text{  }^{\text{NP}} \text{---}$ ..... Non polarity electrolytic $\text{---} \text{  } \text{---}$ ..... Ceramic, plastic $\text{---} \text{  }^{\text{M}} \text{---}$ ..... Film $\text{---} \text{  }^{\text{A}} \text{---}$ ..... Trimmer
Unit	None ..... F $\mu$ ..... $\mu\text{F}$ p ..... pF
Rated voltage	None ..... 50V For other than 50V and electrolytic capacitors, described in the Circuit Diagram.
Tolerance	(1) Ceramic, plastic, and film capacitors of which capacitance are more than 10 pF. None ..... $\pm 5\%$ or more B ..... $\pm 0.1\%$ C ..... $\pm 0.25\%$ D ..... $\pm 0.5\%$ F ..... $\pm 1\%$ G ..... $\pm 2\%$ (2) Ceramic, plastic, and film capacitors of which capacitance are 10 pF or less. None ..... more than $\pm 5\%$ pF B ..... $\pm 0.1$ pF C ..... $\pm 0.25$ pF (3) Electrolytic, Trimmer Tolerance is not described.
Temperature characteristic (Ceramic capacitor)	None ..... SL For others, temperature characteristics are described. (For capacitors of 0.01 $\mu\text{F}$ and no indications are described as F.)



## 5-5. Inductor Indication

Unit	None ..... H μ ..... μH m ..... mH
Tolerance	None ..... ±5% B ..... ±0.1% C ..... ±0.25% D ..... ±0.5% F ..... ±1% G ..... ±2% K ..... ±10% M ..... ±20%
Type	PL ..... Peaking For other, model name is described.



## 5-6. Waveform and Voltage Measurement

- Measurement of waveform and voltage at each-section in the color circuits was conducted with sufficient service color bar signal being received and reproduced in normal conditions.
- Waveforms and voltage values for the remaining circuit were measured with a broadcasting signal normally received, so they may vary slightly according to the programs being received. Use them as a measure for servicing.
- All voltage values except the waveforms are expressed in DC and measured by a digital voltmeter.

3. If it is difficult to remove the part, temporarily stop the desoldering job and wait until temperature of the part lowers.  
Then, repeat steps 1 and 2.
4. Form leads of the replacement part (general part equivalent to the chip part) as shown in the figures and solder place. (Fig. 10)




Fig. 10

## 5-7. Chip Part Replacement

(Use spare part with wire leads connected.)

1. Hold a Chip part to be removed with tweezers and apply heat to the solder at one end of the part with a soldering iron. (Fig. 9)




Fig. 9

2. Apply heat to the solder at the other end of the part and remove it.

The heating time should be as short as possible so the excessive heat is not applied to foil patterns and the PC Board.

5. Mount the replacement part so that it does not touch any other parts. (Fig. 11)




Fig. 11

# SECTION 4

## PARTS LIST

### SAFETY PRECAUTION

The parts identified by  $\Delta$  mark are critical for safety. Replace only with part number specified.

The mounting position of replacement is to be identical with originals.

The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

### NOTICE

The part number must be used when ordering parts in order to assist in processing, be sure to include the model number and description.

Parts marked # are of chip type and mounted on original PC boards.

However, when they are placed for servicing works, use discrete parts listed on the parts list.

This parts list is based on the model V-804B. For V-854B different parts only are listed on the difference list.

In models V-804B, V-854B, two types of Main PC board assemblies are used.

20256360.SA or 20320670.S\* (\*: Optional character) is printed on each PC board. The PC board 20256360.SA is called Type A and the PC board 20320670.S\* is called Type B in this service manual.

When using the Type A PC board, AMP PC board assembly is used and when using the Type B PC board, Video 2 and Video 3 PC boards are used.

### ABBREVIATIONS

#### 1. Integrated circuit (IC)

#### 2. Capacitor (Cap)

- Capacitance Tolerance (for Nominal Capacitance more than 10pF)

Symbol	B	C	D	F	G	J	K	M	N
Tolerance %	$\pm 0.1$	$\pm 0.25$	$\pm 0.5$	$\pm 1$	$\pm 2$	$\pm 5$	$\pm 10$	$\pm 20$	$\pm 30$

Symbol	P	Q	T	U	V	W	X	Y	Z
Tolerance %	+100 0	+30 -10	+50 -10	+75 -10	+20 -10	+100 -10	+40 -20	+150 -10	+80 -20

Ex. 10 $\mu$ F J = 10 $\mu$ F  $\pm 5\%$

- Capacitance Tolerance (for Nominal Capacitance 10pF or less)

Symbol	B	C	D	F	G
Tolerance pF	$\pm 0.1$	$\pm 0.25$	$\pm 0.5$	$\pm 1$	$\pm 2$

Ex. 10pF G = 10pF  $\pm 2$ pF

#### 3. Resistor (Res)


- Resistance tolerance

Symbol	B	C	D	F	G	J	K	M
Tolerance %	$\pm 0.1$	$\pm 0.25$	$\pm 0.5$	$\pm 1$	$\pm 2$	$\pm 5$	$\pm 10$	$\pm 20$


Ex. 470  $\Omega$  J = 470 $\Omega$   $\pm 5\%$

#### 4. EXPLODED VIEWS


#### 4-1. Packing Assembly




#### 4-2. Remote Control Unit (V-804B)




### 4-3. Remote Control Unit (V-854B)




#### 4-4. Cabinet Assembly




## 4-5. Chassis Assembly



## 4-6. Mechanism Assembly (1)



## 4-7. Mechanism Assembly (2)



## 5. PARTS LIST

LOCATION NUMBER	PART NUMBER	DESCRIPTION	LOCATION NUMBER	PART NUMBER	DESCRIPTION
- MECHANICAL PARTS -			K370	70031423	Spring
0001C	70060940	Owners Manual English	K380	70031424	T Soft Brake Assy
0010C	70011743	Remote Control Unit	K390	70031426	Spring
0013C	70011442	Cable	K402	70031471	Drive Lever
0026F	70051180	Door	K410	70031427	Cam Slider
0042F	70051310	Cassette Door	K420	70031428	Spring
0044F	70051218	Spring	K430	70031472	Idle Up Down Lever
0120	72471082	Screw, 3x10mm	K440	70031473	Idle Kick Lever
△0195	70012039	Power Cord	K450	70031476	Idle Centering Lever
△0250	70051118	Front Panel	K470	70031477	Cam Lever
0260	72471082	Screw, 3x10mm	K480	70031430	FL Drive Slider
0270	70051199	Knob	K490	70031431	Cassette Holder Assy
0300	70051208	Insulator	K530	70031415	Drive Arm Assy
0310	70051209	Insulator	K550	70051150	Drive Lever Gear
9067C	70061025	Quick Reference English	K562	70031482	Arm Brake Lever
AT03	70108916	Battery Case	K564	70031440	Spring
B218	70031325	Center Holding Post	K570	70031441	Top Bracket
B410	70031394	Loading Drive Assy	K590	70031483	Door Open Lever
B424	70031396	Loading Motor Sub Assy	U190	70090480	P C Board Assy Pre Amp
B432	70031401	Cam Switch	U190A	70031520	Screw
B435	70031402	Loading Drive Unit	U501A	70070069	Screw
B440	70051147	Cam Gear			
B450	70031404	S Loading Assy			
B470	70031408	T Loading Assy			
B490	70031412	Loading Slider Assy			
B560	70031498	Capstan Motor Assy			
B570	70070028	Screw 2. 6x6mm			
B580	70031442	Reel Belt			
G001S	70031528	Cylinder Assy			
G010	70031444	Plate(Cylinder)			
G020	70031603	Screw 2. 6x4mm			
G021	70031488	Screw 2. 6x0. 4x5mm			
G030	70031445	Plate(Cylinder)			
G040	70031488	Screw 2. 6x0. 4x5mm			
G050	70031451	Slip Ring Assy			
G060	70031449	Screw			
G101	70031529	Upper Cylinder Assy			
G101A	70031521	Screw			
G101B	70031523	Coupling			
G102	70031526	Lower Cylinder Assy			
G410	70031348	Guide Sleeve			
G420	70031349	S Slider Assy			
G448	70031505	O Ring			
G450	70031360	T Slider Assy			
G480	70031365	ACE Head Assy			
G484	70031367	ACE Head Sub Assy			
G504	70031508	Spring			
G520	70031370	No. 9 Guide Lever Assy			
G530	70031443	FE Head			
G560	70031384	Pinch Lever Assy			
G580	70031390	Pinch Drive Assy			
G590	70031392	Spring			
G680	70031493	Cleaner Lever Assy			
K110	70031328	S Reel Assy			
K130	70031334	Washer			
K140	70031335	T Reel Assy			
K170	70031334	Washer			
K180	70031339	Idle Arm Assy			
K200	70031345	Center Gear Pulley			
K220	70031503	Washer			
K222	70031527	Washer			
K242	70031374	Tension Lever Sub Assy			
K252	70031376	Band Brake Sub Assy			
K254	70031377	Band Holder			
K260	70031378	Spring			
K270	70031379	Hook Lever			
K280	70031380	Hook Lever			
K290	70031381	Tension Drive Lever			
K320	70031466	Rec Inhibit Lever			
K330	70031420	S Main Brake Assy			
K340	70031421	T Main Brake Assy			
K350	70031422	Spring			
K360	70031469	S Soft Brake Lever			



LOCATION NUMBER	PART NUMBER	DESCRIPTION
--------------------	----------------	-------------

LOCATION NUMBER	PART NUMBER	DESCRIPTION
--------------------	----------------	-------------

DIFFERENCE LIST

V-854B

0001C	70060944	Owners Manual	English
0010C	70011738	Remote Control Unit	
0026F	70051179	Door	
0042F	70051322	Cassette Door	
0250	70051115	Front Panel	
0270	70051200	Knob, Shuttle	
0280	70051201	Knob, Jog	
0600	70061088	Packing(Bottom)	
0650	70061087	Packing(Top)	
9066C	70061024	Quick Reference	English
9067C	-----	Not Used	
AT03	70108952	Battery Case	
AT05	70108965	Top Cover	
G001S	70031518	Cylinder Assy	
G101	70031519	Upper Cylinder Assy	
G102	70031522	Lower Cylinder Assy	
U190	70090478	PC Board Assy	Pre Amp

LOCATION NUMBER	PART NUMBER	DESCRIPTION	LOCATION NUMBER	PART NUMBER	DESCRIPTION
- ELECTRICAL PARTS -			D901	A7150650	Diode
			D930	70011874	Diode, Zener
			D931	70011874	Diode, Zener
			DI01	70010180	Diode
					- COILS -
0005M	70090540	P C Board Assy Main (Type A)	L101	70011775	Coil, Peaking
		- INTEGRATED CIRCUITS -	L104	70011850	Coil, Peaking
IC101	70011942	IC	L105	23237972	Coil, Peaking
IC201	70011884	IC	L202	23238703	Coil, Peaking
IC231	70011890	IC	L203	23238704	Coil, Peaking
IC431	70011891	IC	L204	70011851	Coil, Peaking
IC501	70012120	IC	L231	70011463	Filter
IC502	70011801	IC	L232	70011541	Coil, Peaking
IC503	70011887	IC	L402	70011459	Coil, Peaking
IC504	70011892	IC	L431	70011463	Filter
IC505	70011808	IC	L433	70011776	Coil, Peaking
IC598	70011613	IC	L435	70011848	Coil, Peaking
IC599	70011893	IC	L505	70011464	Filter
IC701	70011806	IC	L506	70011464	Filter
IC803	70011905	IC	L507	70011464	Filter
IC821	70011803	IC	L508	70011464	Filter
IC920	70011898	IC	L520	70011459	Coil, Peaking
Q823	70011901	IC	L581	70011850	Coil, Peaking
		- TRANSISTORS -	L701	23237729	Coil, Peaking
Q211	A6335470	Transistor, Chip	L771	70011935	Coil
Q212	A6541130	Transistor, Chip	L775	70011852	Coil, Peaking
Q213	A6335470	Transistor, Chip	L781	70011936	Coil
Q214	A6541130	Transistor, Chip	L785	70011852	Coil, Peaking
Q215	A6541130	Transistor, Chip	L821	70011455	Coil, Choke
Q218	A6004040	Transistor, Chip	L822	70011455	Coil, Choke
Q235	A6335470	Transistor, Chip	L823	23238653	Coil, Peaking
Q240	A6004040	Transistor, Chip	L825	70011455	Coil, Choke
Q261	A6541130	Transistor, Chip	L826	70011464	Filter
Q262	A6004040	Transistor, Chip	L901	70011464	Filter
Q271	A6004040	Transistor, Chip			- CAPACITORS -
Q410	A6335470	Transistor, Chip	C101	24814103	Cap, Chip
Q435	A6335470	Transistor, Chip	C182	24287103	Cap, Chip
Q436	A6004040	Transistor, Chip	C103	24814103	Cap, Chip
Q437	A6335470	Transistor, Chip	C104	24783390	Cap, Chip
Q506	70011581	Transistor, Chip	C105	70041300	Cap, Electrolytic
Q507	70011581	Transistor, Chip	C106	70041038	Cap, Electrolytic
Q508	70011386	Transistor	C107	70041328	Cap, Chip
Q509	70011386	Transistor	C108	70041298	Cap, Electrolytic
Q510	A6004010	Transistor, Chip	C109	70041596	Cap, Chip
Q511	A6004010	Transistor, Chip	C110	24285103	Cap, Chip
Q513	A6541130	Transistor, Chip	C111	70041314	Cap, Electrolytic
Q514	70012032	Transistor, Chip	C112	70041562	Cap, Chip
Q771	A6319311	Transistor	C113	24092178	Cap, Chip
Q772	70011787	Transistor, Chip	C114	70041596	Cap, Chip
Q773	70011787	Transistor, Chip	C115	70041587	Cap, Chip
Q781	A6319311	Transistor	C116	24092178	Cap, Chip
Q802	70011877	Photo coupler	C117	24815102	Cap, Chip
Q822	70012031	Transistor	C118	70041528	Cap, OS
Q101	70010181	Transistor	C120	24783270	Cap, Chip
Q102	70010181	Transistor	C122	70041724	Cap, Chip
Q103	A6335470	Transistor, Chip	C201	24092178	Cap, Chip
Q104	A6335470	Transistor, Chip	C202	24783221	Cap, Chip
Q105	A6335470	Transistor, Chip	C204	70041038	Cap, Electrolytic
		- DIODES -	C205	24814103	Cap, Chip
D081	70010628	Diode, Zener	C206	70041570	Cap, Electrolytic
D503	70010153	Diode	C207	70041328	Cap, Chip
D507	23118486	Diode	C208	24783390	Cap, Chip
D508	23118486	Diode	C209	24783680	Cap, Chip
D509	70012002	Diode, Zener	C210	70041587	Cap, Chip
D512	23118486	Diode	C212	70041706	Cap, Chip
D596	A7160570	Diode	C213	70041328	Cap, Chip
D597	23118486	Diode	C214	24206010	Cap, Electrolytic
D803	70011880	Diode	C215	70041298	Cap, Electrolytic
D805	70011483	Diode	C216	70041298	Cap, Electrolytic
D806	70011482	Diode	C217	70041038	Cap, Electrolytic
D807	23118486	Diode	C218	70041038	Cap, Electrolytic
D808	70011488	Diode, Zener	C219	70041053	Cap, Electrolytic
D821	70011873	Diode	C221	70041328	Cap, Chip
D822	70011790	Diode	C222	70041570	Cap, Electrolytic
D823	70011789	Diode	C223	70041596	Cap, Chip
D824	70011481	Diode			

LOCATION NUMBER	PART NUMBER	DESCRIPTION		LOCATION NUMBER	PART NUMBER	DESCRIPTION	
C224	70041292	Cap, Electrolytic	100 $\mu$ F	M 6.3V	C530	70041596	Cap, Chip
C225	24774121	Cap, Chip	120pF	J 50V	C531	70041328	Cap, Chip
C226	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C532	24092178	Cap, Chip
C231	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C533	24092178	Cap, Chip
C232	70041328	Cap, Chip	100nF	Z 25V	C534	70041506	Cap, Electrolytic
C233	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C535	70041596	Cap, Chip
C234	70041578	Cap, Electrolytic	220nF	M 50V	C536	70041596	Cap, Chip
C235	70041328	Cap, Chip	100nF	Z 25V	C537	70041596	Cap, Chip
C236	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C538	70041596	Cap, Chip
C237	70041328	Cap, Chip	100nF	Z 25V	C539	70041589	Cap, Chip
C238	24774100	Cap, Chip	10pF	D 50V	C540	24774070	Cap, Chip
C239	70041328	Cap, Chip	100nF	Z 25V	C542	24814103	Cap, Chip
C261	70041328	Cap, Chip	100nF	Z 25V	C543	24092178	Cap, Chip
C263	70041596	Cap, Chip	10nF	K 50V	C544	24814103	Cap, Chip
C264	24774220	Cap, Chip	22pF	J 50V	C546	70041314	Cap, Electrolytic
C401	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C547	24814103	Cap, Chip
C402	70041530	Cap, Chip	330nF	Z 16V	C548	70041518	Cap, Electrolytic
C403	70041302	Cap, Electrolytic	22 $\mu$ F	M 6.3V	C549	70041314	Cap, Electrolytic
C404	24815153	Cap, Chip	0.015 $\mu$ F	K 50V	C552	24093962	Cap, Variable
C405	24774150	Cap, Chip	15pF	J 50V	C560	70041314	Cap, Electrolytic
C406	24815102	Cap, Chip	1000pF	K 50V	C561	70041314	Cap, Electrolytic
C407	70041504	Cap, Electrolytic	470nF	M 50V	C562	24092178	Cap, Chip
C409	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C575	24815472	Cap, Chip
C410	24781300	Cap, Chip	30pF	J 50V	C576	70040991	Cap, Chip
C411	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C580	24783270	Cap, Chip
C412	70041328	Cap, Chip	100nF	Z 25V	C581	70041684	Cap, Ceramic
C413	70041503	Cap, Electrolytic	100nF	M 50V	C597	70041573	Cap, Electrolytic
C414	24815153	Cap, Chip	0.015 $\mu$ F	K 50V	C701	70041706	Cap, Chip
C415	70041561	Cap, Chip	330nF	Z 25V	C702	24815182	Cap, Chip
C416	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C703	70041504	Cap, Electrolytic
C417	70040873	Cap, Plastic	82nF	J 63V	C704	24783101	Cap, Chip
C419	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C705	70041596	Cap, Chip
C420	70041016	Cap, Chip	47pF	J 50V	C706	70041038	Cap, Electrolytic
C421	70041401	Cap, Chip	200pF	J 50V	C707	70041004	Cap, Chip
C422	70041533	Cap, Chip	47nF	K 50V	C708	70041301	Cap, Electrolytic
C423	70041723	Cap, Chip	8pF	D 50V	C709	70041328	Cap, Chip
C431	24815472	Cap, Chip	4700pF	K 50V	C715	70041655	Cap, Chip
C432	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C716	70041655	Cap, Chip
C433	70041328	Cap, Chip	100nF	Z 25V	C717	70041519	Cap, Electrolytic
C434	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C726	24783101	Cap, Chip
C435	70041328	Cap, Chip	100nF	Z 25V	C727	24783101	Cap, Chip
C436	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C728	70041401	Cap, Chip
C437	24815102	Cap, Chip	1000pF	K 50V	C740	70041328	Cap, Chip
C440	70041328	Cap, Chip	100nF	Z 25V	C771	70041113	Cap, Electrolytic
C441	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C773	70041596	Cap, Chip
C442	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C774	70041698	Cap, Chip
C443	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C775	70041569	Cap, Plastic
C444	24774220	Cap, Chip	22pF	J 50V	C777	24214221	Cap, Ceramic
C445	70041323	Cap, Chip	8pF	C 50V	C781	70041113	Cap, Electrolytic
C446	24783270	Cap, Chip	27pF	J 50V	C782	70041596	Cap, Chip
C447	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C783	70041596	Cap, Chip
C448	24774330	Cap, Chip	33pF	J 50V	C784	70041596	Cap, Chip
C449	70041328	Cap, Chip	100nF	Z 25V	C785	70041568	Cap, Plastic
C501	24815182	Cap, Chip	1800pF	K 50V	$\Delta$ C801	70041687	Cap, Plastic
C505	24815182	Cap, Chip	1800pF	K 50V	$\Delta$ C802	70041584	Cap, Ceramic
C508	70041323	Cap, Chip	8pF	C 50V	$\Delta$ C803	70041584	Cap, Ceramic
C509	24774100	Cap, Chip	10pF	D 50V	$\Delta$ C804	70041687	Cap, Plastic
C510	24774100	Cap, Chip	10pF	D 50V	$\Delta$ C805	70041576	Cap, Electrolytic
C511	24815222	Cap, Chip	2200pF	K 50V	C806	70041499	Cap, Plastic
C512	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C807	24538184	Cap, Plastic
C513	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C808	70041184	Cap, Chip
C515	24783151	Cap, Chip	150pF	J 50V	C809	70041370	Cap, Ceramic
C516	70041328	Cap, Chip	100nF	Z 25V	$\Delta$ C811	70041320	Cap, Ceramic
C517	70041328	Cap, Chip	100nF	Z 25V	C812	70040729	Cap, Chip
C518	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C813	70041370	Cap, Ceramic
C519	24783101	Cap, Chip	100pF	J 50V	$\Delta$ C821	70041510	Cap, Electrolytic
C520	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C822	70041511	Cap, Electrolytic
C521	24783101	Cap, Chip	100pF	J 50V	$\Delta$ C823	70041508	Cap, Electrolytic
C522	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C824	70041509	Cap, Electrolytic
C523	24815102	Cap, Chip	1000pF	K 50V	$\Delta$ C825	70041507	Cap, Electrolytic
C524	24815102	Cap, Chip	1000pF	K 50V	C826	70041730	Cap, Electrolytic
C525	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C827	70041730	Cap, Electrolytic
C526	70041515	Cap, Electrolytic	33 $\mu$ F	M 25V	C828	70041730	Cap, Electrolytic
C528	70041328	Cap, Chip	100nF	Z 25V	C829	70041509	Cap, Electrolytic
C529	70041596	Cap, Chip	10nF	K 50V	C830	70041517	Cap, Electrolytic
							10nF
							K 50V
							100nF
							Z 25V
							0.1 $\mu$ F
							K 25V
							0.1 $\mu$ F
							K 25V
							10 $\mu$ F
							M 25V
							10nF
							K 50V
							10nF
							K 50V
							10nF
							K 50V
							10nF
							K 50V
							8pF
							D 50V
							7pF
							D 50V
							0.01 $\mu$ F
							Z 50V
							0.1 $\mu$ F
							K 25V
							0.01 $\mu$ F
							Z 50V
							47 $\mu$ F
							M 6.3V
							0.01 $\mu$ F
							Z 50V
							22 $\mu$ F
							M 35V
							47 $\mu$ F
							M 6.3V
							20pF
							M 6.3V
							47 $\mu$ F
							M 6.3V
							47 $\mu$ F
							0.1 $\mu$ F
							K 25V
							4700pF
							K 50V
							4.7nF
							M 50V
							27pF
							J 50V
							82pF
							J 50V
							0.001F
							M 6.3V
							470pF
							J 50V
							1800pF
							K 50V
							470nF
							M 50V
							100pF
							J 50V
							10nF
							K 50V
							10 $\mu$ F
							M 16V
							680pF
							J 50V
							22 $\mu$ F
							M 16V
							100nF
							Z 25V
							15nF
							K 50V
							15nF
							K 50V
							4.7 $\mu$ F
							M 35V
							100pF
							J 50V
							100pF
							J 50V
							200pF
							J 50V
							100nF
							Z 25V
							47 $\mu$ F
							M 16V
							10nF
							K 50V
							18nF
							K 50V
							100nF
							J 100V
							220pF
							K 500V
							47 $\mu$ F
							M 16V
							10nF
							K 50V
							10nF
							K 50V
							27nF
							J 100V
							100nF
							M 250V
							220pF
							K 400V
							220pF
							K 400V
							100nF
							M 250V
							470 $\mu$ F
							M 450V
							33nF
							J 630V
							0.18 $\mu$ F
							J 50V
							12nF
							K 50V
							100pF
							K 1kV
							2.2F
							M 125V
							1nF
							J 50V
							100pF
							K 1kV
							820 $\mu$ F
							M 16V
							220 $\mu$ F
							M 16V
							1mF
							M 10V
							100 $\mu$ F

LOCATION NUMBER	PART NUMBER	DESCRIPTION	LOCATION NUMBER	PART NUMBER	DESCRIPTION	
C831	70041517	Cap, Electrolytic 22 $\mu$ F	M 50V	R232	24872222 Res, Chip 2.2k $\Omega$	J 1/16W
C832	24539224	Cap, Plastic 0.22 $\mu$ F	J 50V	R233	24872122 Res, Chip 1.2k $\Omega$	J 1/16W
△C835	70041575	Cap, Electrolytic 470 $\mu$ F	M 35V	R240	24872332 Res, Chip 3.3k $\Omega$	J 1/16W
C836	70041574	Cap, Electrolytic 100 $\mu$ F	M 35V	R241	24872473 Res, Chip 47k $\Omega$	J 1/16W
C837	24538334	Cap, Plastic 0.33 $\mu$ F	J 50V	R261	24872124 Res, Chip 120k $\Omega$	J 1/16W
C838	70041731	Cap, Electrolytic 47 $\mu$ F	M 16V	R262	24871223 Res, Chip 22k $\Omega$	J 1/8W
C842	70041729	Cap, Electrolytic 10 $\mu$ F	M 16V	R263	70041096 Chip Jumper	
C920	70041504	Cap, Electrolytic 470nF	M 50V	R264	70041096 Chip Jumper	
C921	70041504	Cap, Electrolytic 470nF	M 50V	R271	24871104 Res, Chip 100k $\Omega$	J 1/8W
C922	70041504	Cap, Electrolytic 470nF	M 50V	R272	70041096 Chip Jumper	
C923	70041504	Cap, Electrolytic 470nF	M 50V	R401	24872333 Res, Chip 33k $\Omega$	J 1/16W
C924	70041504	Cap, Electrolytic 470nF	M 50V	R402	24872102 Res, Chip 1k $\Omega$	J 1/16W
C925	70041504	Cap, Electrolytic 470nF	M 50V	R403	24872222 Res, Chip 2.2k $\Omega$	J 1/16W
C926	70041583	Cap, Electrolytic 470nF	M 50V	R405	24872333 Res, Chip 33k $\Omega$	J 1/16W
C928	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R406	24872473 Res, Chip 47k $\Omega$	J 1/16W
C929	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R415	24872102 Res, Chip 1k $\Omega$	J 1/16W
C930	24591103	Cap, Plastic 0.01 $\mu$ F	J 50V	R416	24872105 Res, Chip 1M $\Omega$	J 1/16W
C931	24591103	Cap, Plastic 0.01 $\mu$ F	J 50V	R420	70041169 Res, Chip 68 $\Omega$	J 1/10W
C932	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R429	70041096 Chip Jumper	
C933	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R431	24872821 Res, Chip 820 $\Omega$	J 1/16W
C934	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R432	24872222 Res, Chip 2.2k $\Omega$	J 1/16W
C935	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R433	24872752 Res, Chip 7.5k $\Omega$	J 1/16W
C936	24591103	Cap, Plastic 0.01 $\mu$ F	J 50V	R434	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
C937	24591103	Cap, Plastic 0.01 $\mu$ F	J 50V	R436	24872331 Res, Chip 330 $\Omega$	J 1/16W
C938	70041301	Cap, Electrolytic 22 $\mu$ F	M 16V	R437	24872102 Res, Chip 1k $\Omega$	J 1/16W
C939	70041301	Cap, Electrolytic 22 $\mu$ F	M 16V	R438	24872122 Res, Chip 1.2k $\Omega$	J 1/16W
C940	70041298	Cap, Electrolytic 1 $\mu$ F	M 50V	R439	24872123 Res, Chip 12k $\Omega$	J 1/16W
C941	70041298	Cap, Electrolytic 1 $\mu$ F	M 50V	R440	24872123 Res, Chip 12k $\Omega$	J 1/16W
C946	24815562	Cap, Chip 5600pF	K 50V	R441	24872122 Res, Chip 1.2k $\Omega$	J 1/16W
C947	24815562	Cap, Chip 5600pF	K 50V	R443	24872471 Res, Chip 470 $\Omega$	J 1/16W
C960	24794331	Cap, Electrolytic 330 $\mu$ F	M 16V	R501	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
C963	70041301	Cap, Electrolytic 22 $\mu$ F	M 16V	R502	24872821 Res, Chip 820 $\Omega$	J 1/16W
C964	70041577	Cap, Electrolytic 330 $\mu$ F	M 16V	R503	24872471 Res, Chip 470 $\Omega$	J 1/16W
C968	70041578	Cap, Electrolytic 220nF	M 50V	R504	24872224 Res, Chip 220k $\Omega$	J 1/16W
C969	70041328	Cap, Chip 100nF	Z 25V	R505	24872684 Res, Chip 680k $\Omega$	J 1/16W
C970	70041535	Cap, Chip 47nF	Z 50V	R506	70041554 Res, Chip 4.7M $\Omega$	K 1/16W
C971	70041572	Cap, Electrolytic 330 $\mu$ F	M 10V	R507	70041554 Res, Chip 4.7M $\Omega$	K 1/16W
C972	70041596	Cap, Chip 10nF	K 50V	R508	24872182 Res, Chip 1.8k $\Omega$	J 1/16W
C973	70041038	Cap, Electrolytic 10 $\mu$ F	M 16V	R509	24872563 Res, Chip 56k $\Omega$	J 1/16W
C101	24814103	Cap, Chip 0.01 $\mu$ F	Z 50V	R510	24872182 Res, Chip 1.8k $\Omega$	J 1/16W
C102	24814103	Cap, Chip 0.01 $\mu$ F	Z 50V	R511	24872563 Res, Chip 56k $\Omega$	J 1/16W
C103	24815102	Cap, Chip 1000pF	K 50V	R512	24871102 Res, Chip 1k $\Omega$	J 1/8W
- RESISTORS -				R513	24871102 Res, Chip 1k $\Omega$	J 1/8W
R092	24871202	Res, Chip 2k $\Omega$	J 1/8W	R514	24872473 Res, Chip 47k $\Omega$	J 1/16W
R093	24871202	Res, Chip 2k $\Omega$	J 1/8W	R515	24872473 Res, Chip 47k $\Omega$	J 1/16W
R101	24872222	Res, Chip 2.2k $\Omega$	J 1/16W	R516	24872912 Res, Chip 9.1k $\Omega$	J 1/16W
R102	24872122	Res, Chip 1.2k $\Omega$	J 1/16W	R517	24872103 Res, Chip 10k $\Omega$	J 1/16W
R104	24872124	Res, Chip 120k $\Omega$	J 1/16W	R518	24872163 Res, Chip 16k $\Omega$	J 1/16W
R105	24871680	Res, Chip 68k $\Omega$	J 1/8W	R519	24872114 Res, Chip 110k $\Omega$	J 1/16W
R106	70041609	Res, Chip 9.1k $\Omega$	F 1/8W	R520	24872114 Res, Chip 110k $\Omega$	J 1/16W
R110	24871101	Res, Chip 100 $\Omega$	J 1/8W	R521	70041598 Res, Carbon 1 $\Omega$	J 1/6W
△R111	70041541	Res, Fusible 8.2 $\Omega$	J 1/2W	R522	24871201 Res, Chip 200 $\Omega$	J 1/8W
R112	24872821	Res, Chip 820 $\Omega$	J 1/16W	R525	24871103 Res, Chip 10k $\Omega$	J 1/8W
R201	24872331	Res, Chip 330 $\Omega$	J 1/16W	R526	24871103 Res, Chip 10k $\Omega$	J 1/8W
R202	24872512	Res, Chip 5.1k $\Omega$	J 1/16W	R527	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R203	24872102	Res, Chip 1k $\Omega$	J 1/16W	R528	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R204	70041613	Res, Chip 2M $\Omega$	J 1/10W	R529	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R205	24872122	Res, Chip 1.2k $\Omega$	J 1/16W	R530	24872222 Res, Chip 2.2k $\Omega$	J 1/16W
R206	24872272	Res, Chip 2.7k $\Omega$	J 1/16W	R531	24872392 Res, Chip 3.9k $\Omega$	J 1/16W
R207	24872152	Res, Chip 1.5k $\Omega$	J 1/16W	R532	24872222 Res, Chip 2.2k $\Omega$	J 1/16W
R208	24872271	Res, Chip 270 $\Omega$	J 1/16W	R533	24872103 Res, Chip 10k $\Omega$	J 1/16W
R209	24872222	Res, Chip 2.2k $\Omega$	J 1/16W	R534	24872303 Res, Chip 30k $\Omega$	J 1/16W
R210	24872152	Res, Chip 1.5k $\Omega$	J 1/16W	R535	24872473 Res, Chip 47k $\Omega$	J 1/16W
R211	24872681	Res, Chip 680 $\Omega$	J 1/16W	R536	24871102 Res, Chip 1k $\Omega$	J 1/8W
R212	24872101	Res, Chip 100 $\Omega$	J 1/16W	R537	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R213	24872822	Res, Chip 8.2k $\Omega$	J 1/16W	R538	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R214	24872105	Res, Chip 1M $\Omega$	J 1/16W	R548	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R215	24872105	Res, Chip 1M $\Omega$	J 1/16W	R549	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R216	24872101	Res, Chip 100 $\Omega$	J 1/16W	R560	70040321 Res, Carbon 4.7k $\Omega$	J 1/8W
R217	24872681	Res, Chip 680 $\Omega$	J 1/16W	R561	24871102 Res, Chip 1k $\Omega$	J 1/8W
R218	24872332	Res, Chip 3.3k $\Omega$	J 1/16W	R562	24871182 Res, Chip 1.8k $\Omega$	J 1/8W
R221	24872101	Res, Chip 100 $\Omega$	J 1/16W	R563	24872472 Res, Chip 4.7k $\Omega$	J 1/16W
R222	24871182	Res, Chip 1.8k $\Omega$	J 1/8W	R566	24366272 Res, Carbon 2.7k $\Omega$	J 1/6W
R226	24872182	Res, Chip 1.8k $\Omega$	J 1/16W	R567	24366272 Res, Carbon 2.7k $\Omega$	J 1/6W
R231	24872222	Res, Chip 2.2k $\Omega$	J 1/16W	R568	24366202 Res, Carbon 2k $\Omega$	J 1/6W

LOCATION NUMBER	PART NUMBER	DESCRIPTION						
R569	24366202	Res, Carbon	2kΩ	J 1/6W				
R570	24872103	Res, Chip	10kΩ	J 1/16W				
R571	24872103	Res, Chip	10kΩ	J 1/16W				
R572	24871472	Res, Chip	4.7kΩ	J 1/8W				
R574	70041096	Chip Jumper						
R575	24872512	Res, Chip	5.1kΩ	J 1/16W				
△R591	70041605	Res, Fusible	18Ω	J 1/4W				
R592	24872472	Res, Chip	4.7kΩ	J 1/16W				
R593	24366102	Res, Carbon	1kΩ	J 1/6W				
R598	70041136	Res, Chip	300Ω	J 1/8W				
R599	24871103	Res, Chip	10kΩ	J 1/8W				
R601	24872681	Res, Chip	680Ω	J 1/16W				
R615	24871222	Res, Chip	2.2kΩ	J 1/8W				
R621	24871104	Res, Chip	100kΩ	J 1/8W				
R622	24871104	Res, Chip	100kΩ	J 1/8W				
R701	24872473	Res, Chip	47kΩ	J 1/16W				
R702	24872182	Res, Chip	1.8kΩ	J 1/16W				
R703	24872334	Res, Chip	330kΩ	J 1/16W				
R704	24872181	Res, Chip	180Ω	J 1/16W				
R705	24872113	Res, Chip	11kΩ	J 1/16W				
R706	24872562	Res, Chip	5.6kΩ	J 1/16W				
R707	24872105	Res, Chip	1MΩ	J 1/16W				
R716	24872181	Res, Chip	180Ω	J 1/16W				
R717	70041096	Chip Jumper						
R718	24872562	Res, Chip	5.6kΩ	J 1/16W				
R719	24871273	Res, Chip	27kΩ	J 1/8W				
R733	24872104	Res, Chip	100kΩ	J 1/16W				
R734	24872104	Res, Chip	100kΩ	J 1/16W				
R735	24872513	Res, Chip	51kΩ	J 1/16W				
R740	24872393	Res, Chip	39kΩ	J 1/16W				
R741	24872273	Res, Chip	27kΩ	J 1/16W				
R771	70041552	Res, Chip	3.3Ω	J 1/16W				
R772	24872123	Res, Chip	12kΩ	J 1/16W				
R773	24872101	Res, Chip	100Ω	J 1/16W				
R774	24871339	Res, Chip	3.3Ω	J 1/8W				
R775	24872152	Res, Chip	1.5kΩ	J 1/16W				
R777	24871152	Res, Chip	1.5kΩ	J 1/8W				
R782	24872822	Res, Chip	8.2kΩ	J 1/16W				
R783	24872101	Res, Chip	100Ω	J 1/16W				
R784	24871229	Res, Chip	2.2Ω	J 1/8W				
R789	70041096	Chip Jumper						
R790	24872473	Res, Chip	47kΩ	J 1/16W				
R793	24872153	Res, Chip	15kΩ	J 1/16W				
R804	24871151	Res, Chip	150Ω	J 1/8W				
R805	70041606	Res, Oxide Metal	39kΩ	J 2W				
R806	70041607	Res, Oxide Metal	560Ω	J 2W				
R807	70041608	Res, Oxide Metal	68Ω	J 2W				
R808	70041136	Res, Chip	300Ω	J 1/8W				
△R810	70041716	Res, Oxide Metal	0.39Ω	J 1/2W				
R813	70041612	Res, Carbon	620kΩ	J 1/2W				
R814	24871101	Res, Chip	100Ω	J 1/8W				
R820	24871202	Res, Chip	2kΩ	J 1/8W				
R821	24871102	Res, Chip	1kΩ	J 1/8W				
R920	24872183	Res, Chip	18kΩ	J 1/16W				
R921	24872183	Res, Chip	18kΩ	J 1/16W				
R922	24872273	Res, Chip	27kΩ	J 1/16W				
R923	24872273	Res, Chip	27kΩ	J 1/16W				
R924	24872273	Res, Chip	27kΩ	J 1/16W				
R925	24872273	Res, Chip	27kΩ	J 1/16W				
R926	24872273	Res, Chip	27kΩ	J 1/16W				
R927	24872273	Res, Chip	27kΩ	J 1/16W				
R928	24872333	Res, Chip	33kΩ	J 1/16W				
R929	24872333	Res, Chip	33kΩ	J 1/16W				
R930	24872273	Res, Chip	27kΩ	J 1/16W				
R931	24872273	Res, Chip	27kΩ	J 1/16W				
R932	24872102	Res, Chip	1kΩ	J 1/16W				
R936	70041096	Chip Jumper						
R938	70041096	Chip Jumper						
R942	24872471	Res, Chip	470Ω	J 1/16W				
R943	24872471	Res, Chip	470Ω	J 1/16W				
R946	24872391	Res, Chip	390Ω	J 1/16W				
R947	24872391	Res, Chip	390Ω	J 1/16W				
R963	24872121	Res, Chip	120Ω	J 1/16W				
R964	24872121	Res, Chip	120Ω	J 1/16W				
R970	24872273	Res, Chip	27kΩ	J 1/16W				
R973	70041096	Chip Jumper						
RI01	24871303	Res, Chip	30kΩ	J 1/8W				
RI02	24871223	Res, Chip	22kΩ	J 1/8W				
RI03	24872182	Res, Chip	1.8kΩ	J 1/16W				
RI05	24872332	Res, Chip	3.3kΩ	J 1/16W				
RI06	24871151	Res, Chip	150Ω	J 1/8W				
RI07	24871123	Res, Chip	12kΩ	J 1/8W				
RI08	24872123	Res, Chip	12kΩ	J 1/16W				
RI09	24871202	Res, Chip	2kΩ	J 1/8W				
RI10	24871202	Res, Chip	2kΩ	J 1/8W				
RI11	24871202	Res, Chip	2kΩ	J 1/8W				
RI12	24872102	Res, Chip	1kΩ	J 1/16W				
RI13	24872102	Res, Chip	1kΩ	J 1/16W				
RI14	24872332	Res, Chip	3.3kΩ	J 1/16W				
RI15	24871103	Res, Chip	10kΩ	J 1/8W				
RJ05	70041093	Chip Jumper						
RJ06	70041093	Chip Jumper						
RJ11	70041096	Chip Jumper						
RJ12	70041096	Chip Jumper						
RJ13	70041096	Chip Jumper						
RJ15	70041096	Chip Jumper						
RJ16	70041096	Chip Jumper						
RJ21	70041093	Chip Jumper						
RJ22	70041093	Chip Jumper						
RJ23	70041093	Chip Jumper						
RJ24	70041093	Chip Jumper						
RJ27	70041093	Chip Jumper						
RJ28	70041093	Chip Jumper						
RJ30	70041096	Chip Jumper						
RJ34	70041093	Chip Jumper						
RJ35	70041093	Chip Jumper						
RJ39	70041096	Chip Jumper						
RJ42	70041096	Chip Jumper						
RJ43	70041093	Chip Jumper						
RJ44	70041093	Chip Jumper						
RJ52	70041093	Chip Jumper						
RJ54	70041093	Chip Jumper						
RJ80	70041093	Chip Jumper						
RJ81	70041093	Chip Jumper						
RJ90	70041093	Chip Jumper						
△RF826	70041604	Res, Fusible	1.5Ω	J 1/4W				
△RF827	70041603	Res, Fusible	2.7Ω	J 1/2W				
△RF828	70041602	Res, Fusible	2.2Ω	J 1/2W				
		- MISCELLANEOUS -						
0052M	70070025	Screw	3x8mm					
△F801	70011866	Fuse	1.6A, 250V					
F801A	23165102	Fuse Holder						
P102	23164506	Plug 2P						
P802A	70060762	Eyelet						
S102	70011826	Switch, Push						
△T801	70011769	Coil, Line Filter	TRF3192					
△T802	70011847	Poewr Transformer						
X401	70011860	Crystal	4.43MHz					
X501	70011861	Crystal	16MHz					
X502	70010116	Crystal, 32kHz						
X503	70011859	Crystal	17.734MHz					
Z502	70031317	Stator						
△Z801	70011781	IC Protector	ICP-N10					
△Z811	70011864	Fuse	3.15A, 125V					
△Z812	70011865	Fuse	4.0A, 125V					
△Z821	70011781	IC Protector	ICP-N10					
Z822	70011768	DC-DC Converter						
Z101	70011793	Photo Interrupter	GP1S562					
Z102	70011793	Photo Interrupter	GP1S562					
Z110	70011828	Hall Sensor	HW300B					
■0005M	70090607	P C Board Assy	Main (Type B)					
		- INTEGRATED CIRCUITS -						
IC101	70011942	IC	TA8894AF					
IC201	70011884	IC	TA8892N					
IC218	70012107	IC	1MH6					
IC264	70012118	IC	1M21					
IC266	70012107	IC	1MH6					
IC416	70012107	IC	1MH6					
IC418	70012107	IC	1MH6					

LOCATION NUMBER	PART NUMBER	DESCRIPTION		LOCATION NUMBER	PART NUMBER	DESCRIPTION	
IC501	70012120	IC	TMP90CR74DF-7328	L507	70011464	Filter	ZBF253D-00F
IC502	70011801	IC	TA7267BP	L508	70011464	Filter	ZBF253D-00F
IC503	70011887	IC	TB6515AP	L520	70011459	Coil, Peaking	
IC504	70011892	IC	ST24C04	L581	70012113	Coil, Peaking	
IC505	70011808	IC	PST7032MT	L701	23237729	Coil, Peaking	TRF4822AP
IC598	70011613	IC	AN7805	L771	70011935	Coil	
IC599	70011893	IC	PST7045MT	L775	70011852	Coil, Peaking	
IC701	70011806	IC	BA7755	L781	70011936	Coil	
IC803	70011905	IC	STR-D6802	L785	70011852	Coil, Peaking	
IC821	70011803	IC	LA5611	L821	70011455	Coil, Choke	
IC920	70011898	IC	TA8863AF	L822	70011455	Coil, Choke	
Q823	70011901	IC	PQ12RF1	L823	23238653	Coil, Peaking	TRF4470AI
		- TRANSISTORS -		L825	70011455	Coil, Choke	
Q211	A6335470	Transistor, Chip	2SC2712Y-R	L826	70011464	Filter	ZBF253D-00F
Q212	A6541130	Transistor, Chip	2SA1162Y-R	L901	70011464	Filter	ZBF253D-00F
Q213	A6335470	Transistor, Chip	2SC2712Y-R	L975	70011851	Coil, Peaking	
Q214	A6541130	Transistor, Chip	2SA1162Y-R			- CAPACITORS -	
Q215	A6541130	Transistor, Chip	2SA1162Y-R	C101	24814103	Cap, Chip	0.01 $\mu$ F Z 50V
Q261	A6541130	Transistor, Chip	2SA1162Y-R	C102	24814103	Cap, Chip	0.01 $\mu$ F Z 50V
Q262	A6004040	Transistor, Chip	RN1404	C103	24814103	Cap, Chip	0.01 $\mu$ F Z 50V
Q410	A6335470	Transistor, Chip	2SC2712Y-R	C104	24783390	Cap, Chip	39pF J 50V
Q417	A6004040	Transistor, Chip	RN1404	C105	70041300	Cap, Electrolytic	0.47F M 50V
Q506	70011581	Transistor, Chip	DTC114EK	C106	70041038	Cap, Electrolytic	10 $\mu$ F M 16V
Q507	70011581	Transistor, Chip	DTC114EK	C107	70041328	Cap, Chip	100nF Z 25V
Q508	70011386	Transistor	2SA1020-Y	C108	70041298	Cap, Electrolytic	1 $\mu$ F M 50V
Q509	70011386	Transistor	2SA1020-Y	C109	70041596	Cap, Chip	10nF K 50V
Q510	A6004010	Transistor, Chip	RN1401	C110	24285103	Cap, Chip	0.01 $\mu$ F K 50V
Q511	A6004010	Transistor, Chip	RN1401	C111	70041314	Cap, Electrolytic	47 $\mu$ F M 6.3V
Q513	A6541130	Transistor, Chip	2SA1162Y-R	C112	70041562	Cap, Chip	100nF Z 50V
Q514	70012032	Transistor, Chip	2SA1162GR	C113	24092178	Cap, Chip	0.1 $\mu$ F K 25V
Q771	A6319311	Transistor	2SC1959-Y	C114	70041596	Cap, Chip	10nF K 50V
Q772	70011787	Transistor, Chip	2SC2411KQ	C115	70041863	Cap, Chip	560pF J 50V
Q773	70011787	Transistor, Chip	2SC2411KQ	C116	24092178	Cap, Chip	0.1 $\mu$ F K 25V
Q781	A6319311	Transistor	2SC1959-Y	C117	24815102	Cap, Chip	1000pF K 50V
△Q802	70011877	Photo coupler	PC120FY2	C118	70041528	Cap, OS	1 $\mu$ F M 16V
Q822	70012031	Transistor	KTD2092	C120	24783270	Cap, Chip	27pF J 50V
Q101	70010181	Transistor	PT493F	C122	70041269	Cap, Chip	220pF J 50V
Q102	70010181	Transistor	PT493F	C201	24092178	Cap, Chip	0.1 $\mu$ F K 25V
Q103	A6335470	Transistor, Chip	2SC2712Y-R	C202	24783221	Cap, Chip	220pF J 50V
Q104	A6335470	Transistor, Chip	2SC2712Y-R	C204	70041038	Cap, Electrolytic	10 $\mu$ F M 16V
Q105	A6335470	Transistor, Chip	2SC2712Y-R	C205	24814103	Cap, Chip	0.01 $\mu$ F Z 50V
		- DIODES -		C206	70041570	Cap, Electrolytic	100 $\mu$ F M 10V
D081	70010628	Diode, Zener	ZTK338	C207	70041328	Cap, Chip	100nF Z 25V
D503	70010153	Diode	1N4148	C208	24783390	Cap, Chip	39pF J 50V
D507	23118486	Diode	ERA15-02	C209	24783680	Cap, Chip	68pF J 50V
D508	23118486	Diode	ERA15-02	C210	70041863	Cap, Chip	560pF J 50V
D509	70012002	Diode, Zener	MTZJ7.5B	C212	70041706	Cap, Chip	470pF J 50V
D512	23118486	Diode	ERA15-02	C213	70041328	Cap, Chip	100nF Z 25V
D596	A7160570	Diode	1SS176	C214	24206010	Cap, Electrolytic	1 $\mu$ F M 50V
D597	23118486	Diode	ERA15-02	C215	70041298	Cap, Electrolytic	1 $\mu$ F M 50V
△D803	70011880	Diode	SIWBA60	C216	70041298	Cap, Electrolytic	1 $\mu$ F M 50V
D805	70011483	Diode	AG01	C217	70041038	Cap, Electrolytic	10 $\mu$ F M 16V
D806	70011482	Diode	RU1P	C218	70041038	Cap, Electrolytic	10 $\mu$ F M 16V
D807	23118486	Diode	ERA15-02	C219	70041053	Cap, Electrolytic	4.7 $\mu$ F M 35V
D808	70011488	Diode, Zener	ZPD5V1	C221	70041328	Cap, Chip	100nF Z 25V
△D821	70011873	Diode	RU4Z	C222	70041570	Cap, Electrolytic	100 $\mu$ F M 10V
△D822	70011790	Diode	RU2YX	C223	70041596	Cap, Chip	10nF K 50V
D823	70011789	Diode	1SS136	C224	70041292	Cap, Electrolytic	100 $\mu$ F M 6.3V
△D824	70011481	Diode	EL1Z	C225	24774121	Cap, Chip	120pF J 50V
D901	A7150650	Diode, Chip	1SS184	C226	24092178	Cap, Chip	0.1 $\mu$ F K 25V
D930	70011874	Diode, Zener	ZPD15	C261	70041328	Cap, Chip	100nF Z 25V
D931	70011874	Diode, Zener	ZPD15	C262	70041864	Cap, Chip	24pF J 50V
DI01	70010180	Diode		C263	70041596	Cap, Chip	10nF K 50V
		- COILS -		C264	24774220	Cap, Chip	22pF J 50V
L101	70011775	Coil, Peaking		C265	24774070	Cap, Chip	7pF D 50V
L104	70011850	Coil, Peaking		C266	70040239	Cap, Ceramic, Chip	18pF J 50V
L105	70012110	Coil, Peaking		C267	24783470	Cap, Chip	47pF J 50V
L202	23238703	Coil, Peaking	TRF4820AJ	C401	70041298	Cap, Electrolytic	1 $\mu$ F M 50V
L203	23238704	Coil, Peaking	TRF4680AJ	C402	70041530	Cap, Chip	330nF Z 16V
L204	70011851	Coil, Peaking		C403	70041302	Cap, Electrolytic	22 $\mu$ F M 6.3V
L208	70012111	Coil, Peaking		C404	24815153	Cap, Chip	0.015 $\mu$ F K 50V
L209	70012112	Coil, Peaking		C405	24774150	Cap, Chip	15pF J 50V
L402	70011459	Coil, Peaking		C406	24815102	Cap, Chip	1000pF K 50V
L505	70011464	Filter	ZBF253D-00F	C407	70041504	Cap, Electrolytic	470nF M 50V
L506	70011464	Filter	ZBF253D-00F	C409	24814103	Cap, Chip	0.01 $\mu$ F Z 50V

LOCATION NUMBER	PART NUMBER	DESCRIPTION			LOCATION NUMBER	PART NUMBER	DESCRIPTION		
C410	24781300	Cap, Chip	30pF	J 50V	C717	70041519	Cap, Electrolytic	4.7 $\mu$ F	M 35V
C411	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C726	24783101	Cap, Chip	100pF	J 50V
C412	70041328	Cap, Chip	100nF	Z 25V	C727	24783101	Cap, Chip	100pF	J 50V
C413	70041503	Cap, Electrolytic	100nF	M 50V	C728	70041401	Cap, Chip	200pF	J 50V
C414	24815153	Cap, Chip	0.015 $\mu$ F	K 50V	C740	70041328	Cap, Chip	100nF	Z 25V
C415	70041156	Cap, Chip	330nF	Z 25V	C771	70041113	Cap, Electrolytic	47 $\mu$ F	M 16V
C416	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C773	70041596	Cap, Chip	10nF	K 50V
C417	70040873	Cap, Plastic	82nF	J 63V	C774	70041698	Cap, Chip	18nF	K 50V
C419	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C775	70041569	Cap, Plastic	100nF	J 100V
C420	70041016	Cap, Chip	47pF	J 50V	C777	24214221	Cap, Ceramic	220pF	K 500V
C421	70041401	Cap, Chip	200pF	J 50V	C781	70041113	Cap, Electrolytic	47 $\mu$ F	M 16V
C422	70041681	Cap, Chip	0.047 $\mu$ F	M 50V	C782	70041596	Cap, Chip	10nF	K 50V
C427	24539334	Cap, Plastic	0.33 $\mu$ F	J 50V	C783	70041596	Cap, Chip	10nF	K 50V
C428	24539334	Cap, Plastic	0.33 $\mu$ F	J 50V	C784	70041596	Cap, Chip	10nF	K 50V
C443	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C785	70041568	Cap, Plastic	27nF	J 100V
C501	24815182	Cap, Chip	1800pF	K 50V	$\Delta$ C801	70041687	Cap, Plastic	100nF	M 250V
C505	24815182	Cap, Chip	1800pF	K 50V	$\Delta$ C802	70041584	Cap, Ceramic	220pF	K 400V
C508	70041323	Cap, Chip	8pF	C 50V	$\Delta$ C803	70041584	Cap, Ceramic	220pF	K 400V
C509	24774100	Cap, Chip	10pF	D 50V	$\Delta$ C804	70041687	Cap, Plastic	100nF	M 250V
C510	24774100	Cap, Chip	10pF	D 50V	$\Delta$ C805	70041576	Cap, Electrolytic	470 $\mu$ F	M 450V
C511	24815222	Cap, Chip	2200pF	K 50V	C806	70041499	Cap, Plastic	33nF	J 630V
C512	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C807	24539184	Cap, Plastic	0.18 $\mu$ F	J 50V
C513	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C808	70041184	Cap, Chip	12nF	K 50V
C515	24783151	Cap, Chip	150pF	J 50V	C809	70041370	Cap, Ceramic	100pF	K 1kV
C516	70041328	Cap, Chip	100nF	Z 25V	$\Delta$ C811	70041320	Cap, Ceramic	2.2F	M 125V
C517	70041328	Cap, Chip	100nF	Z 25V	C812	70040729	Cap, Chip	1nF	J 50V
C518	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C813	70041370	Cap, Ceramic	100pF	K 1kV
C519	24783101	Cap, Chip	100pF	J 50V	$\Delta$ C821	70041510	Cap, Electrolytic	820 $\mu$ F	M 16V
C520	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	C822	70041511	Cap, Electrolytic	220 $\mu$ F	M 16V
C521	24783101	Cap, Chip	100pF	J 50V	$\Delta$ C823	70041508	Cap, Electrolytic	1mF	M 10V
C522	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C824	70041509	Cap, Electrolytic	100 $\mu$ F	M 10V
C523	24815102	Cap, Chip	1000pF	K 50V	$\Delta$ C825	70041507	Cap, Electrolytic	220 $\mu$ F	M 10V
C524	24815102	Cap, Chip	1000pF	K 50V	C826	70041730	Cap, Electrolytic	22 $\mu$ F	M 16V
C525	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C827	70041730	Cap, Electrolytic	22 $\mu$ F	M 16V
C526	70041515	Cap, Electrolytic	33 $\mu$ F	M 25V	C828	70041730	Cap, Electrolytic	22 $\mu$ F	M 16V
C528	70041328	Cap, Chip	100nF	Z 25V	C829	70041509	Cap, Electrolytic	100 $\mu$ F	M 10V
C529	70041596	Cap, Chip	10nF	K 50V	C830	70041517	Cap, Electrolytic	22 $\mu$ F	M 50V
C530	70041596	Cap, Chip	10nF	K 50V	C831	70041517	Cap, Electrolytic	22 $\mu$ F	M 50V
C531	70041328	Cap, Chip	100nF	Z 25V	C832	24539224	Cap, Plastic	0.22 $\mu$ F	J 50V
C532	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	$\Delta$ C835	70041575	Cap, Electrolytic	470 $\mu$ F	M 35V
C533	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C836	70041574	Cap, Electrolytic	100 $\mu$ F	M 35V
C534	70041506	Cap, Electrolytic	10 $\mu$ F	M 25V	C837	24539334	Cap, Plastic	0.33 $\mu$ F	J 50V
C535	70041596	Cap, Chip	10nF	K 50V	C838	70041731	Cap, Electrolytic	47 $\mu$ F	M 16V
C536	70041596	Cap, Chip	10nF	K 50V	C842	70041729	Cap, Electrolytic	10 $\mu$ F	M 16V
C537	70041596	Cap, Chip	10nF	K 50V	C920	70041504	Cap, Electrolytic	470nF	M 50V
C538	70041596	Cap, Chip	10nF	K 50V	C921	70041504	Cap, Electrolytic	470nF	M 50V
C539	70041589	Cap, Chip	8pF	D 50V	C922	70041504	Cap, Electrolytic	470nF	M 50V
C540	24774070	Cap, Chip	7pF	D 50V	C923	70041504	Cap, Electrolytic	470nF	M 50V
C542	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C924	70041504	Cap, Electrolytic	470nF	M 50V
C543	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C925	70041504	Cap, Electrolytic	470nF	M 50V
C544	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C926	70041583	Cap, Electrolytic	470nF	M 50V
C546	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C928	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C547	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V	C929	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C548	70041518	Cap, Electrolytic	22 $\mu$ F	M 35V	C930	24591103	Cap, Plastic	0.01 $\mu$ F	J 50V
C549	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C931	24591103	Cap, Plastic	0.01 $\mu$ F	J 50V
C552	24093962	Cap, Variable	20pF		C932	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C560	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C933	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C561	70041314	Cap, Electrolytic	47 $\mu$ F	M 6.3V	C934	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C562	24092178	Cap, Chip	0.1 $\mu$ F	K 25V	C935	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V
C575	24815472	Cap, Chip	4700pF	K 50V	C936	24591103	Cap, Plastic	0.01 $\mu$ F	J 50V
C576	70040991	Cap, Chip	4.7nF	M 50V	C937	24591103	Cap, Plastic	0.01 $\mu$ F	J 50V
C580	24783270	Cap, Chip	27pF	J 50V	C938	70041301	Cap, Electrolytic	22 $\mu$ F	M 16V
C581	70041684	Cap, Ceramic	82pF	J 50V	C939	70041301	Cap, Electrolytic	22 $\mu$ F	M 16V
C597	70041573	Cap, Electrolytic	0.001F	M 6.3V	C940	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V
C701	70041708	Cap, Chip	470pF	J 50V	C941	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V
C702	24815182	Cap, Chip	1800pF	K 50V	C946	24815562	Cap, Chip	5600pF	K 50V
C703	70041504	Cap, Electrolytic	470nF	M 50V	C947	24815562	Cap, Chip	5600pF	K 50V
C704	24783101	Cap, Chip	100pF	J 50V	C950	24794331	Cap, Electrolytic	330 $\mu$ F	M 16V
C705	70041596	Cap, Chip	10nF	K 50V	C963	70041301	Cap, Electrolytic	22 $\mu$ F	M 16V
C706	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V	C964	70041577	Cap, Electrolytic	330 $\mu$ F	M 16V
C707	70041004	Cap, Chip	680pF	J 50V	C968	70041578	Cap, Electrolytic	220nF	M 50V
C708	70041301	Cap, Electrolytic	22 $\mu$ F	M 16V	C969	70041328	Cap, Chip	100nF	Z 25V
C709	70041328	Cap, Chip	100nF	Z 25V	C970	70041535	Cap, Chip	47nF	Z 50V
C715	70041655	Cap, Chip	15nF	K 50V	C971	70041572	Cap, Electrolytic	330 $\mu$ F	M 10V
C716	70041655	Cap, Chip	15nF	K 50V	C972	70041596	Cap, Chip	10nF	K 50V

LOCATION NUMBER	PART NUMBER	DESCRIPTION				LOCATION NUMBER	PART NUMBER	DESCRIPTION			
C973	70041038	Cap, Electrolytic	10 $\mu$ F	M 16V		R515	24872473	Res, Chip	47k $\Omega$	J 1/16W	
C975	24783680	Cap, Chip	68pF	J 50V		R516	24872912	Res, Chip	9.1k $\Omega$	J 1/16W	
C101	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V		R517	24872103	Res, Chip	10k $\Omega$	J 1/16W	
C102	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V		R518	24872163	Res, Chip	16k $\Omega$	J 1/16W	
C103	24815102	Cap, Chip	1000pF	K 50V		R519	24872114	Res, Chip	110k $\Omega$	J 1/16W	
		- RESISTORS -				R520	24872114	Res, Chip	110k $\Omega$	J 1/16W	
R092	24871202	Res, Chip	2k $\Omega$	J 1/8W		R521	70041598	Res, Carbon	1 $\Omega$	J 1/6W	
R093	24871202	Res, Chip	2k $\Omega$	J 1/8W		R522	24871201	Res, Chip	200 $\Omega$	J 1/8W	
R102	70041093	Chip Jumper				R525	24871103	Res, Chip	10k $\Omega$	J 1/8W	
R104	24872124	Res, Chip	120k $\Omega$	J 1/16W		R526	24871103	Res, Chip	10k $\Omega$	J 1/8W	
R105	24871680	Res, Chip	68k $\Omega$	J 1/8W		R527	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R106	70041609	Res, Chip	9.1k $\Omega$	F 1/8W		R528	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R110	24871101	Res, Chip	100 $\Omega$	J 1/8W		R529	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
△R111	70041541	Res, Fusible	8.2 $\Omega$	J 1/2W		R530	24872222	Res, Chip	2.2k $\Omega$	J 1/16W	
R112	24872821	Res, Chip	820 $\Omega$	J 1/16W		R531	24872392	Res, Chip	3.9k $\Omega$	J 1/16W	
R201	24871331	Res, Chip	330 $\Omega$	J 1/8W		R532	24872222	Res, Chip	2.2k $\Omega$	J 1/16W	
R202	24872512	Res, Chip	5.1k $\Omega$	J 1/16W		R533	24872103	Res, Chip	10k $\Omega$	J 1/16W	
R203	24872102	Res, Chip	1k $\Omega$	J 1/16W		R534	24872303	Res, Chip	30k $\Omega$	J 1/16W	
R204	70041613	Res, Chip	2M $\Omega$	J 1/10W		R535	24872473	Res, Chip	47k $\Omega$	J 1/16W	
R205	24872122	Res, Chip	1.2k $\Omega$	J 1/16W		R536	24871102	Res, Chip	1k $\Omega$	J 1/8W	
R206	24872272	Res, Chip	2.7k $\Omega$	J 1/16W		R537	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R207	24872152	Res, Chip	1.5k $\Omega$	J 1/16W		R538	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R208	24872271	Res, Chip	270 $\Omega$	J 1/16W		R548	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R209	24872222	Res, Chip	2.2k $\Omega$	J 1/16W		R549	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R210	24872152	Res, Chip	1.5k $\Omega$	J 1/16W		R560	70040321	Res, Carbon	4.7k $\Omega$	J 1/8W	
R211	24872681	Res, Chip	680 $\Omega$	J 1/16W		R561	24871102	Res, Chip	1k $\Omega$	J 1/8W	
R213	24872822	Res, Chip	8.2k $\Omega$	J 1/16W		R562	24871102	Res, Chip	1k $\Omega$	J 1/8W	
R214	24872105	Res, Chip	1M $\Omega$	J 1/16W		R563	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R215	24872105	Res, Chip	1M $\Omega$	J 1/16W		R566	24366272	Res, Carbon	2.7k $\Omega$	J 1/6W	
R216	24872101	Res, Chip	100 $\Omega$	J 1/16W		R567	24366272	Res, Carbon	2.7k $\Omega$	J 1/6W	
R217	24872681	Res, Chip	680 $\Omega$	J 1/16W		R568	24366202	Res, Carbon	2k $\Omega$	J 1/6W	
R218	24872332	Res, Chip	3.3k $\Omega$	J 1/16W		R569	24366202	Res, Carbon	2k $\Omega$	J 1/6W	
R221	24872102	Res, Chip	1k $\Omega$	J 1/16W		R570	24872103	Res, Chip	10k $\Omega$	J 1/16W	
R222	24872681	Res, Chip	680 $\Omega$	J 1/16W		R571	24872103	Res, Chip	10k $\Omega$	J 1/16W	
R226	24872182	Res, Chip	1.8k $\Omega$	J 1/16W		R572	24871472	Res, Chip	4.7k $\Omega$	J 1/8W	
R227	70041093	Chip Jumper				R574	70041096	Chip Jumper			
R240	24872682	Res, Chip	6.8k $\Omega$	J 1/16W		R575	24872512	Res, Chip	5.1k $\Omega$	J 1/16W	
R241	24872473	Res, Chip	47k $\Omega$	J 1/16W		△R591	70041605	Res, Fusible	18 $\Omega$	J 1/4W	
R261	24872124	Res, Chip	120k $\Omega$	J 1/16W		R592	24872472	Res, Chip	4.7k $\Omega$	J 1/16W	
R262	24871223	Res, Chip	22k $\Omega$	J 1/8W		R593	24366102	Res, Carbon	1k $\Omega$	J 1/6W	
R263	70041096	Chip Jumper				R598	70041136	Res, Chip	300 $\Omega$	J 1/8W	
R264	70041096	Chip Jumper				R599	24871103	Res, Chip	10k $\Omega$	J 1/8W	
R268	24872182	Res, Chip	1.8k $\Omega$	J 1/16W		R601	24872681	Res, Chip	680 $\Omega$	J 1/16W	
R269	24872821	Res, Chip	820 $\Omega$	J 1/16W		R615	24871222	Res, Chip	2.2k $\Omega$	J 1/8W	
R270	24872681	Res, Chip	680 $\Omega$	J 1/16W		R621	24871104	Res, Chip	100k $\Omega$	J 1/8W	
R271	24872104	Res, Chip	100k $\Omega$	J 1/16W		R622	24871104	Res, Chip	100k $\Omega$	J 1/8W	
R274	70041096	Chip Jumper				R701	24872473	Res, Chip	47k $\Omega$	J 1/16W	
R275	24872223	Res, Chip	22k $\Omega$	J 1/16W		R702	24872182	Res, Chip	1.8k $\Omega$	J 1/16W	
R276	24872682	Res, Chip	6.8k $\Omega$	J 1/16W		R703	24872334	Res, Chip	330k $\Omega$	J 1/16W	
R401	24872333	Res, Chip	33k $\Omega$	J 1/16W		R704	24872181	Res, Chip	180 $\Omega$	J 1/16W	
R402	24872102	Res, Chip	1k $\Omega$	J 1/16W		R705	24872113	Res, Chip	11k $\Omega$	J 1/16W	
R403	24872222	Res, Chip	2.2k $\Omega$	J 1/16W		R706	24872562	Res, Chip	5.6k $\Omega$	J 1/16W	
R405	24872333	Res, Chip	33k $\Omega$	J 1/16W		R707	24872105	Res, Chip	1M $\Omega$	J 1/16W	
R406	24871183	Res, Chip	18k $\Omega$	J 1/8W		R716	24872181	Res, Chip	180 $\Omega$	J 1/16W	
R415	24872102	Res, Chip	1k $\Omega$	J 1/16W		R717	70041096	Chip Jumper			
R416	24872105	Res, Chip	1M $\Omega$	J 1/16W		R718	24872562	Res, Chip	5.6k $\Omega$	J 1/16W	
R420	70041169	Res, Chip	68 $\Omega$	J 1/10W		R719	24871273	Res, Chip	27k $\Omega$	J 1/8W	
R425	24872473	Res, Chip	47k $\Omega$	J 1/16W		R733	24872104	Res, Chip	100k $\Omega$	J 1/16W	
R426	24872473	Res, Chip	47k $\Omega$	J 1/16W		R734	24872104	Res, Chip	100k $\Omega$	J 1/16W	
R429	70041093	Chip Jumper				R735	24872513	Res, Chip	51k $\Omega$	J 1/16W	
R432	24872222	Res, Chip	2.2k $\Omega$	J 1/16W		R740	24872393	Res, Chip	39k $\Omega$	J 1/16W	
R501	24872472	Res, Chip	4.7k $\Omega$	J 1/16W		R741	24872273	Res, Chip	27k $\Omega$	J 1/16W	
R502	24872821	Res, Chip	820 $\Omega$	J 1/16W		R771	70041552	Res, Chip	3.3 $\Omega$	J 1/16W	
R503	24872471	Res, Chip	470 $\Omega$	J 1/16W		R772	24872123	Res, Chip	12k $\Omega$	J 1/16W	
R504	24872224	Res, Chip	220k $\Omega$	J 1/16W		R773	24872101	Res, Chip	100 $\Omega$	J 1/16W	
R505	24872684	Res, Chip	680k $\Omega$	J 1/16W		R774	24871339	Res, Chip	3.3 $\Omega$	J 1/8W	
R506	70041554	Res, Chip	4.7M $\Omega$	K 1/16W		R775	24872152	Res, Chip	1.5k $\Omega$	J 1/16W	
R507	70041554	Res, Chip	4.7M $\Omega$	K 1/16W		R777	24871152	Res, Chip	1.5k $\Omega$	J 1/8W	
R508	24872182	Res, Chip	1.8k $\Omega$	J 1/16W		R782	24872822	Res, Chip	8.2k $\Omega$	J 1/16W	
R509	24872563	Res, Chip	56k $\Omega$	J 1/16W		R783	24872101	Res, Chip	100 $\Omega$	J 1/16W	
R510	24872182	Res, Chip	1.8k $\Omega$	J 1/16W		R784	24871229	Res, Chip	2.2 $\Omega$	J 1/8W	
R511	24872563	Res, Chip	56k $\Omega$	J 1/16W		R789	70041096	Chip Jumper			
R512	24871102	Res, Chip	1k $\Omega$	J 1/8W		R790	24872473	Res, Chip	47k $\Omega$	J 1/16W	
R513	24871102	Res, Chip	1k $\Omega$	J 1/8W		R793	24872153	Res, Chip	15k $\Omega$	J 1/16W	
R514	24872473	Res, Chip	47k $\Omega$	J 1/16W		R804	24871151	Res, Chip	150 $\Omega$	J 1/8W	





LOCATION NUMBER	PART NUMBER	DESCRIPTION			LOCATION NUMBER	PART NUMBER	DESCRIPTION		
C436	70041298	Cap, Electrolytic	1 $\mu$ F	M 50V	LF01	23238717	Coil, Peaking	TRF4569AJ	
C437	70041472	Cap, Chip	1nF	K 50V	LF03	70011996	Coil, Peaking		
C438	70040238	Cap, Ceramic, Chip	15pF	J 50V	LF04	70011541	Coil, Peaking		
C439	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V			- CAPACITORS -		
C440	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V	CF01	70011349	Cap, Electrolytic	1 $\mu$ F	M 50V
C441	70041376	Cap, Chip	10nF	Z 50V	CF02	24201470	Cap, Electrolytic	47 $\mu$ F	M 6.3V
C442	70041376	Cap, Chip	10nF	Z 50V	CF03	70041376	Cap, Chip	10nF	Z 50V
C444	70040228	Cap, Ceramic, Chip	22pF	J 50V	CF04	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V
C445	70041589	Cap, Chip	8pF	D 50V	CF05	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V
C446	70040259	Cap, Ceramic, Chip	27pF	J 50V	CF06	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V
C447	70041376	Cap, Chip	10nF	Z 50V	CF07	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V
C448	70041103	Cap, Chip	33pF	J 50V	CF08	24201470	Cap, Electrolytic	47 $\mu$ F	M 6.3V
C449	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V	CF09	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
		- RESISTORS -			CF10	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
R231	70040371	Res, Chip	22k $\Omega$	J 1/16W	CF12	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
R232	70040371	Res, Chip	22k $\Omega$	J 1/16W	CF13	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V
R233	70041171	Res, Chip	1.2k $\Omega$	J 1/10W	CF14	70041376	Cap, Chip	10nF	Z 50V
R430	70040353	Res, Chip	820 $\Omega$	J 1/16W	CF16	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
R431	70040353	Res, Chip	820 $\Omega$	J 1/16W	CF17	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
R433	70041694	Res, Chip	7.5k $\Omega$	J 1/16W	CF18	24092293	Cap, Chip	0.1 $\mu$ F	Z 25V
R434	70040373	Res, Chip	47k $\Omega$	J 1/16W	CF20	24781470	Cap, Chip	47pF	J 50V
R436	70040339	Res, Chip	330 $\Omega$	J 1/16W	CF21	70041704	Cap, Chip	47nF	K 10V
R437	70040354	Res, Chip	1k $\Omega$	J 1/16W	CF22	70040268	Cap, Ceramic, Chip	22nF	K 25V
R438	70041171	Res, Chip	1.2k $\Omega$	J 1/10W	CF23	70040268	Cap, Ceramic, Chip	22nF	K 25V
R439	70040571	Res, Chip	12k $\Omega$	J 1/16W	CF36	70041372	Cap, Chip	39pF	J 50V
R440	70040571	Res, Chip	12k $\Omega$	J 1/16W	CF37	70040239	Cap, Ceramic, Chip	18pF	J 50V
R441	70041171	Res, Chip	1.2k $\Omega$	J 1/10W	CF38	70041376	Cap, Chip	10nF	Z 50V
R443	70040570	Res, Chip	470 $\Omega$	J 1/16W	CF39	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V
R445	70040391	Chip Jumper			CF40	70040228	Cap, Ceramic, Chip	22pF	J 50V
R446	70040348	Res, Chip	100 $\Omega$	J 1/16W	CF41	70040228	Cap, Ceramic, Chip	22pF	J 50V
R447	70040338	Res, Chip	680 $\Omega$	J 1/16W	CF42	70040228	Cap, Ceramic, Chip	22pF	J 50V
R448	70040352	Res, Chip	560 $\Omega$	J 1/16W	CK01	24781151	Cap, Chip	150pF	J 50V
R449	70040371	Res, Chip	22k $\Omega$	J 1/16W	CK02	24205479	Cap, Electrolytic	4.7 $\mu$ F	M 35V
■0035M	70090601	P C Board Assy	Video3		CK03	24781151	Cap, Chip	150pF	J 50V
		- TRANSISTORS -			CK04	24205479	Cap, Electrolytic	4.7 $\mu$ F	M 35V
Q414	A6335470	Transistor, Chip	2SC2712Y-R		CK05	70041707	Cap, Chip	1nF	Z 50V
Q415	A6335470	Transistor, Chip	2SC2712Y-R		CK06	24203220	Cap, Electrolytic	22 $\mu$ F	M 16V
		- COILS -			CK07	70041707	Cap, Chip	1nF	Z 50V
L403	23238703	Coil, Peaking	TRF4820AJ		CK08	24203220	Cap, Electrolytic	22 $\mu$ F	M 16V
		- CAPACITORS -			CK09	24781151	Cap, Chip	150pF	J 50V
C425	24781390	Cap, Chip	39pF	J 50V	CK10	24205479	Cap, Electrolytic	4.7 $\mu$ F	M 35V
C426	24781101	Cap, Chip	100pF	J 50V	CK11	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
C426	70040262	Cap, Ceramic, Chip	100pF	J 50V	CK12	24781151	Cap, Chip	150pF	J 50V
		- RESISTORS -			CK13	24205479	Cap, Electrolytic	4.7 $\mu$ F	M 35V
R407	70040348	Res, Chip	100 $\Omega$	J 1/16W	CK14	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
R408	70040684	Res, Chip	680 $\Omega$	J 1/8W	CK23	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
R409	70040354	Res, Chip	1k $\Omega$	J 1/16W	CK24	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
R410	70040354	Res, Chip	1k $\Omega$	J 1/16W	CK25	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
R424	70040335	Res, Chip	27k $\Omega$	J 1/16W	CK26	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V
■0030M	70090543	P C Board Assy	Terminal		CK27	24203220	Cap, Electrolytic	22 $\mu$ F	M 16V
		- INTEGRATED CIRCUITS -			CK28	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V
ICF01	70011881	IC	STV6400		CK29	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V
ICF40	70011903	IC	TA78L09S		CK37	70041707	Cap, Chip	1nF	Z 50V
ICK01	70011882	IC	BA7730S		CK38	70041707	Cap, Chip	1nF	Z 50V
		- TRANSISTORS -					- RESISTORS -		
QF10	A6014040	Transistor, Chip	RN2404		RF01	70040373	Res, Chip	47k $\Omega$	J 1/16W
QF11	A6004040	Transistor, Chip	RN1404		RF02	70040350	Res, Chip	220 $\Omega$	J 1/16W
QF12	A6335470	Transistor, Chip	2SC2712-Y		RF03	70040350	Res, Chip	220 $\Omega$	J 1/16W
QF15	A6004040	Transistor, Chip	RN1404		RF04	70040561	Res, Chip	82pF	J 1/8W
QF16	A6335470	Transistor, Chip	2SC2712-Y		RF07	70040812	Res, Chip	68 $\Omega$	J 1/8W
QF38	A6541130	Transistor, Chip	2SA1162-Y		RF08	70040373	Res, Chip	47k $\Omega$	J 1/16W
QF39	A6335470	Transistor, Chip	2SC2712-Y		RF09	70040363	Res, Chip	47k $\Omega$	J 1/16W
QK03	A6004040	Transistor, Chip	RN1404		RF10	70040358	Res, Chip	10k $\Omega$	J 1/16W
QK04	A6004040	Transistor, Chip	RN1404		RF11	70041801	Res, Chip	11k $\Omega$	J 1/10W
		- DIODES -			RF17	70040391	Chip Jumper		
DF01	70010341	Diode	1SS226		RF19	70041385	Res, Chip	27k $\Omega$	J 1/8W
DF02	70010341	Diode	1SS226		RF20	70041385	Res, Chip	27k $\Omega$	J 1/8W
DF04	70010341	Diode	1SS226		RF21	70040374	Res, Chip	82k $\Omega$	J 1/16W
DF05	70010341	Diode	1SS226		RF22	70040133	Res, Chip	1k $\Omega$	J 1/8W
DF07	70010341	Diode	1SS226		RF23	70040133	Res, Chip	1k $\Omega$	J 1/8W
DK03	70010341	Diode	1SS226		RF24	70040561	Res, Chip	82pF	J 1/8W
DK04	70010341	Diode	1SS226		RF26	70040391	Chip Jumper		
		- COILS -			RF27	70040348	Res, Chip	100 $\Omega$	J 1/16W
					RF28	70040338	Res, Chip	680 $\Omega$	J 1/16W
					RF29	70040351	Res, Chip	390 $\Omega$	J 1/16W

LOCATION NUMBER	PART NUMBER	DESCRIPTION		LOCATION NUMBER	PART NUMBER	DESCRIPTION			
RF30	70040365	Res, Chip	68kΩ	J 1/16W	R032	70041093	Chip Jumper		
RF34	70040348	Res, Chip	100Ω	J 1/16W	R033	70041093	Chip Jumper		
RF35	70040359	Res, Chip	15kΩ	J 1/16W	R037	70041093	Chip Jumper		
RF36	70040354	Res, Chip	1kΩ	J 1/16W	R040	70041093	Chip Jumper		
RF37	70040356	Res, Chip	18kΩ	J 1/16W	R041	70041093	Chip Jumper		
RF38	70040354	Res, Chip	1kΩ	J 1/16W	R043	70041096	Chip Jumper		
RF39	70040358	Res, Chip	10kΩ	J 1/16W	R046	70041093	Chip Jumper		
RF40	70041167	Res, Chip	1.8kΩ	J 1/8W	R048	70041093	Chip Jumper		
RF41	70041167	Res, Chip	1.8kΩ	J 1/8W	R060	70041096	Chip Jumper		
RF42	70041167	Res, Chip	1.8kΩ	J 1/8W	R062	24871152	Res, Chip	1.5kΩ	J 1/8W
RF43	70040364	Res, Chip	56kΩ	J 1/16W	R064	24872152	Res, Chip	1.5kΩ	J 1/16W
RF44	70041800	Res, Chip	4.3kΩ	J 1/10W	R065	24871101	Res, Chip	100Ω	J 1/8W
RF45	70040350	Res, Chip	220Ω	J 1/16W	R067	24872470	Res, Chip	47Ω	J 1/16W
RK01	70041261	Res, Chip	5.6kΩ		R068	70041096	Chip Jumper		
RK02	70041387	Res, Chip	220kΩ	J 1/10W	R069	24872103	Res, Chip	10kΩ	J 1/16W
RK03	70041261	Res, Chip	5.6kΩ		R070	24871101	Res, Chip	100Ω	J 1/8W
RK04	70041387	Res, Chip	220kΩ	J 1/10W	R071	24871101	Res, Chip	100Ω	J 1/8W
RK05	70040131	Res, Chip	820Ω	J 1/8W	R072	70041093	Chip Jumper		
RK07	70040363	Res, Chip	47kΩ	J 1/16W	R073	70041093	Chip Jumper		
RK08	70040131	Res, Chip	820Ω	J 1/8W	R082	70041093	Chip Jumper		
RK10	70040363	Res, Chip	47kΩ	J 1/16W	R083	70041093	Chip Jumper		
RK11	70041261	Res, Chip	5.6kΩ		R084	70041093	Chip Jumper		
RK12	70041198	Res, Chip	47kΩ	J 1/8W	R091	24872683	Res, Chip	68kΩ	J 1/16W
RK13	70040362	Res, Chip	33kΩ	J 1/16W			- MISCELLANEOUS -		
RK14	70041261	Res, Chip	5.6kΩ		H004	70011845	IF Module		
RK15	70041198	Res, Chip	47kΩ	J 1/8W	H004A	70060762	Eyelet		
RK16	70040362	Res, Chip	33kΩ	J 1/16W	H005	70012019	Tuner	FE4231	
RK33	70040135	Res, Chip	12kΩ	J 1/8W	H005A	70060762	Eyelet		
RK34	70040372	Res, Chip	33kΩ	J 1/16W	Z002	70011260	Filter		
RK35	70040135	Res, Chip	12kΩ	J 1/8W					
RK36	70040372	Res, Chip	33kΩ	J 1/16W	■0140M	70090510	P C Board Assy	MPX	
RK37	70040353	Res, Chip	820Ω	J 1/16W			- INTEGRATED CIRCUITS -		
RK38	70040353	Res, Chip	820Ω	J 1/16W	ICD01	70011902	IC	TA78L008AP	
RK39	70040363	Res, Chip	47kΩ	J 1/16W	ICD03	70011885	IC	MSP3410	
RK40	70040363	Res, Chip	47kΩ	J 1/16W	ICD04	70011886	IC	M5218AP	
RK60	70040371	Res, Chip	22kΩ	J 1/16W	ICD05	70011886	IC	M5218AP	
		- MISCELLANEOUS -					- TRANSISTORS -		
PF03	70011920	Connector			QD06	A6335470	Transistor, Chip	2SC2712-Y	
PF04	70011920	Connector			QD07	70011868	Transistor, Chip	IMX1	
PF07	70061013	Pin Jack			QD09	70011869	Transistor, Chip	RN2406	
PF08	70011916	Connector			QD10	A6335470	Transistor, Chip	2SC2712-Y	
					QD11	70011868	Transistor, Chip	IMX1	
■0110M	70090526	P C Board Assy	Sub Main		QD12	70011934	Transistor	KTA1273	
		- INTEGRATED CIRCUITS -			QD13	A6004020	Transistor, Chip	RN1402	
IC891	70011904	IC	PQ05SZ11		QD90	A6335470	Transistor, Chip	2SC2712-Y	
		- TRANSISTORS -					- DIODES -		
Q001	A6335470	Transistor, Chip	2SC2712-Y		DD01	23118041	Diode, Chip	MA111	
Q002	A6541130	Transistor, Chip	2SA1162-Y				- COILS -		
Q060	A6541130	Transistor, Chip	2SA1162-Y		LD01	23238713	Coil, Peaking	TRF4120AJ	
Q061	A6335470	Transistor, Chip	2SC2712-Y		LD02	23238707	Coil, Peaking	TRF4390AJ	
		- COILS -			LD04	70011456	Coil, Peaking		
L002	23238714	Coil, Peaking	TRF4100AJ		LD05	70011456	Coil, Peaking		
L060	23238506	Coil, Peaking	TRF4229AJ		LD06	23238707	Coil, Peaking	TRF4390AJ	
L080	23238714	Coil, Peaking	TRF4100AJ		LD07	23238707	Coil, Peaking	TRF4390AJ	
		- CAPACITORS -					- CAPACITORS -		
C061	70041011	Cap, Chip	10pF	J 50V	CD02	24783470	Cap, Chip	47pF	J 50V
C080	24794470	Cap, Electrolytic	47μF	M 16V	CD03	24783470	Cap, Chip	47pF	J 50V
C081	24814103	Cap, Chip	0.01μF	Z 50V	CD04	70041530	Cap, Chip	330nF	Z 16V
C082	24794470	Cap, Electrolytic	47μF	M 16V	CD05	70041596	Cap, Chip	10nF	K 50V
C083	24814103	Cap, Chip	0.01μF	Z 50V	CD06	24814103	Cap, Chip	0.01μF	Z 50V
C089	24814103	Cap, Chip	0.01μF	Z 50V	CD07	24287103	Cap, Chip	0.01μF	Z 50V
C090	70041500	Cap, Electrolytic	47μF	M 50V	CD08	24287103	Cap, Chip	0.01μF	Z 50V
C091	24794470	Cap, Electrolytic	47μF	M 16V	CD09	24287103	Cap, Chip	0.01μF	Z 50V
C093	24794470	Cap, Electrolytic	47μF	M 16V	CD10	70041282	Cap, Chip	2pF	C 50V
C891	70041530	Cap, Chip	330nF	Z 16V	CD11	24783010	Cap, Chip	1pF	C 50V
C892	24794470	Cap, Electrolytic	47μF	M 16V	CD12	24774270	Cap, Chip	27pF	J 50V
		- RESISTORS -			CD15	24206010	Cap, Electrolytic	1μF	M 50V
R001	24872102	Res, Chip	1kΩ	J 1/16W	CD16	70041181	Cap, Electrolytic	220μF	M 10V
R002	24872271	Res, Chip	270Ω	J 1/16W	CD17	24287103	Cap, Chip	0.01μF	Z 50V
R003	24872821	Res, Chip	820Ω	J 1/16W	CD18	24203100	Cap, Electrolytic	10μF	M 16V
R004	24872152	Res, Chip	1.5kΩ	J 1/16W	CD19	24287103	Cap, Chip	0.01μF	Z 50V
R005	24872681	Res, Chip	680Ω	J 1/16W	CD20	24203101	Cap, Electrolytic	100μF	M 16V
R006	70041096	Chip Jumper			CD21	24287103	Cap, Chip	0.01μF	Z 50V
R022	70041096	Chip Jumper			CD22	24203100	Cap, Electrolytic	10μF	M 16V
R031	70041093	Chip Jumper			CD23	24287103	Cap, Chip	0.01μF	Z 50V

LOCATION NUMBER	PART NUMBER	DESCRIPTION						
CD24	24287103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD25	24203101	Cap, Electrolytic	100 $\mu$ F	M 16V				
CD26	24203220	Cap, Electrolytic	22 $\mu$ F	M 16V				
CD27	24287103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD28	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V				
CD29	24092178	Cap, Chip	0.1 $\mu$ F	K 25V				
CD30	70041706	Cap, Chip	470pF	J 50V				
CD31	70041706	Cap, Chip	470pF	J 50V				
CD32	70040737	Cap, Electrolytic	33 $\mu$ F	M 16V				
CD33	24092178	Cap, Chip	0.1 $\mu$ F	K 25V				
CD34	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V				
CD35	24203100	Cap, Electrolytic	10 $\mu$ F	M 16V				
CD36	70040994	Cap, Chip	390pF	J 50V				
CD37	70040994	Cap, Chip	390pF	J 50V				
CD38	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD39	24203101	Cap, Electrolytic	100 $\mu$ F	M 16V				
CD40	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V				
CD41	24815222	Cap, Chip	2200pF	K 50V				
CD42	24815222	Cap, Chip	2200pF	K 50V				
CD43	70041530	Cap, Chip	330nF	Z 16V				
CD44	24815392	Cap, Chip	3900pF	K 50V				
CD47	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V				
CD48	24206010	Cap, Electrolytic	1 $\mu$ F	M 50V				
CD49	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD51	24093962	Cap, Variable	20pF					
CD61	70041530	Cap, Chip	330nF	Z 16V				
CD62	24203101	Cap, Electrolytic	100 $\mu$ F	M 16V				
CD63	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD64	70041530	Cap, Chip	330nF	Z 16V				
CD65	70041530	Cap, Chip	330nF	Z 16V				
CD66	24203470	Cap, Electrolytic	47 $\mu$ F	M 16V				
CD67	24815392	Cap, Chip	3900pF	K 50V				
CD68	24206229	Cap, Electrolytic	2.2 $\mu$ F	M 50V				
CD69	24206229	Cap, Electrolytic	2.2 $\mu$ F	M 50V				
CD70	24815392	Cap, Chip	3900pF	K 50V				
CD71	70041594	Cap, Chip	8.2nF	K 50V				
CD72	70041594	Cap, Chip	8.2nF	K 50V				
CD73	24206229	Cap, Electrolytic	2.2 $\mu$ F	M 50V				
CD77	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V				
CD81	24815122	Cap, Chip	1200pF	K 50V				
CD90	70041530	Cap, Chip	330nF	Z 16V				
CD91	70041530	Cap, Chip	330nF	Z 16V				
CD92	24814103	Cap, Chip	0.01 $\mu$ F	Z 50V				
- RESISTORS -								
RD01	70041096	Chip Jumper						
RD02	70041096	Chip Jumper						
RD03	24872562	Res, Chip	5.6k $\Omega$	J 1/16W				
RD04	24872392	Res, Chip	3.9k $\Omega$	J 1/16W				
RD05	24872392	Res, Chip	3.9k $\Omega$	J 1/16W				
RD06	24872182	Res, Chip	1.8k $\Omega$	J 1/16W				
RD07	24872332	Res, Chip	3.3k $\Omega$	J 1/16W				
RD08	24872471	Res, Chip	470 $\Omega$	J 1/16W				
RD09	24872221	Res, Chip	220 $\Omega$	J 1/16W				
RD10	24872391	Res, Chip	390 $\Omega$	J 1/16W				
RD11	24872101	Res, Chip	100 $\Omega$	J 1/16W				
RD12	70041096	Chip Jumper						
RD13	70041096	Chip Jumper						
RD14	24872472	Res, Chip	4.7k $\Omega$	J 1/16W				
RD15	70041096	Chip Jumper						
RD16	24872103	Res, Chip	10k $\Omega$	J 1/16W				
RD17	24872103	Res, Chip	10k $\Omega$	J 1/16W				
RD18	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD20	24872124	Res, Chip	120k $\Omega$	J 1/16W				
RD21	24872124	Res, Chip	120k $\Omega$	J 1/16W				
RD22	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD23	24872472	Res, Chip	4.7k $\Omega$	J 1/16W				
RD24	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD25	24872184	Res, Chip	180k $\Omega$	J 1/16W				
RD26	24872184	Res, Chip	180k $\Omega$	J 1/16W				
RD28	24872104	Res, Chip	100k $\Omega$	J 1/16W				
RD29	24872104	Res, Chip	100k $\Omega$	J 1/16W				
RD30	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD31	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD32	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD33	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD34	24872103	Res, Chip	10k $\Omega$	J 1/16W				
RD35	24872103	Res, Chip	10k $\Omega$	J 1/16W				
RD36	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD37	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD38	24871102	Res, Chip	1k $\Omega$	J 1/8W				
RD39	24871562	Res, Chip	5.6k $\Omega$	J 1/8W				
RD40	24871562	Res, Chip	5.6k $\Omega$	J 1/8W				
RD41	24872221	Res, Chip	220 $\Omega$	J 1/16W				
RD42	24872221	Res, Chip	220 $\Omega$	J 1/16W				
RD43	24872221	Res, Chip	220 $\Omega$	J 1/16W				
RD45	70041096	Chip Jumper						
RD47	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD48	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD49	24872102	Res, Chip	1k $\Omega$	J 1/16W				
RD61	70041093	Chip Jumper						
RD63	70041096	Chip Jumper						
RD64	70041096	Chip Jumper						
RD65	70041093	Chip Jumper						
RD66	70041096	Chip Jumper						
RD67	70041093	Chip Jumper						
RD68	70041093	Chip Jumper						
RD70	70041096	Chip Jumper						
RD72	70041093	Chip Jumper						
RD75	70041096	Chip Jumper						
RD77	24872471	Res, Chip	470 $\Omega$	J 1/16W				
RD78	24871102	Res, Chip	1k $\Omega$	J 1/8W				
RD79	70041093	Chip Jumper						
RD80	24872103	Res, Chip	10k $\Omega$	J 1/16W				
RD81	70041093	Chip Jumper						
RD82	70041093	Chip Jumper						
RD83	70041093	Chip Jumper						
RD84	70041096	Chip Jumper						
RD85	70041096	Chip Jumper						
RD86	70041096	Chip Jumper						
RD87	70041096	Chip Jumper						
RD90	24872272	Res, Chip	2.7k $\Omega$	J 1/16W				
RD91	24871222	Res, Chip	2.2k $\Omega$	J 1/8W				
RD92	24871473	Res, Chip	47k $\Omega$	J 1/8W				
RD93	24872104	Res, Chip	100k $\Omega$	J 1/16W				
RD94	24871562	Res, Chip	5.6k $\Omega$	J 1/8W				
RD95	70041096	Chip Jumper						
RD96	70041096	Chip Jumper						
RD99	24871151	Res, Chip	150 $\Omega$	J 1/8W				
- MISCELLANEOUS -								
JPD17	70012001	IC Protector						
PD01	70012011	Connector	2.5mm					
QD03A	70011915	Socket						
XD01	70011858	Crystal	18.432MHz					
ZD01	70011464	Filter	ZBF253D-00F					
ZD02	70011464	Filter	ZBF253D-00F					
ZD03	70011464	Filter	ZBF253D-00F					
ZD04	70011464	Filter	ZBF253D-00F					
ZD05	70011464	Filter	ZBF253D-00F					
ZD06	70011464	Filter	ZBF253D-00F					
ZD07	70011464	Filter	ZBF253D-00F					
ZD08	70011464	Filter	ZBF253D-00F					
ZD09	70011464	Filter	ZBF253D-00F					
ZD10	70011464	Filter	ZBF253D-00F					
ZD11	70011464	Filter	ZBF253D-00F					
ZD12	70011464	Filter	ZBF253D-00F					
ZD15	70011862	Filter	ZJSR5101					
ZD16	70011862	Filter	ZJSR5101					
ZD17	70011862	Filter	ZJSR5101					
ZD18	70011863	Filter	ZJK5103D					
ZD19	70011863	Filter	ZJK5103D					
ZD20	70011863	Filter	ZJK5103D					
ZD21	70011863	Filter	ZJK5103D					
ZD90	70011862	Filter	ZJSR5101					
ZD91	70011998	Filter	6.5MHz					
0210M	70090533	P C Board Assy	KDB1					
- INTEGRATED CIRCUITS -								
ICX01	70012123	IC	TMP87CK70AF-6203					
- TRANSISTORS -								
QX03	A6335470	Transistor, Chip	ZSC2712-Y					

LOCATION NUMBER	PART NUMBER	DESCRIPTION		LOCATION NUMBER	PART NUMBER	DESCRIPTION	
QX04	A6325549	Transistor	2SC2236-Y	RM24	70040358	Res, Chip	10kΩ J 1/16W
QX05	70011788	Transistor, Chip	RN2402	RM26	70040359	Res, Chip	15kΩ J 1/16W
QX06	70011788	Transistor, Chip	RN2402	RM28	70040359	Res, Chip	15kΩ J 1/16W
		- DIODES -		RM29	70041173	Res, Chip	100kΩ J 1/10W
DX27	70011582	Diode, LED	SE303AC-YD	RM30	70040358	Res, Chip	10kΩ J 1/16W
DX28	70011582	Diode, LED	SE303AC-YD	RM31	70040362	Res, Chip	33kΩ J 1/16W
DX32	70011876	Diode, LED		RM32	70041173	Res, Chip	100kΩ J 1/10W
		- CAPACITORS -		RX43	70040133	Res, Chip	1kΩ J 1/8W
CX01	24201220	Cap, Electrolytic	22μF M 6.3V	RX44	70040354	Res, Chip	1kΩ J 1/16W
CX05	70041690	Cap, Chip	30pF J 50V	RX45	70041694	Res, Chip	7.5kΩ J 1/16W
CX06	70041690	Cap, Chip	30pF J 50V			- MISCELLANEOUS -	
CX07	70041376	Cap, Chip	10nF Z 50V	PM02	70011350	Phono Jack	
CX14	70040262	Cap, Ceramic, Chip	100pF J 50V	PX06	70011350	Phono Jack	
CX20	70041376	Cap, Chip	10nF Z 50V	SX01	23145394	Push Switch, 1C1P	
CX21	70041038	Cap, Electrolytic	10μF M 16V	SX05	23145394	Push Switch, 1C1P	
		- RESISTORS -		SX06	23145394	Push Switch, 1C1P	
RX01	70041614	Res, Chip	1.8kΩ J 1/8W	SX08	23145394	Push Switch, 1C1P	
RX12	70040373	Res, Chip	47kΩ J 1/16W	SX09	23145394	Push Switch, 1C1P	
RX13	70040373	Res, Chip	47kΩ J 1/16W				
RX14	70040373	Res, Chip	47kΩ J 1/16W	■0270M	70090445	P C Board Assy JSB	
RX15	70041352	Res, Chip	4.7kΩ J 1/8W			- MISCELLANEOUS -	
RX20	70040677	Res, Chip	270Ω J 1/8W	SX18	70061011	Switch Shuttle	
RX25	70040679	Res, Chip	2.2kΩ J 1/8W				
RX27	70040358	Res, Chip	10kΩ J 1/16W				
RX28	70040358	Res, Chip	10kΩ J 1/16W				
RX29	70040335	Res, Chip	27kΩ J 1/16W				
RX30	70040565	Res, Chip	2.7kΩ J 1/8W				
RX31	70040565	Res, Chip	2.7kΩ J 1/8W				
RX40	70040373	Res, Chip	47kΩ J 1/16W				
RX41	70040354	Res, Chip	1kΩ J 1/16W				
RX42	70041167	Res, Chip	1.8kΩ J 1/8W				
RX48	70041601	Res, Metal	1.8Ω J 1/2W				
RX61	70040677	Res, Chip	270Ω J 1/8W				
RX64	70041600	Res, Oxide Mental	6.8Ω J 1W				
RX66	70040359	Res, Chip	15kΩ J 1/16W				
RX67	70040678	Res, Chip	470kΩ J 1/8W				
RX68	70040333	Res, Chip	100Ω J 1/8W				
RX72	70040132	Res, Chip	22kΩ J 1/8W				
RX73	70040341	Res, Chip	10Ω J 1/16W				
RX76	70040373	Res, Chip	47kΩ J 1/16W				
		- MISCELLANEOUS -					
GX01	70011879	FIP	7-MT-155GNK				
SX07	23344094	Push Switch					
SX10	23344094	Push Switch					
SX11	23344094	Push Switch					
XX01	70010937	Resonator	8MHz				
ZR01	70011443	F.U.	1R-9106A-D				
■0212M	70090476	P C Board Assy	FCB				
		- CAPACITORS -					
C943	70041472	Cap, Chip	1nF K 50V				
C944	70041472	Cap, Chip	1nF K 50V				
		- RESISTORS -					
R940	70040354	Res, Chip	1kΩ J 1/16W				
R941	70040354	Res, Chip	1kΩ J 1/16W				
RF80	70041441	Res, Chip	75Ω J 1/10W				
		- MISCELLANEOUS -					
P982	70011917	Connector	3.5mm				
P983	70011918	Socket					
PF81	70011919	Socket					
■0225M	70090455	P C Board Assy	KDB2				
		- INTEGRATED CIRCUITS -					
ICM02	70011889	IC	LA6462M				
		- DIODES -					
DM01	70010341	Diode	1SS226				
DX26	70011582	Diode, LED	SE303AC-YD				
DX49	70011875	Diode, LED					
		- CAPACITORS -					
CM27	70041472	Cap, Chip	1nF K 50V				
CM28	24630852	Cap, Electrolytic	22μF M 16V				
CM29	24206338	Cap, Electrolytic	0.33μF M 50V				
CM30	24781151	Cap, Chip	150pF J 50V				
CM31	24781151	Cap, Chip	150pF J 50V				
		- RESISTORS -					

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
DIFFERENCE LIST				
V-854B				
■0270M	70090441	P C Board Assy	JSB	
- MISCELLANEOUS -				
SX18	70011921	Switch, Shuttle		
■0210M	70090553	P C Board Assy	KDB1	
- RESISTORS -				
RX62	70041352	Res, Chip	4.7kΩ	J 1/8W
RX63	70040373	Res, Chip	47kΩ	J 1/16W
■0030M	70090559	P C Board Assy	Terminal	
- INTEGRATED CIRCUITS -				
ICN61	70012043	IC	SDA5648	
- CAPACITORS -				
CN61	24092293	Cap, Chip	0.1μF	Z 25V
CN62	70041264	Cap, Chip	150pF	
CN63	24538334	Cap, Plastic	0.33μF	J 50V
CN64	24591333	Cap, Plastic	0.033μF	J 50V
CN65	70011646	Cap, Plastic	2.2nF	J 50V
- RESISTORS -				
RN63	70040371	Res, Chip	22kΩ	J 1/16W
RN64	70041199	Res, Chip	1MΩ	J 1/10W
RN65	70041173	Res, Chip	100kΩ	J 1/10W
RN68	70041783	Res, Chip	5.1kΩ	J 1/10W
RN69	70041799	Res, Chip	820kΩ	J 1/10W
RN70	70040336	Res, Chip	68kΩ	J 1/16W
RN71	70041862	Res, Chip	1.2MΩ	J 1/10W
■0005M	70090608	P C Board Assy	Main (Type B)	
- TRANSISTORS -				
Q131	A6541130	Transistor, Chip	2SA1162Y-R	
Q132	A6004040	Transistor, Chip	RN1404	
Q133	A6004040	Transistor, Chip	RN1404	
Q134	A6541130	Transistor, Chip	2SA1162Y-R	
- COILS -				
L131	70011773	Coil, Peaking		
L132	23238712	Coil, Peaking	TRF4150AJ	
- CAPACITORS -				
C132	70041113	Cap, Electrolytic	47μF	M 16V
C133	24814103	Cap, Chip	0.01μF	Z 50V
C134	24783151	Cap, Chip	150pF	J 50V
C135	70040238	Cap, Ceramic, Chip	15pF	J 50V
C137	24783221	Cap, Chip	220pF	J 50V
- RESISTORS -				
R131	24872473	Res, Chip	47kΩ	J 1/16W
R132	24872472	Res, Chip	4.7kΩ	J 1/16W
R133	24872104	Res, Chip	100kΩ	J 1/16W
R135	24872103	Res, Chip	10kΩ	J 1/16W
R136	24872223	Res, Chip	22kΩ	J 1/16W
R137	70040684	Res, Chip	680Ω	J 1/8W
R138	70040347	Res, Chip	82Ω	J 1/16W
■0005M	70090557	P C Board Assy	Main (Type A)	
- TRANSISTORS -				
Q131	A6541130	Transistor, Chip	2SA1162-Y	
Q132	A6004040	Transistor, Chip	RN1404	
Q133	A6004040	Transistor, Chip	RN1404	
Q134	A6541130	Transistor, Chip	2SA1162-Y	
- DIODES -				
D822	70011790	Diode	RU2YX	
D823	70011789	Diode	1SS136	
- COILS -				
L131	70011773	Coil, Peaking		
L132	23238712	Coil, Peaking	TRF4150AJ	
- CAPACITORS -				
C132	70041113	Cap, Electrolytic	47μF	M 16V
C133	24814103	Cap, Chip	0.01μF	Z 50V
C134	24783151	Cap, Chip	150pF	J 50V
C135	70040238	Cap, Ceramic, Chip	15pF	J 50V
C137	24783221	Cap, Chip	220pF	J 50V
C809	70041370	Cap, Ceramic	100pF	K 1kV
C813	70041370	Cap, Ceramic	100pF	K 1kV
C822	70041511	Cap, Electrolytic	220μF	M 16V

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
C960	24794331	Cap, Electrolytic	330 $\mu$ F	M 16V
- RESISTORS -				
R111	70041541	Res, Fusible	8.2 $\Omega$	J 1/2W
R131	24872473	Res, Chip	47k $\Omega$	J 1/16W
R132	24872472	Res, Chip	4.7k $\Omega$	J 1/16W
R133	24872104	Res, Chip	100k $\Omega$	J 1/16W
R135	24872103	Res, Chip	10k $\Omega$	J 1/16W
R136	24872223	Res, Chip	22k $\Omega$	J 1/16W
R137	70040684	Res, Chip	680 $\Omega$	J 1/8W
R138	70040347	Res, Chip	82 $\Omega$	J 1/16W
R227	70041093	Chip Jumper		

# SPECIFICATIONS

---

Format	: VHS standard
Recording system	: Rotary, 2-head helical scan system
Video heads	: 4 heads
Video signal system	: CCIR; 625 lines, 50 fields, PAL colour signal NTSC colour, 525 lines
Tape speed	: SP : 23.39 mm/s (PAL)      SP : 33.35 mm/s (NTSC) LP : 11.70 mm/s (PAL)      SLP : 11.12 mm/s (NTSC)
Recording time	: SP : 240 minutes with E240 cassettes (PAL) LP : 480 minutes with E240 cassettes (PAL)
Winding time	: Approx. 110 seconds with E180 cassettes
Dimensions	: 430 (W) × 92 (H) × 318.5 (D) mm
Mass	: 4.7kg
Operating temperature	: +5 to +40°C
Operating humidity	: Less than 80% RH
Mains power	: 230/240 V AC, 50 Hz
Power consumption	: 25 W (in operation)
<b>CONNECTORS</b>	
Aerial input	: 75 Ω coaxial
Aerial output	: 75 Ω coaxial
Video input	: AUDIO/VIDEO SCART socket, 1.0 V(p-p), 75 Ω LINE IN 2 VIDEO Phono type jack, 1.0 V(p-p), 75 Ω
Audio input	: AUDIO/VIDEO SCART socket, 308 mV(rms), more than 10 kΩ LINE IN 2 AUDIO Phono type jacks, 308 mV(rms), more than 47 kΩ
Video output	: AUDIO/VIDEO SCART socket, 1.0 V(p-p), 75 Ω
Audio output	: AUDIO/VIDEO SCART socket, 308 mV(rms), less than 1.0 kΩ AUDIO OUT Phono type jacks, 308 mV(rms), less than 4.7 kΩ
<b>VIDEO</b>	
Signal-to-noise ratio	: More than 43 dB (SP mode/PAL)
<b>AUDIO</b>	
Signal-to-noise ratio	: More than 42 dB (SP mode/PAL/normal mono)
Frequency range	: 20 Hz to 20 kHz (Hi-Fi mode)
Dynamic range	: More than 90 dB (Hi-Fi mode)
Audio track	: 1 track (Normal-mono), 2 channels (Hi-Fi sound)
<b>TIMER</b>	
Clock	: 24-hour digital indication
No. of events	: 6 events 1 month
<b>TUNER</b>	
System	: Frequency synthesizer
Channel coverage	: PAL I VHF: A – J, UHF: E21 – E69
RF converter	: UHF channel 60 (53 – 67, adjustable)
<b>Accessories</b>	
	: Aerial cable ..... 1
	: Remote control unit ..... 1
	: Batteries (R03) ..... 2

Designs and specifications are subject to change without notice.

